

<div>Manual for AR Glasses (model XGA020C)</div> <div><div>Name and contact information of the manufacturer Name: Hubei Xingli Meizu Group Co., Ltd. Address: No. B1345, Chonggu Start-up Area, Taizi Lake Cultural and Digital Creative Industry Park, 14, Shuangmen Avenue, Wuhan Economic and Technological Development Zone, Wuhan, Hubei, China. ID-Number (of manual): XGA020C-Manual-Overseas-V1.0 Do not delete or modify the content of this manual.</div><div>EN</div></div>																	
23																	
<div>StarV Air 2 at a Glance</div> <div><div><div>Microphone</div><div>Roller</div><div>Power Button</div><div>Speaker</div></div><div>Type-C Charging Port</div><div>Bottom View</div><div><div>Microphone</div><div>Leak-proof Speaker</div></div><div>Top View</div></div>																	
24																	
<div>Roller</div> <div><div><div>Long Press</div><div>Single press</div><div>Double press</div><div>Rolling forward</div><div>Rolling backward</div></div><div><div>Back to idle screen/open application list</div><div>Confirm</div><div>Return</div><div>Switch to region next/right/ Switch to region next down</div><div>Switch to region next left/ Switch to region next up</div></div></div> <div><div><div>EN</div></div><div></div></div>																	
25																	
<div>Power button</div> <div><div><div>Single press</div><div>Press and hold for 1s</div><div>Press and hold for 3s/5s</div><div>Double press</div><div>Press and hold for 8s</div></div><div><div>Turn off screen/ Turn on screen</div><div>Activate AI voice assistant</div><div>Power on/off</div><div>Turn on AI conference assistant by default</div><div>Hard reboot</div></div></div> <div><div><div>EN</div></div><div></div></div>																	
26																	
<div>Nose pads adjustment</div> <div><div><div></div><div>Nose pad bracket is not detachable Distance between the two nose pads can be adjusted manually</div></div></div>																	
27																	
<div>Scan the QR code to get the manual in more languages and download MYVU AR APP</div> <div><div></div><div>Please scan the QR code above using your smartphone to install</div></div>																	
28																	
<div>Product Specification</div> <table><tr><td>Model Number</td><td>XGA020C</td></tr><tr><td>Protection Rating</td><td>IP52</td></tr><tr><td>Bluetooth</td><td>BT5.2</td></tr><tr><td>Frequency Band</td><td>2400MHz - 2483.5MHz</td></tr><tr><td>Max. Signal Transmission</td><td>7dBm</td></tr><tr><td>Battery type</td><td>Rechargeable Lithium-ion battery</td></tr><tr><td>Battery capacity</td><td>204mAh</td></tr><tr><td>Charging input</td><td>5V = 1A</td></tr></table>		Model Number	XGA020C	Protection Rating	IP52	Bluetooth	BT5.2	Frequency Band	2400MHz - 2483.5MHz	Max. Signal Transmission	7dBm	Battery type	Rechargeable Lithium-ion battery	Battery capacity	204mAh	Charging input	5V = 1A
Model Number	XGA020C																
Protection Rating	IP52																
Bluetooth	BT5.2																
Frequency Band	2400MHz - 2483.5MHz																
Max. Signal Transmission	7dBm																
Battery type	Rechargeable Lithium-ion battery																
Battery capacity	204mAh																
Charging input	5V = 1A																
29																	
<div>Rechargeable Li-Ion Battery 1/CPA/12/34</div> <div><div><div>Model</div><div>Rated Capacity</div><div>Rated Energy</div><div>Nominal Voltage</div><div>Limited Charge Voltage</div><div>Email</div><div>Web</div><div>Company Name</div><div>Company Address</div></div><div><div>XR24314R</div><div>204mAh</div><div>0.79Wh</div><div>3.87Vdc</div><div>4.65Vdc</div><div>vdh@gvdl.com</div><div>http://www.gvdl.com</div><div>Chongqing YDL Electronics Co., Ltd.</div><div>Bulking 1-4, P-8 Industrial New Area, Zhaogia Street, Kaizhou District, Chongqing, 405401, China</div></div></div>																	
30																	
<div>Terms of Use</div> <div><div><div>Legal Statement</div><div>Copyright © Hubei Xingli Meizu Group. All rights reserved. This information is for reference only and does not constitute any express or implied warranty or condition of any kind with respect to the product. Please understand that the actual product's color, weight, size, screen display, and other specifications may vary.</div></div><div><div><div>Disclaimer</div><div>Thank you for purchasing our product. The information in this manual pertains to your safety, legal rights, and responsibilities. This manual may be updated and published on the official website. For the latest product information, please visit the product's page on our official website. By using this product, you and your guest users agree that you have carefully read, understand, and agree to comply with the terms and conditions of this manual. You and your guest users agree to take full responsibility for your actions and the consequences of these actions when using this product. You and your guest users agree to use this product only for appropriate purposes and in compliance with all applicable local laws, regulations, rules, as well as all terms, notices, practices, policies, and guidelines that have been or may be established for this product. Hubei Xingli Meizu Group assumes no liability for your or your guest user's access to or use of third-party content or any data or features contained therein (Third-Party Services). You and your guest users are responsible for any personal injury or property damage caused by improper use of the product or use of the product contrary to this manual. You or your guest users must adhere to all recommendations and guidelines provided by the Third-Party Services you use, in order to avoid potential risks. Your obligations and rights when using and accessing Third-Party Services are solely governed by the agreements between you and the respective Third-Party Service providers. For more information about the after-sales and warranty services of this product, visit our official website at https://care.meizu.com/.</div></div></div></div>																	
31																	
<div>Health and Safety Warnings</div> <div><div>All users are required to regularly review the health and safety warnings for this product to stay informed about any updates to the warnings. Please visit the official website for such updates: www.meizu.com/starv/summary_012. Before using this product, users must thoroughly read this user manual and become familiar with the product's features and risks. Failure to use this product in a safe and responsible manner may result in physical harm to yourself or others, or damage to the product or other property. Notifications for All Users As this user manual is not fully developed, individuals under the age of 18 should not use this product, nor should any user share this product with them. Individuals with facial injuries affecting areas where the product is worn, or individuals who are vulnerable to low-temperature scolds and burns, should refrain from using this product. This product does not provide visual correction, and individuals with vision issues such as myopia (near-sightedness), hyperopia (far-sightedness), or astigmatism may have difficulty viewing clearly. Before using this product, carefully inspect its appearance for any damage, such as cracks or missing parts in the frame, lenses, or nose pads. If the product is damaged in any way, do not use it. If you have a history of severe health conditions such as epilepsy, hypertension, heart disease, acrophobia (fear of heights), severe myopia, and mental illnesses, or if you are pregnant, it is not advisable to use this product as the immersive 3D content and thrilling experience may harm you. If you are not in any of these categories but nevertheless experience dizziness, eye fatigue, visual abnormalities (such as diplopia, distorted vision, eye discomfort, or pain) while using this product, please stop using it immediately. Some individuals may have allergies to materials such as plastic, leather, or fibers, and prolonged exposure to these allergens can cause symptoms including redness, swelling, and inflammation. If you experience similar conditions, please discontinue the use of this product and see a doctor. To prevent radio wave interference, maintain a distance of at least 15 cm between this product and implantable</div></div>																	
32																	
<div>medical devices or personal medical equipment (such as pacemakers, cochlear implants, and hearing aids). Consult the manufacturer of such devices for restrictions on using this product.</div> <div><div><div>Recommended Usage Environment</div><div>To reduce the risk of injury, discomfort, or property damage, please ensure that all users of this product have carefully read the following warnings before using it. You are responsible for ensuring that you remain in a safe environment whenever you use this product. Special attention to safety is required when using this product, as the digital information can block part of your view of your actual surroundings. Use this product where the temperature ranges from 0°C to 35°C (32°F to 95°F), and the altitude is below 2,000 meters. Store this product in dry accessories where the temperature is between -20°C and 45°C (-4°F to 113°F). Avoid storing or using this product in humid environments. This product is only resistant to sweat or small amounts of water droplets. Do not wear this product while swimming or bathing/showering, and do not immerse it in water. Avoid exposing this product to rain or direct sunlight and keep it away from fire. Do not use this product in dusty or humid environments and keep it away from magnetic fields to prevent functional issues.</div></div><div><div><div>Safety Information</div><div>Before using the product, please carefully inspect your surrounding environment and ensure it is safe, as failure to do so may result in serious injury or death. Ensure that your real-world surroundings are free of any obstacles, furniture, pits, slippery surfaces, people, or pets while using this product. Stay away from stairs, balconies, open doors, windows, and open flames. Note that outdoor use of this product may cause uncontrollable and unforeseeable dangers to your personal safety. For example, vehicle or pedestrian traffic, environmental noise, or changes in lighting conditions can adversely affect the product's functions (such as spatial tracking). Do not use this product at gas stations or in close proximity to flammables, chemicals, or any areas with risks of fire and explosion.</div></div></div></div>																	
33																	
<div>In places where the use of wireless devices is explicitly prohibited, such as medical and healthcare facilities, please refrain from using this product and turn off the device and accessories. Failure to do so may cause interference with other electronic devices or pose other risks. Do not use this product in any unfamiliar environment. Do not use this product if sudden movements or intense physical activities may be required. Exercise caution when using this product in moving vehicles such as cars, buses, subways, or trains, as variation in speed and sudden movements may increase your susceptibility to adverse reactions, especially when using the AR features of this product. Avoid using this product in noisy environments, as distractions may cause dangers or prompt you to raise the product's volume to unsafe levels. Do not use this product in environments with any unknown risks, or during driving, as it may be risky and even life-threatening. Using this product in certain situations may distract you and cause danger. Please observe applicable laws and regulations in your country or region that prohibit or restrict the use of mobile devices. This product and its accessories may contain small parts. Please keep the device and its accessories out of the reach of children. Children may inadvertently damage the product and its accessories or swallow small parts, leading to choking or other hazards.</div> <div><div><div>Health Precautions</div><div>If you are sick, fatigued, under the influence of alcohol or other medications, or feeling unwell, please refrain from using this product, as it may exacerbate your illness and increase the risks. If you have serious health issues (such as heart disease), conditions that affect your ability to engage in physical activities safely, or if you are elderly, please consult your doctor before using this product. Exercise moderation in eye usage and avoid prolonged wearing of this product to prevent visual fatigue. It is recommended to take a break of 10-15 minutes every 2 hours.</div></div></div>																	
34																	
<div><div><div>Cleaning and Maintenance</div><div>Keep the device and its accessories dry. Do not dry them up using heating devices such as a hair dryer. Before cleaning and maintenance, stop using the device and remove all connectors or cables to other devices. Clean this product by gently wiping it with the provided eyeglass cloth, a soft velvet cloth, or other lens-cleaning cloths dampened by a neutral, mild cleanser. Use a dry, non-abrasive, microfiber cloth or eyeglass cloth to absorb the moisture. Do not use other liquids or media to clean the lenses.</div></div><div><div><div>Regulatory Information</div><div>After pairing your smartphone with this product, you can access information on regulatory certification in the MYVU app. Go to Settings for Glasses > About Glasses > Regulatory Certification.</div></div></div></div>																	
35																	
<div><div><div>CAUTION</div><div>Visual Fatigue</div><div>When using this product, please adjust the display brightness to minimize the contrast between the display and the surrounding environment. Maximum brightness in dark environments and minimum brightness in bright environments can cause visual impairment. If you experience symptoms of visual fatigue or dizziness, cease the use of this product immediately.</div></div><div><div><div>Contagious Diseases</div><div>This product is in direct contact with the user's skin when used. Sharing it among multiple users may result in the spread of diseases and is therefore not recommended. To prevent the transmission of contagious conditions (such as pink eye), avoid sharing this product with individuals who have contagious diseases or other illnesses, especially those affecting the eyes or skin. Clean the product before each use.</div></div><div><div><div>Other Types of Discomfort</div><div>When you use the product, moving images and changing light conditions may cause dizziness or loss of balance.</div></div></div></div></div>																	
36																	
<div><div><div>If you experience any of the following symptoms, please stop using the product and see a doctor: spasms, loss of consciousness, seizures, involuntary movements, dizziness, directional impairment, nausea, headache, drowsiness or fatigue, eye pain or discomfort, eye fatigue, eye twitching, or vision abnormalities (such as distortion, blurriness, or double vision), excessive sweating, increased salivation, impaired hearing, impaired hand-eye coordination, or other symptoms similar to motion sickness. Please note that using this product in moving vehicles (such as cars, buses, planes, trains, or boats) may trigger or exacerbate the aforementioned symptoms. Taking regular breaks during product use can alleviate these symptoms and reduce health risks. If you notice swelling, itching, tingling, or any other types of discomfort on the skin in contact with the product, please discontinue use. If the symptoms persist, see a doctor.</div></div><div><div><div>Device Safety</div><div>This product should not be worn simultaneously with any other form of eyewear, as it may damage the product or cause danger to users. This product is not sold with a power adapter. Any power adapter you choose for power supply to the product must comply with local standards. Please avoid using substandard adapters which might cause irreparable damage to the product. The display embedded in this product is powered by high-precision technologies. Please avoid throwing, tossing, or dropping the product and prevent it from experiencing strong external impacts. If the product is dropped, crushed, or damaged due to external force, please stop using the product immediately. Do not use this product with unauthorized accessories or devices. For information on compatibility, please visit our official website. Do not attempt to disassemble, reassemble, modify, or repair the product by yourself or by engaging unauthorized entities. In the event of an obvious malfunction (even if it does not prevent other functions from working properly), stop using the product immediately to prevent electric shock, serious injury, or death. Hubei Xingli Meizu Group is not responsible for any damage or personal injury caused by improper or unsafe use of this product.</div></div></div></div>																	
37																	
<div><div><div>Prolonged Heat Exposure</div><div>While this product is in use, certain components are in direct contact with the user's skin. Please read and strictly adhere to the following instructions: Prolonged skin contact with the product that is hot to the touch may cause low-temperature burns, which are typically characterized by skin redness. The temperature safety warning for this product is based on the EN 563 standard (temperatures of touchable surfaces) and ISO 13732-1 standard (methods for the assessment of human responses to contact with surfaces). According to these standards, there is a possibility of burning the user's skin if the temperature of the surface in contact with the skin exceeds 43°C (109.4°F). If the product feels uncomfortably warm in extreme environmental conditions, please stop using it immediately. The product automatically shuts down when it overheats. Do not place the product in direct sunlight or near heat sources such as radiators or flames, as this may lead to overheating or damage to the product.</div></div><div><div><div>Storage</div><div>Be sure to place this product in its dedicated case while not in use, and avoid exposing it to liquids, moisture, direct sunlight, or rain and snow, which could cause irreparable damage to the product. Before placing the product in its case, ensure that its temple arms are folded properly, and avoid applying excessive pressure to the temple arms. If the glasses are used with lenses for nearsightedness, farsightedness, or astigmatism, be sure to remove these lenses from the glasses and store them properly. Refrain from frequent insertion and removal of the nose pads to prevent unnecessary wear. Do not expose either side of the lenses to powerful light sources, such as lasers or flashlights.</div></div></div></div>																	
38																	
<div><div><div>Third-Party Services</div><div>When using Third-Party Services through this product, you are required to comply with the terms of such services. If there is any conflict between the terms of such services and the terms in this manual, the latter shall prevail. Hubei Xingli Meizu Group assumes no responsibility or obligation for your access to or use of Third-Party Services.</div></div></div>																	
39																	
<div><div><div>including any content or functionality contained therein. Your rights to access or use such services are governed solely by the agreements between you and the respective Third-Party Service providers. Under no circumstances should Hubei Xingli Meizu Group be considered the licensor of Third-Party Services, and Hubei Xingli Meizu Group does not grant any use such Third-Party Services, assume any obligations in relation to the Third-Party Services, or make any representations or warranties regarding the Third-Party Services.</div></div><div><div><div>After-Sales Service</div><div>The after-sales service is provided by the distributor of this product or the official authorized service partner. If there is any conflict between these terms of after-sales service and the product's distributor and local regulations, the latter shall prevail. Friendly Reminder - Defects occurring in the product during normal use are eligible for free repair within 12 months from the date of purchase. However, if you purchase the product within the EU or EFTA, the warranty period shall be 24 months. - If you are unable to provide a valid proof of purchase, your warranty period will start 90 days after the product's manufacturing date as provided by the manufacturer. - Repairs beyond the warranty period and damages caused by unauthorized disassembly / repairs will incur corresponding charges. - Regular system software updates are necessary to maintain optimal performance. Some malfunctions can be resolved after system software updates, and utilizing the system update service will not affect the original warranty rights of the device. Please keep the device turned on during the update and maintain a stable internet connection.</div></div></div></div>																	
40																	
<div><div><div>EU regulatory conformance</div><div>Hubei Xingli Meizu Group Co., Ltd. hereby declares that this device XGA020C is in compliance with Directive 2014/53/EU (RED), Regulation (EU) 1907/2006 (REACH), Directive 2011/65/EU (RoHS) and where applicable, Regulation (EU) 2023/842 (Batteries). The full text of the EU declaration of conformity is available at the following internet address: www.myvu.net This equipment may be operated in all European countries.</div></div><div><div><div>Regulatory certification</div><div>After pairing your smartphone with this product, you can access information on the regulatory certification via the MYVU app. Go to Settings for Glasses > About Glasses > Regulatory Certification.</div></div></div></div>																	
41																	
<div><div><div>Disposal and recycling information</div><div>The symbol on the product, battery, battery, literature, or packaging means that the products and batteries should be taken to separate waste collection points designated by local authorities at the end of their life span. This will ensure that EEE waste is recycled and not sent to landfill, thereby protecting the environment and protecting human health and the environment. For more information, please contact your local authorities, retailer, or household waste disposal service or visit the website www.myvu.net</div></div><div><div><div>Disposal of electrical and electronic equipment</div><div>Do not dispose of this product as general waste. It is your legal obligation to collect these devices separately from unsorted municipal waste. Disposal in the residual waste bin or yellow bin is prohibited. If the products contain batteries or accumulators that are not permanently installed, they must be removed before disposal and disposed of separately as batteries.</div></div></div></div>																	
42																	
<div><div><div>Possibilities of returning old appliances</div><div>Owners of old devices can hand them in within the framework of the options set up and available by public waste disposal authorities for returning or collecting old devices to ensure that the old devices are properly disposed of.</div></div></div>																	
43																	
<div><div><div>Data protection</div><div>We would like to point out to all end users of waste electrical and electronic equipment that they are responsible for deleting personal data on the old equipment to be disposed of. Hubei Xingli Meizu Group Co., Ltd. hereby declares that this device complies with the basic requirements and the other applicable provisions of the EU Declaration of Conformity according to the Radio Equipment Directive 2014/53/EU and the RoHS Directive 2011/65/EU. The full EU declaration of conformity can be found on the website: www.myvu.net</div></div><div><div><div>FCC regulatory conformance</div><div>Hubei Xingli Meizu Group Co., Ltd. hereby declares that this device XGA020C is in compliance with the essential requirements and other relevant provisions of FCC regulation.</div></div><div><div><div>Labeling requirements</div><div>This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.</div></div><div><div><div>Changes or modification warning</div><div>Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.</div></div><div><div><div>Information to the user</div><div>Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.</div></div></div></div></div></div></div>																	
44																	
<div><div><div>However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: - Reorient or relocate the receiving antenna. - Increase the separation between the equipment and receiver. - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. - Consult the dealer or an experienced radio/TV technician for help.</div></div><div><div><div>FCC Radiation Exposure Statement:</div><div>The SAR limit of USA (FCC) is 1.6 W/kg for body averaged over one gram of tissue. Device types XGA020C (FCC ID: 2BHQZ-XGA020C) has also been tested with 0.0m against this SAR limit.</div></div></div></div>																	
45																	
<div><div><div>UK/CA regulatory conformance</div><div>Hubei Xingli Meizu Group Co., Ltd. hereby declares that this device XGA020C is in compliance with the essential requirements and other relevant provisions of UK/CA regulation.</div></div></div>																	
46																	
47																	
48																	
49																	
50																	
51																	
52																	
53																	
54																	
55																	
56																	
57																	
58																	
59																	
60																	
61																	
62																	
63																	
64																	
65																	
66																	
67																	
68																	
69																	
70																	
71																	
72																	
73																	
74																	
75																	
76																	
77																	
78																	
79																	
80																	
81																	
82																	
83																	
84																	
85																	
86																	
87																	
88																	
89																	
90																	
91																	
92																	
93																	
94																	
95																	
96																	
97																	
98																	
99																	
100																	