

# GSK Installation Guide

(Galaxy Smart Keeper)

# Product Overview and Specifications



- Product Name : GSK (Galaxy Smart Keeper)
- Purpose of use  
: Notification function to prevent theft of displayed products
- Size(mm) : 85(w) x 85(d) x 30(h)
- Color : White / Black
- Component : GSK Controller , Cradle , Antenna , Double-sided tape

항목	내용	비고
Input	5VDC / Max 1A	
TX Beacon	RF Power : + 10dBm	Default
	EddyStone Type	
	Interval : 100mS	Default
RX BLE	RF Power : + 5dBm -97dBm Sensiviti support	
	Application of Balun Circuit for Blocking Adjacent Channels	
	App for Setup Connectivity BLE Mode Support	
	Multi Connection 12ea support	
Audio Output	1ch Alert sound output	
	3W AMP IC	
RF ANTENNA	U.FL Connector applied, external antenna support	
LED display	R.G.B LED Communication Status Information Representation	
Operating Temperature Range	+ 10 ~ + 45 °C	
Storage Temperature Range	-20 ~ + 85 °C	
warranty	1 year or less	

# Table of Content

1. Pre-installation Essentials and Checklist
2. Installation Process
3. Store Account Creation
4. Manager App Installation
5. Controller Registration
6. Controller Placement
7. GSK app Installation
8. Device Registration

# 1

## **Pre-installation Essentials and Checklist**

# Pre-installation precautions and checklist

## Pre-Installation Requirements

- Internet access is required for GSK to be installed. Please connect the display device and management device to Wi-Fi.
- The GSK app will be installed automatically when you install the Samsung Retail Mode app.

## Installation checklist

### Store Environment



Display devices with  
Samsung Retail Mode  
app installed



Management  
devices  
to install the Manager  
app



Wi-Fi environment

### Creating an Account



E-mail address



Internet-enabled  
PC

### GSK Kit



GSK Controller




The Guide

# 2

## Installation Process

# Installation Process

- GSK installation process is as follows:



# 3

## Store Account Creation

Sign up

Sign up approval and Authentication

Create a Store on the Administrator Site



## Sign up

- Connect to management site 'https://cms.mss-gsk.retailsamsung.com '
- Follow these steps to create a store account
- The administrator approval is required after completing registration
- Approval is typically completed within 24 hours.

\*Chrome is recommended as the internet browser.

**1**

Click Sign up

**Galaxy Keeper**  
Galaxy Smart Keeper ( GSK )

User ID  
Password

☐ Remember ID

**LOGIN**

**Sign up**

아이디/비밀번호 찾기

KO | EN

**2**

Accept the terms and conditions and click 'Accept'

Effective date 2024-01-01 Korea/KR

**Terms & Conditions**

Last updated: [2022.07.31]

**Introduction**

Welcome to [GALAXY PRICE CMS] By using our website and/or using the services that are provided, you acknowledge that you have read, understood, and agree to be bound by our Terms and Conditions. These Terms and Conditions unconditionally extend and apply to all related applications, internet service, or website extensions. If you are not in agreement with all of these Terms and Conditions, you are prohibited from using this Website, and you may discontinue use immediately. [GALAXY PRICE CMS] recommends that you save or print a copy of these Terms and Conditions for future reference.

Collection and use of personal information

**Terms & Conditions**

Last updated: [2022.07.31]

**Introduction**

Welcome to [GALAXY PRICE CMS] By using our website and/or using the services that are provided, you acknowledge that you have read, understood, and agree to be bound by our Terms and Conditions. These Terms and Conditions unconditionally extend and apply to all related applications, internet service, or website extensions. If you are not in agreement with all of these Terms and Conditions, you are prohibited from using this Website, and you may discontinue use immediately. [GALAXY PRICE CMS] recommends that you save or print a copy of these Terms and Conditions for future reference.

Terms of service

**AGREE**

**3**

Enter your profile information

**Galaxy Keeper**  
Galaxy Smart Keeper ( GSK )

First Name  
Last Name  
E-mail  
ID  
Password  
Confirm Password

**Request**

**Check**

8~20자 이내 영문/숫자/특수문자 조합

Classification  
☒ Samsung Store ☐ CR# Store

**4**

Select your store classification, region and subsidiary.  
Click 'Done'

E-mail  
ID  
Password  
Confirm Password

8~20자 이내 영문/숫자/특수문자 조합

Classification  
☒ Samsung Store ☐ CR# Store

Region  
Africa

Subsidiary  
SSA


**Back** **Done**

# Log-In and Authentication

- After the administrator approval, you can log in through the authentication process

1


Enter ID, PW, and click 'LOGIN'



The login screen for Galaxy Keeper (GSK) features a white background with the app's name and logo at the top. Below this, there are two input fields for 'User ID' and 'Password'. A 'Remember ID' checkbox is located below the password field. A prominent black 'LOGIN' button is centered below the inputs. At the bottom, there is a 'Sign up' button and a link for 'Find ID or reset password'. Language options 'KO' and 'EN' are in the bottom right corner.

2


Complete authentication via Google OTP or email authentication



The 'Two-step verification' screen offers two authentication paths. The left path, 'Opt.1 Google Authenticator (Google OTP)', instructs the user to use a Google OTP code and features a black 'OTP Authentication' button. The right path, 'Opt.2 E-mail Authentication', instructs the user to verify their email with a verification number and features a black 'E-mail Authentication' button.

3

Enter to the main screen once you complete the authentication



The main dashboard of Galaxy Keeper displays a summary of system metrics. It includes a sidebar with navigation links (Dashboard, Keeper, API Test, Admin) and a top navigation bar with filters for Region, Subsidary, Country, and Store. The summary section shows three key metrics: 'Number of Store' (12), 'Number of Device' (50), and 'Number of Controller' (17), each with a corresponding trend indicator. A 'Device Status' section on the right shows a circular gauge with a legend for various statuses: OK, OK OFF, OK ON, and Lock.

## Creating a Store

- Select your store and edit store operating hours through the following process

1

Select the Keeper > 'Store' at the left menu, then select the relevant store

No	Region Subsidiary Country	City	Store ID	Store Idx	Admin ID	Store Name	Device	GK ON	Lock	Last	GK OFF	Alarm	Unlock	Never Activated	Can
1	Korea Korea Korea	강기도	A2095	457708	loozloaz	물리화공의 안전관리	50	-	-	1	1	-	5	43	

2

Click 'Edit' at the bottom right to set the store operating hours

Region	Korea	Subsidiary	Korea	Country	Korea
Store Type	sts	Store Sets	apk_distribution_for_kt	Grade	확장 점수 정보가 없습니다.
Channel	채널 아이디 정보가 없습니다.	Channel Type	채널 타입 정보가 없습니다.	Area	서울광역시
Admin	관리자 / loozloaz	Device	50	Controller	5
Description	확장 설명 정보가 없습니다.				

4

Click 'Confirm' at the bottom right, then click 'Confirm' again in the pop-up window

Store opening hours/view changes have been saved.  
Are you sure update opening hours/view?

Cancel Confirm

3

Set store operating hours

Store Operation ※ Please check the opening day(s) of the week.

☒ Sun 09:30 - 19:00 ☐ Apply the same opening hours to all

☒ Mon 09:30 - 19:00 ☒ Tue 09:30 - 19:00

☒ Wed 09:30 - 19:00 ☒ Thu 09:30 - 19:00

☒ Fri 09:30 - 19:00 ☒ Sat 09:30 - 19:00

# 4

## Manager App Installation

## Manager App Installation

- Download the Manager app by scanning the QR code in the guide from the GSK Kit on the Management device
- After running the Manager app, proceed with the permission settings in the following order, then log in

1

Download Manager app by scanning QR code below.



GSK Manager



2

Select 'allow' for all four requested permissions

Allow access to use the app.


- ☒ Allow full access
- ☒ Allow access to Bluetooth (required)
- ☒ Allow access to location (required)
- ☒ Allow access to notification (required)
- ☒ Allow access to camera (required)

① While using the app  
Only this time

Don't allow

Allow access to use the app.

- ☒ Allow full access
- ☒ Allow access to Bluetooth (required)



② While using the app  
Only this time

Don't allow

Allow access to use the app.


- ☒ Allow full access
- ☒ Allow access to Bluetooth (required)
- ☒ Allow access to location (required)
- ☒ Allow access to notification (required)
- ☒ Allow access to camera (required)



③ Allow  
Don't allow

Allow access to use the app.

- ☒ Allow full access
- ☒ Allow access to Bluetooth (required)
- ☒ Allow access to location (required)
- ☒ Allow access to notification (required)
- ☒ Allow access to camera (required)



④ Allow  
Don't allow

3

Log in with your store account

Store ID login

ID

Enter ID

Password

\*\*\*\*

☐ Auto login

Login

# 5


## Controller Registration

## Controller Registration

- Log in to the **Manager app** and follow the order below to register the controller
- When setting up the display device located near the entrance, please refer to the page 34


1

Select the store you set when creating the account



2

Tap '+' for controller registration



3


Scan the QR code on the back of the controller

\*The controller must be powered on.




4

Select the table placement for the controller.




5

Register the controller name with the location where the controller will be placed



6

The controller registration is complete



# 6

## Controller Placement

Placement Guide

GSK Support Mode

Area mode

Fence mode

Pin Point mode




## Placement Guide

- For smartphone and tablet tables, place the controller under the table and connect the included dipole antenna.
  - \*For optimal performance, placing controller on the table is recommended.
- Place GSK controllers on the top of the table only for the Watch table without dipole antenna.

### SMP/Tablet Table

Place under or side of the table



### Watch Table

Place on the table



## Placement Guide

- When placing the controller under the table, ensure that there are no obstacles that could affect the controller signal.
- Please refer to the correct installation example below.

### Incorrect installation example



Stick to the wall (X)



Install next to power lines or electrical devices (X)



Install by bending the antenna (X)

### Correct example




Example of correct installation (○)

## GSK Operation Mode


- GSK supports the following four modes to match your store environment:

### Distance Mode




The mode simply turns on an alarm when it is out of the range of settings from the controller

### Area Mode



The mode turns on the alarm when it is out of area from the multiple security ranges which created by multiple controllers

### Pin-Point Mode



This mode turns on an alarm when there is an approach to the range of the controller

### Fence Mode




This mode turns on an alarm when you step outside the store's entrance area by identifying the inside and outside based on the set area

## Area mode


- The placement of the controller varies depending on the environment of each store and the operation mode you use
- Area mode is the most basic mode which is suitable for the most store conditions. Multiple security ranges are combined
- Refer to the placement guide below to arrange it accordingly

● Security Range ● Controller Location


60m<sup>2</sup>



100m<sup>2</sup>



180m<sup>2</sup>




## Fence mode


- The two controllers inside the store, outlined in blue, are installed symmetrically at the ends of both tables, 5m away from the installed controller at the entrance
- The red line below is the Fence line. The warning alarm will sound when the display device cross the fence line.
- Refer to the placement guide below to arrange it accordingly

● Security Range ● Controller Location

100m<sup>2</sup>





\*Table size



● Installing 5 Controllers

180m<sup>2</sup>



● Installing 5 Controllers


\*The placement of the controller varies depending on the environment of each store and the operation mode you use



## Pin Point mode

- Pin-Point mode triggers an alarm when you approach within 3 meters of the controller installed near the entrance.
- The controller inside the store, outlined in blue, is installed on the center table 5 m away from the installed controller at the entrance
- Refer to the placement guide below to arrange it accordingly

● Security Range ● Controller Location



\*The placement of the controller varies depending on the environment of each store and the operation mode you use


\* If you wish to manually adjust the alarm range of the entrance controller, please refer to page 32.

## Fence mode or Pin-Point mode settings


- To use Fence or Pin-Point modes, the installation position of the controller must be set as follows.

**1**


To use Fence and Pin-Point modes, click the 'List' button below in the Manager app.

**2**


Select 'Change the installation location'.

**3**


Select the installation location for the controller within the store.

**4**


The installation location will be displayed on the screen.



<Example – Fence mode>



<Example – Pin-Point mode>



# 7

**Install GSK App**




## Installing the GSK App

- When installing Samsung Retail Mode app, two APPs are installed automatically. (GSK, GSK Watcher).p.34
- Please be sure to run the GSK Watcher app first.
- If the GSK app is launched first, it will automatically switch to the GSK Watcher.


1 Please be sure to run the Watcher app first.




GSK  
Watcher



2 Please allow all permissions.




3 Click "Go to GSK app"



3 Launch the GSK app and select 'Galaxy Smart Keeper'.



GSK



## Installing the GSK App

- Proceed the setup in the following order after activating the GSK app

1

Select 'Galaxy Smart Keeper'

Select the security system to be applied to the display device.

☒ Galaxy Smart Keeper

☐ Galaxy Keeper 2.0

Confirm

\* If you want to use GK2.0, select and enter the GK2.0 app

2

Select 'allow' for all three requested permissions

Allow access to use the app.

☒ Allow full access

☒ Allow access to camera (required)

☒ Allow access to Bluetooth (required)

☒ Allow access to location (required)

☒ Allow access to notification (required)

☒ Allow to display over other apps (required)

☒ Disable the battery optimization (required)

☒ Allow access to disturb permission (required)

If you do not grant required permissions, use of some services may be restricted.

Next

Allow access to use the app.

☒ Allow full access

☒ Allow access to camera (required)


☒ Allow access to Bluetooth (required)

☒ Allow access to location (required)

Allow GSK to access this device's location?



Precise



Approximate

While using the app

Only this time

Don't allow



Location permission



GSK

Location access for this app

☒ Allow all the time

☐ Allow only while using the app

☐ Ask every time

☐ Don't allow

Use precise location

When precise location is off, apps can access your approximate location



[See all GSK permissions](#)

[See all apps with this permission](#)

3

The 'Register Device' screen will appear after allowing all permissions

Register device

Register your device by pressing the Plus button at the top of the Manager app.

My device

Model : Galaxy S24 Ultra  
S/N : 123456789

Do not close the screen during the registration process.

\* Continue the process on the next page

# 8

## Device Registration

**Device Registration**

**Connecting Controller to GSK**

**Setting GSK App Function**

**Security Range Settings and Alarms: Alarm Screen**


## Device Registration

- Run the Manager app while the 'Device Registration' screen is open in the GSK app to sync them.
- Set up as below both in the Manager app and GSK app

\*Make sure the controller is registered with Manager app. (Refer to the page 14).

**1**


Leave the GSK app page on while setting up the manager app as described on the left



GSK app

**2**


Click '+' button



Manager app

**3**


Select the detected device



Manager app

**4**

If you register the device model or color by name, it will be easy to find later




Manager app

**5**

Select the desired mode


\*Proceed after completing device registration in the Manager app



GSK app

**6**

Click the 'Close' button when the registration is complete.




Manager app

## Connecting Controller to GSK

- Click 'Controller' in the bottom left to connect the controller to the GSK app


**1**

Tap '+' to connect the controller to the device

**2**

Choose how to connect to the controller


\*When connecting by 'Find QR Code', be sure to connect only the controller registered with the manager app




① **Find QR Code**  
Scan the QR code on the back of the controller



② **Find in the list**  
Select from the list of controllers registered in the Manager app


**3**

The controller is connected



## Setting GSK App Function

- You can set up the GSK app by clicking 'Setting'



You can check the operating hours of the device.

GSK operation can be turned on/off

You can choose the type of security

You can set the operation mode

You can set the distance to lock

※ The default setting is '5m'.

You can adjust the volume of the warning alarm


You can initialize the app

You can change to GK2.0 app. GSK app will be initialized.

## GSK Warning Alarm Screen\_Phone

- The warning alarm will sound with a notification as shown below if you go out of the set range.
- When the user moves more than 3m away from the controller, a notification will appear. If the user moves more than 5m away, a first warning alarm will sound for 5 seconds, followed by a second warning alarm.
- Each model has preset configurations for 3m and 5m distances, so there's no need for manual measurement each time.
- The notification is only provided when set to 5m setting in distance mode

Screen when out of security range



## GSK Warning Alarm Screen\_Watch

- The warning alarm will sound with a notification as shown below if you go out of the set range.
- When the user moves more than 3m away from the controller, a notification will appear. If the user moves more than 5m away, a first warning alarm will sound for 5 seconds, followed by a second warning alarm.
- Each model has preset configurations for 3m and 5m distances, so there's no need for manual measurement each time.
- The primary notification is provided when set to 5m setting in distance mode

Screen when out of security range

### Watch



**Notification**  
Toast Alarm Only



**First warning alarm**  
Full Screen Alarm +  
Lock mode



**Second warning alarm**  
Full Screen Alarm +  
Lock mode +  
Controller warning  
Alarm



## Security range settings and alarms: How to unlock & enter the GSK app

- When the warning alarm is triggered, the device will be unlocked automatically when it returns near the table.
- If you want to unlock the device when the controller is not connected or is outside the security range, please follow the process below.

1


Tap the Enter PIN button to unlock the lock



GSK app

2


Please check the 4-digit key code displayed on the screen.



GSK app

3


Enter the GSK Manager app and tap the key icon at the bottom centre



Manager app

4


Enter 4-digits that checked in the GSK app



Manager app

5


Check the GSK app Pin number on the screen



Manager app

6

Enter the Pin number in the GSK app and unlock



GSK app

## FCC Information to User

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

### Caution

Modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC Compliance Information : This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

### IMPORTANT NOTE:

FCC RF Radiation Exposure Statement: This equipment complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20 centimeters between the radiator and your body. This transmitter must not be collocated or operating in conjunction with any other antenna or transmitter.