

展开尺寸:120*160mm

备注: C:0 M:0 Y:0 K:100

C:9 M:92 Y:30 K:0

材质:128g铜板纸

beici

User manual for Beici Foot Spa Bath Massager

Please read this manual carefully and keep it properly before using the product.

Instructions for Use

1. Add water:

2. Power on:

3. Preparation before use:

4. Start-up:

5. Temperature setting:

6. Bubble Spring mode:

7. Red light mode:

8. Massage mode:

9. Shutdown and Drainage:

Eexplain:

Maintenance and upkeep

1. The product emits 10 beeps, indicating that the water temperature is too hot and triggering an over temperature alarm. Please immediately shut down or add cold water to cool down.

2. The product emits 5 beeps, indicating a temperature sensor malfunction. Please contact the platform customer service immediately for assistance.

3. If the power cord is damaged, in order to avoid danger, it must be replaced by professionals from the manufacturer, their maintenance department, or similar departments.

4. When not in use, please pour as much water as possible and store in a cool, dry, and ventilated place.

Specification parameters

Product Name	Beici Foot Spa Bath Massager	Product Model	BC-BZ312A1 BC-BZ312C1
Rated voltage / Frequency	120V~/60Hz	Rated Power	500W(BC-BZ312A1) 800W(BC-BZ312C1)
Security Category		Expand Product Dimensions	401*351*222mm(BC-BZ312A1) 421*371*315mm(BC-BZ312C1)
Execution Standards	GB 4706.1-2005 GB 4706.10-2008	Folding Product Size	401*351*102mm(BC-BZ312A1) 421*371*157mm(BC-BZ312C1)

Certificate of conformity

Inspector:

Company: Beici Electric Appliance Co., Ltd

The manufacturing, assembly, and performance of this product have been inspected and found to meet the factory quality standards, and it is allowed to leave the factory.

Service hotline: (+86)400803022

Address: No.88, Chizhushan Road, Jijiang District, Wuhu City, Anhui Province, China

正面

Safety precautions

1. Before leaving the factory, the product must undergo a water test. If there are residual water stains in the basin, it is a normal phenomenon.

2. It is strictly prohibited to heat without water. If the heating function is accidentally turned on when there is no water, please turn it off immediately.

3. It is strictly prohibited to use it on an empty stomach, after meals, under the influence of alcohol, or after vigorous exercise.

4. For patients with heart disease, diabetes, malignant tumor, pregnant women and those with physiological period and physical deficiency, please consult a professional doctor before deciding whether to use this product.

5. Children must use it under the supervision of their parents.

6. It is recommended to use the foot soaking medicine bags sold by our company or those with filter packaging for foot soaking to avoid causing unnecessary internal blockage of the product.

7. It is strictly prohibited to step on the edge of the foot bath during use to prevent deformation of the silicone basin wall.

8. To prevent hair and other dirt and debris from entering the interior of the product and causing blockage, please focus on cleaning the water circulation inlet/outlet after each use.

9. It is strictly prohibited to insert fingers or toes into the gaps between the massage components during use to avoid injury.

10. The device has a heating surface. Attention must be paid when using it for people who are not sensitive to heat.

11. If liquid leaks from the appliance, the appliance cannot be continued to be used.

12. Please unplug the power plug of this product before cleaning and moving it.

13. The rated power of this product is measured in water temperature environments of 100°F (inclusive) and below.

Warranty service

1. This product comes with a one-year warranty, calculated from the date of purchase.

2. During the warranty period, if there are quality issues with the product during normal use, you will receive free warranty service.

3. This free service does not include consumable parts that require frequent replacement.

4. When providing warranty, please present the warranty card and proof of purchase time. Please keep the warranty card properly.

5. Free warranty service will not be available in the following situations:

a) If it exceeds 1 year from the date of purchase.

b) No warranty card.

c) Malfunctions or human damage caused by failure to operate according to the instructions.

d) Malfunctions or human damage caused by self-disassembly, repair, or modification.

e) The aging and wear of the product caused by normal use, but do not affect the normal use of the product.

The following situations are not covered by the warranty

1. Unable to provide after-sales service card or valid purchase voucher.

2. The purchase voucher model does not match or has been altered with the repair product model.

3. Product damage caused by improper use, storage, and maintenance by consumers.

4. Problems such as product aging, deformation, fading, and damage caused by failure to follow the instructions.

5. Not the company's designated maintenance department self-assembly and disassembly repair caused damage to the product.

6. Product damage caused by force majeure.

7. Use this product for non-household purposes (such as commercial purposes, etc.).

8. Product quality accidents caused by using gifts that are not standard in our company.

After sales service card

1. Thank you for your trust in the Beici brand. If you have any unsatisfactory experiences during the shopping process, please contact the customer service of the purchasing store, and professional personnel will be available to serve you.

2. If the product needs to be returned, exchanged or repaired, please fill out this card in its entirety and send it back with the package for convenient and quick processing.

3. Please fill in the return and exchange tracking number or inform customer service of the repair return tracking number, as soon as possible after sending out the product, and keep the tracking number until processing is completed.

Kind reminder: When returning the product, please pack it neatly and ensure that the returned product and accessories are complete. If there are any gifts, they must be returned together.

The return courier refuses to accept cash on delivery, self-pickup courier or logistics.

Purchase platform:

Order date:

Order number:

Store Name:

Purchase ID:

Mobile number:

Processing method:

☐ Returns

☐ Exchange

☐ service

☐ other

Reason for return:

Reason for exchange:

Fault phenomenon:

Detailed description:

售后服务

售后服务

反面

蓓慈电器有限公司				更改记录				
文件编号	10107535			序号	原版本号	更改人	更改日期	变更内容
名 称	BZ312A/BZ312C说明书-海外款	制 图 人	赵智康					
版 本	A/0	制图日期	20241216					
适用型号	BC-BZ312A1、BC- BZ312C1海外款							

FCC Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.