多功能智能眼镜 使用说明书

开、关机

1. 开机:按开机键3秒开机,蓝灯闪3下(提示 音: 开机)即开机

2. 关机:按开机键3秒关机,红灯亮2秒灭(提 示音:关机)即关机

3. 自动关机: 开机后不连接手机或与手机断开 连接后,如无任何操作,5分钟后将自动关机

配对连接

1. 开机进入配对模式,红灯蓝灯交替闪烁,与 蓝牙设备连接

2. 手机配对: 开机未连接手机3击开机键(提 示音: 蓝牙已连接)

按键操作说明

1. 开机后:双击开机键中英文切换(未连接蓝 牙状态下使用

2. 通话模式: (已连接蓝牙状态下使用)

(1) 按1次开机键接听电话/挂断电话

(2) 双击开机键"嘟"唤醒语音助手,单击开 机键关闭

(3) 长按开机键1.5秒拒绝接听电话

(4) 长按开机键1.5秒回拨电话

(2)3击开机键播放下一曲

(3)4击开机键播放上一曲

(1)右边向前滑动:音量+

(2)右边向后滑动:音量

LED指示灯红灯自动熄灭。

4. 音量调节:

5. 拍照功能

低电报警

(1)单击开机键暂停音乐/播放音乐

开启相机状态下前后滑动即可拍照

充电中, LED 指示灯红灯长亮。充电完成

语音提示【3分钟语音播报2次,只报2次就关

机】,红灯长亮1秒,LED指示灯灭。

3. 音乐模式: (已连接蓝牙状态下使用)

首先对您使用本公司的产品表示感谢!在使用之 前请先详细阅读此说明书,正确使用此产品。 为了更好的服务本用户手册的内容可能变更。 因为产品的性能和功能而发生的变更将不做另 行通知。

•产品简介

本产品是具有立体声音响功能的蓝牙眼镜,操 作简便,美观实用,便于携带。采用蓝牙芯 片,兼容主流品牌手机和平板电脑等蓝牙设 备,达到CD级高品质音质,持久续航,左右双 喇叭.开放式定向发音,无障碍接收外界声音,不 影响获取周围环境信息,安全、智能、健康、 便捷。 •包装清单

智能眼镜、智能眼镜充电线、使用说明书、眼

•产品使用提示

1. 使用本产品前请仔细阅读说明书,并保留本 说明书。

2. 首次使用,请先将本产品充满电。

3. 如果产品长期(超过两周)不充电,使用前请对 其充电。

1. 请勿以任何理由拆除或维修改装本产品,否 则可能会导致起火, 电子击穿甚至彻底损坏本 产品。

2. 请勿将设备置于温度过低或过高(0°C以下或 45°C以上)环境下。

- 3. 请勿将产品接触腐蚀性液体。
- 4. 不能将眼镜放在阳光下长时间曝晒,否则容 易变形、老化、折断。
- 5. 请勿将充电线磁吸端靠近金属物体,以防磁 吸金属物体后引起的短路危险。

•重要安全信息

- 1. 在使用本产品前,请先阅读所有安全信息以 确保正确和安全使用. 2. 使用未经原制造商认可的电源, 充电器或电
- 池,可能引发火灾,爆炸或其他危险
- 3. 请使用本制造商认可且与此型号设备配套的 4. 请在温度0°C~35°C范围内使用本产品, 当环
- 境温度过高或过低时,可能会引发设备故障。
- 5. 本设备使用不可拆卸的内置电池,请勿自 行更换电池,以免损坏电池或设备,电池只能 由授权服务中心更换.

6. 如充电完毕,请断开充电器与本设备的连 接,并从电源插座上拔掉充电器。连续充电时 间请勿超过12小时。

- 7. 请保持设备干燥。
- 8. 若设备或其他任何部件不能正常工作,请勿 自行维修产品。 9. 连接其他设备时,请参考使用说明书的连接
- 方法,不要随意连接不配套的设备。

▲ 为避免听力受损,请勿长时间使用高音量。 ▲ 请遵循相关法律法规,不要在以下环境使用。

·如加油站,油库,化学仓库附近等存储有易 燃易爆物或化学品的环境,严禁使用设备。 ·请勿在医院手术室、急诊室、深切治疗部等

场所使用此设备;为避免干扰医疗仪器工作, 使用此设备时请远离心脏起搏器、助听器、植 入耳蜗等医用设备,请保持此设备和起搏器之 间超过15厘米的距离。

若要在个人医疗设备附近使用此设备请咨询医 师和设备制造商。

·请遵守有关驾车时使用此设备的所有安全警 告和规定。

产品保修凭证 雷雨天气时,为避免雷击事故,请勿在室外

产品保修期内出现非人为损坏的性能故障可以 享受下列三包服务

- 自收货之日起7日内,产品出现非人为损坏的 性能故障,用户可选择退回货款或者更换同型 号同规格的产品。 自收货之日起15日内,产品出现非人为损坏
- 的性能故障,用户可选择更换同型号同规格的
- 自收货之日起一年内,产品出现非人为损坏 的性能故障,用户可寄商家维修。

以下情况不在"三包"服务范围之内:

- 未经授权的维修、误用、碰撞、疏忽、滥用、进 液、事故、改动或撕毁、涂改产品标贴、封象。
- 超过"三包"服务有效期的。
- 因火灾、水灾、雷击等不可抗力造成的损坏。
- 因人为原因导致的产品性能故障。
- 未按说明书要求使用而造成损坏的。

发票号码

备注

尊敬的用户,本保修卡是您将来申请保修的凭

证,请您配合销售商填写并妥善保管备用。

用户姓名

联系电话

通讯地址

电子邮箱

邮政编码

产品名称

产品型号

产品条码

联系电话

邮政编码

销售日期

名 称

地

用户

信息

产品

信息

销售商

Multifunctional Smart Glasses Instruction Manual

Turn on and off 1. Power on: Press the power on button for 3

Pairing connection

seconds to power on. When the blue light flashes 3 times (prompt tone: Power on), it is powered on 2. Power off: Press the power button for 3 seconds to turn off the device. The red light will be on for 2 seconds and then off (prompt tone: Power off), indicating that the device is turned off 3. Automatic Shutdown: After turning on the device and not connecting it to the phone or disconnecting it from the phone, if there is no operation, the device will automatically shut down after 5 minutes

- 1. When the device is turned on, it enters the pairing mode, with the red and blue lights flashing alternately, and connects to the Bluetooth device 2. Mobile phone pairing: When the phone is turned on but not connected, press the power button 3 times
- Key operation instructions 1. After startup: Double-click the power-on button to switch between Chinese and English (used when not connected to Bluetooth)

(prompt tone: Bluetooth is connected)

- 2. Call mode: (Used when Bluetooth is connected) (1) Press the power button once to answer or hang
- (2) Double-click the power button "Beep" to wake up the voice assistant, and click the power button to turn
- (3) Press and hold the power button for 1.5 seconds

to reject the call

- (4) Press and hold the power button for 1.5 seconds to call back 3. Music Mode: (Used when connected via
- Bluetooth) (1) Click the power button to pause or play the music
- (2) Press the power button three times to play the next song (3) Press the power button four times to play the previous sona
- 4. Volume adjustment:
- (1) Swipe forward on the right: Volume + (2) Slide the right side backward: Volume -
- 5. Camera function: When the camera is on, you can take a photo by

swiping back and forthto answer the phone Charging During charging, the red LED indicator light remains on all the time. When charging is completed, the red LED indicator light will automatically go off. Low electricity alarm

Voice prompt [Voice broadcast twice within 3 minutes, only twice before shutdown], the red light remains on for 1 second, and the LED indicator light

· Statement

First of all, we would like to express our gratitude for your use of our company's products! Please read this manual carefully before use and use this product correctly. The content of this user manual may be changed in order to provide better service. Changes due to the performance and functions of the product will not be notified separately.

· Product Introduction

This product is a Bluetooth glasses with stereo sound function. It is easy to operate, beautiful and practical, and convenient to carry. It adopts a Bluetooth chip and is compatible with mainstream brand mobile phones, tablets and other Bluetooth devices, achieving CD-level high-quality sound quality, long battery life, and dual speakers on the left and right. Open directional pronunciation, unobstructed reception of external sounds, no impact on obtaining information about the surrounding environment, safe, intelligent, healthy and convenient. · Packaging list

Smart glasses, smart glasses charging cables, user manuals, glasses cleaning cloths. · Product Usage Tips 1. Please read the instruction manual carefully before

- using this product and keep it. 2. For the first use, please fully charge this product. 3. If the product is not charged for a long time (more
- than two weeks), please charge it before use.
- 1. Do not dismantle or modify this product for any reason, otherwise it may cause fire, electronic breakdown or even complete damage to the product.

- 2. Do not place the device in an environment with temperatures that are too low or too high (below 0°C or above 45°C). 3. Do not let the product come into contact with
- corrosive liquids 4. Do not expose glasses to the sun for a long time, otherwise they are prone to deformation, aging and
- 5. Do not place the magnetic end of the charging cable close to metal objects to prevent the risk of short circuit caused by magnetic attraction of metal

· Important security information 1. Before using this product, please read all the safety

breaking.

- information first to ensure correct and safe use. 2. Using power supplies, chargers or batteries that
- have not been approved by the original manufacturer may cause fire, explosion or other dangers 3. Please use the accessories approved by this manufacturer and compatible with this model of equipment.
- 4. Please use this product within the temperature range of 0°C to 35° C. When the ambient temperature is too high or too low, it may cause equipment failure. 5. This device uses a non-removable built-in battery.
- damaging the battery or the device. The battery can only be replaced by an authorized service center. 6. If the charging is complete, please disconnect the charger from this deviceConnect and unplug the charger from the power socket. When charging continuouslyPlease do not exceed 12 hours. 7. Please keep the equipment dry. 8. If the equipment or any other components do not

Please do not replace the battery by yourself to avoid

work properly, please do notSelf-repair products. 9. When connecting other devices, please refer to the connection instructions in the user manualMethod: Do not connect incompatible devices at will.

To avoid hearing damage, do not use high volume for a long time. ↑ Please abide by relevant laws and regulations and do not use in the following environments.

· It can be stored near gas stations, oil depots, chemical warehouses, etcThe use of equipment is strictly prohibited in an environment with flammable, explosive substances or chemicals.

· Please do not be in the operating room, emergency

- room, intensive care unit, etc. of the hospitalThe place uses this equipment; To avoid interfering with the operation of medical instruments, When using this device, please keep away from pacemakers, hearing AIDS and implantsWhen inserting medical devices such as cochlear implants, please keep these devices and pacemakersA distance of more than 15 centimeters between them.If you need to use this device near your personal medical equipment, please consult a doctorTeachers and equipment manufacturers · Please abide by all safety warnings regarding
- the use of this device while drivingNotice and · During thunderstorm weather, to avoid lightning
- strike accidents, do not use outdoors · Do not charge the product in high-humidity places

such as bathrooms, otherwise it may cause electric

shock, personal injury, fire and damage to the charger. · Please abide by the relevant legal regulations that explicitly prohibit its use in any environment.

请勿在浴室等高湿度的地方对产品进行充

电,否则会导致触电,人身伤害,起火和充电器

· 请遵守在任何环境里明确禁止使用的相关法

镜架材质: PC1414/TR90/五金

镜片规格:透明渐变、墨镜等

待机时间:180H(蓝牙连接状态)

充电电压和电流: DC5V/1A最大充电电流达

长期不使用时,每2个月对电池至少充电一次

律规定。

•产品参数

镜片材质: PC/TAC

蓝牙协议: 5.4

充电时间:1.5H

使用时间:5H

160mAh

温馨提示:

电池容量: 100mAh

充电时间:1-2小时。

声道:双喇叭、立体声

Frame material: PC1414/TR90/ hardware Lens material: PC/TAC

Lens specifications: Transparent gradient, sunglasses, etc Bluetooth Protocol: 5.4

· Product parameters

Charging time: 1.5 hours Usage time: 5 hours Standby time: 180 hours (Bluetooth connection

Battery capacity: 100mAh

Channel: Dual speakers, stereo

Charging voltage and current: DC5V/1A, with a maximum charging current of 160mAh

Warm reminder Charging time: 1-2 hours.

When not in use for a long time, charge the battery at least once every two months

Product warranty certificate The following three guarantees service can be

product warranty period due to non-human damage: · Within 7 days from the date of receipt, if the product has performance faults that are not caused by human factors, the user can choose to refund the payment or replace it with a product of the same model and specification.

enjoyed for performance faults that occur during the

· Within 15 days from the date of receipt, if the product has a performance failure that is not caused by human factors, the user may choose to replace it with a product of the same model and specification.

· Within one year from the date of receipt, if the product has performance faults that are not caused by human factors, the user can send it to the merchant for repair

The following situations are not covered by the "three quarantees" service: · Unauthorized repair, misuse, collision,

- negligence, abuse, liquid ingress, accident, alteration or tearing, defacement of product labels and seals. · Beyond the validity period of the "three guarantees" service
- · Damage caused by force majeure such as fire, flood and lightning strike. · Product performance failures caused by human

with the instructions.

· Damage caused by failure to use in accordance

Warranty card

Dear user, this warranty card serves as your proof for future warranty applications. Please cooperate with the seller to fill it out and keep it properly for future use

User name Tel No Address Email Post code Product name Model No.

Barcode

Invoice no.

Remark

Reseller name Reseller address Reseller tel. Postcode Purchasing date

FCC Warning

15.19 Labeling requirements.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

15.21 Information to user.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

15.105 Information to the user. Note: This equipment has been tested and found to comply with the

limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to

provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions. may cause harmful interference to radio communications. However. there is no quarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on. the user is encouraged to try to correct the interference by one or more of the following measures: -Reorient or relocate the receiving

- Reorient or relocate the receiving antenna.
- -Increase the separation between the equipment and receiver.
- -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -Consult the dealer or an experienced radio/TV technician for help.

FCC RF Radiation Exposure Statement:

- 1. This Transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.
- 2. This equipment complies with RF radiation exposure limits set forth for an uncontrolled environment.

This equipment should be installed and operated with minimum distance 5mm between the radiator and your body.