

目渡智能眼镜中英文说明书 (按键款)

MUEDO Smart Beauty Glasses Bilingual Instruction Manual (Button Model)

尺寸: 40mm×175mm

PS: 重点字体已标注红色,印刷出来也需是红色。



目渡智能 智能美颜眼镜 使用说明书

快速体验

1.开机,长按左镜腿和右镜腿的**电源键3秒**开机,左右镜腿分别开机;
2.连接蓝牙,采用手机连接,名称为**“目渡智能眼镜 Y10”或“J6”**;
3.播放音乐,视频或语音通话;
4.关机,长按左镜腿或右镜腿**电源键3秒**,左右镜腿同时关机;
5.更多功能详见使用说明。
备注:语言设置,在开机且不连接设备时使用,按左镜腿或右镜腿**电源键4次**,可切换为英文模式。

• 声明
首先,感谢您使用本公司的产品!
在使用之前请先详细阅读此说明书,正确使用此产品,为了更好的服务,本用户手册的内容可能变更,因为产品的性能和功能而发生的变更将不做另行通知。

• 产品简介
智能美颜眼镜采用蓝牙芯片,兼容主流品牌的手机、电脑、平板电脑和学习机等蓝牙设备。创新的产品设计,功能包括保护眼睛、保护耳朵、语音通话、欣赏音乐、语音打字、智能拍照、智能导航和语音控制等功能。在享受高品质声音的同时,又可时刻获取周围环境信息,使活动更安全、健康、智能和便捷。

• 包装清单
智能眼镜1副、眼镜充电线1根、眼镜清洁布1片、使用说明书1份

• 提示

- 1.使用本产品前,请仔细阅读说明书,并保留本说明书。
- 2.首次使用,请先将本产品充满电。
- 3.如果产品长期(超过两周)不充电,使用前请对其充电。

△警告

- 1.请勿以任何理由拆除或维修改装本产品,否则可能会导致起火,电子击穿甚至彻底损坏本产品。
- 2.请勿将设备置于温度过低或过高(-20°C以下或45°C以上)环境下。
- 3.请勿将产品接触液体甚至浸泡在液体里。
- 4.不能将眼镜放在阳光下长时间曝晒,否则容易变形、老化、折断。
- 5.请勿将充电线磁吸端靠近金属物体,防止磁吸金属物体后引起短路危险。

请遵循相关法律法规,不要在以下环境使用设备。

• 重要安全信息

- 1.在使用本产品前,请先阅读所有安全信息以确保正确和安全的使用。
- 2.使用未经授权制造商认可的电源,充电器或电池,可能引发火灾,爆炸或其他危险。
- 3.请使用本制造商认可且与此型号设备配套的配件。

• 产品参数

镜架材质:SUS/TR90
镜片材质:PC
镜片规格:多种可选(参考附录三)
蓝牙协议:5.0以上
蓝牙半径:10米
充电时间:1.5小时
使用时间:4小时
待机时间:120小时(蓝牙连接状态)
电池容量:90毫安时*2
声道模式:双喇叭、立体声
电源适配:DC5V/1A
最大充电电流:80毫安
温馨提示:
1.长时间不使用时,每2个月对电池至少充电1次;
2.不建议使用快充,避免影响电池寿命。

• 企业介绍

企业网址:www.muedoi.com

• 产品介绍

自渡抖音号: 
自渡微信公众号: 

• 产品购买

自渡抖音小店: 
自渡淘宝店铺: 

附录一 蓝牙连接示意图

① 进入设置
② 选择蓝牙选项
③ 蓝牙连接成功
④ 蓝牙连接示意图

• 3.1 关机
长按智能眼镜的左镜腿或右镜腿**电源键3秒**,语音提示【正在关机】;与蓝牙设备断开连接。

• 3.2 低电关机
1.低电报警,语音提示【电池电量低请充电】;LED指示灯持续闪烁3秒间隔5秒。
2.2 低电关机,语音提示【正在关机】;LED指示灯闪烁3次。

• 3.3 功能操作

• 3.4 欣赏音乐

产品保修凭证

产品保修期内出现非人为损坏的性能故障,可以享受下列三包服务:

- 自收货之日起7日内,产品出现非人为损坏的性能故障,用户可七天内退回产品进行退款
- 自收货之日起15日内,产品出现非人为损坏的性能故障,可更换同型号的产品
- 自收货之日起一年内,产品出现非人为损坏的性能故障,用户可寄商家维修。

属于下列情况不在“三包”服务范围之内:

- 未经授权的维修、误用、碰撞、疏忽、滥用、进液、事故、改动或撕毁、涂改产品标贴、封条。
- 超过“三包”服务有效期的。
- 因火灾、水灾、雷击等不可抗力造成的损坏。
- 因人为原因导致的产品性能故障。
- 未按产品说明书要求使用而造成损坏的。

合格证
产品名称:目渡智能眼镜
检验结果:合格

保修卡
尊敬的用户,本保修卡是您将来申请保修的凭证,请您配合销售商填写并妥善保管备用。

用户信息: 用户姓名 _____
联系电话 _____
通讯地址 _____
电子邮箱 _____
邮政编码 _____

产品信息: 产品名称 _____
产品型号 _____
产品条码 _____

销售商信息: 名称 _____
地址 _____
联系电话 _____
邮政编码 _____
销售日期 _____
发票号码 _____
备注 _____

附录二 眼镜充电线使用方法
将磁吸充电线接头,与智能眼镜镜腿的磁吸接头对齐吸附后,即可进行充电。

附录三 规格型号参考
型号示例:Y10-A-01M

Y10	-	A	-	01	M
智能眼镜					
镜框	镜腿	镜腿			
A 镜框	G1 黑色	10 上下下钩	M 伸缩智能腿		
B 小方框	G2 三黑	11 三黑	N 伸缩智能腿		
C 方框	G3 双双	12 红茶	L 折叠普通腿		
D 小圆框	G4 黑茶	13 绿茶			
E 圆框	G5 黑茶	14 上下下钩			
F 三角框	G6 黑茶	15 红茶			
G 圆环	G7 上下下钩	16 上黄下黑			
H 圆环	G8 上下下钩	17 黑泡茶			
I 圆环	G9 上下下钩				



MUEDO Intelligent Beauty Glasses User Manual

Quick Experience Guide:

1. Power On: Press and hold the power buttons on both the left and right temple arms for **3 seconds** to turn on each arm separately;
2. Connect via Bluetooth: Pair your phone with the device named "**“目渡智能眼镜 Y10”或“J6”**";
3. Play music, videos, or make voice calls;
4. Power Off: Press and hold the power button on either the left or right temple arm for **3 seconds** to turn off both simultaneously;
5. For more features, please refer to the user manual.

Note: For language settings, press the power button on either the left or right temple arm 4 times when the device is powered on but not connected to any device to switch to English mode.

• Disclaimer
First and foremost, thank you for using our company's products!

Please read this manual before using and use this product correctly. For the better service, changes due to the performance and functionality of the product will be revised without notice.

• Product Introduction
The Smart Beauty Glasses are equipped with Bluetooth chips, compatible with mainstream brand smartphones, computers, tablets, and learning devices with Bluetooth capabilities.

With innovative product design, the functions include protecting eyes, protecting ears, phone call, enjoy music, speech typing, intelligent photography, intelligent navigation, speech control. While enjoying high-quality sound, you can also constantly access information about the surrounding environment, making activities safer, healthier, smarter, and more convenient.

• Packing List

- 1 pair of smart glasses
- 1 charging cable for the glasses
- 1 cleaning cloth for the glasses
- 1 User Manual

• Tips

1. Please read the instructions carefully before using this product and keep this manual.
2. For the first time, please fully charge this glasses.
3. If the glasses does not charge for a long period of time (more than two weeks), charge it before use.
4. Warning
Please comply with relevant laws and regulations and do not use the device in the following environments:
 - 1. Do not use in water or repair this product for any reason, as this may result in fire, electronic breakdown or even complete damage to the product.
 - 2. Do not use the device in an environment where the temperature is too low or too high (below -20°C or above 45°C).
 - 3. Do not get the product wet with liquid or immerse it in liquid.
 - 4. Do not expose the glasses to the sun for a long time, otherwise it will be easily deformed, broken and broken.
 - 5. Do not place the magnetic end of the device near metal objects to prevent the risk of short circuit caused by magnetically attracting metal objects.
 - 6. Such as stations, oil depots, environments where flammable and explosive gases or chemicals are stored, such as near gas stations, oil depots, and chemicalwarehouses. The use of the device is strictly prohibited in these areas.
 - 7. Do not use the device in operating rooms, emergency rooms, intensive care units, etc. in order to avoid interfering with the work of medical equipment, please keep away from pacemakers, hearing aids, cochlear implants and other medical equipment when using this device.
5. If the device uses a non-removable internal battery, do not replace the battery yourself to avoid damaging the battery or device. The battery can only be replaced by an authorized service center.
6. If charging is incomplete, disconnect the charger from the device, unplug the charger from the power outlet. Do not charge for more than 12 hours.
7. Please keep the device dry.
8. If the equipment or any other parts do not work properly, please do not repair the product by yourself.
9. When connecting to other devices, please refer to the connection method in the user manual, and do not connect any unsuitable devices at will.
10. During thunderstorms, do not use it outdoors in order to avoid lightning accidents.
11. When charging, do not make a call while charging.
12. Do not use the charger in a place with high humidity such as a bathroom, otherwise it may cause electric shock, personal injury, fire and damage to the charger.
13. Please comply with the relevant legal provisions that are expressly prohibited in any environment.
14. Important Safety Information
1. Before using this product, please read all safety information to ensure correct and safe use.
2. Using a power supply, charger or battery not approved by the original manufacturer may cause fire, explosion or other hazards.
3. Please use the accessories approved by the manufacturer and matched with this model of equipment.
4. Please use the device within the temperature range of 0°C~35°C, and store the device and its accessories within the temperature range of -20°C~45°C. When the ambient temperature is too high or too low, it may cause equipment failure.

• Product Parameters

Frame Material: SUS/TR90
Lens Material: PC
Lens Specifications: Multiple options available (refer to Appendix 3)
Bluetooth Range: 10 meters
Bluetooth Protocol: Above 5.0
Charging Time: 1.5 hours
Usage Time: 4 hours
Battery Capacity: 90mAh*2
Standby Time: 120 hours (when Bluetooth is connected)
Channel Mode: Dual Speakers, Stereo
Charging Voltage: DC5V/1A
Maximum Charging Current: 80mA
• Warm Reminder

1. When not in use for an extended period, charge the battery at least once every 2 months;
2. It is not recommended to use fast charging to avoid affecting the battery life.

• Company Introduction

Company website: www.muedoi.com

• Product Introduction

MUEDO Tiktok 
MUEDO WeChat Official Account 

• Product Purchase

MUEDO Tiktok Store 
MUEDO Taobao Store 

• Appendix I Schematic diagram of Bluetooth connection

① Go to settings
② Select the Bluetooth option
③ Make sure the Bluetooth switch is on, search for the device name: “**“目渡智能眼镜 Y10”或“J6”**”, click the Bluetooth name to enter the connection.

• Appendix II Instructions for Using the Eyewear Charging Cable
With the magnetic charging cable connector with the magnetic connector on the temple arms of the smart glasses, and attach them together to start charging.

• Appendix III Specification and model reference
Model Example:Y10-A-01M

Y10	-	A	-	01	M
Intelligent glasses					
Frame	lens	Temple			
A circle tool	G1 Upper gray	10 Upper gray	M Folding regular legs		
B Small Box	G2 Blue	11 Three legs	N Spring regular legs		
C box	G3 Double	12 black tea	L Folding regular legs		
D Small circle frame	G4 Gravel	13 green tea			
E black box	G5 Gravel	14 Top purple			
F rack	G6 Gravel	15 Gradient blue			
G	G7 Gravel	16 Gradient green			
H	G8 Gravel	17 Grey purple			
I	G9 Gravel	18 Black purple			
J	G10 Gravel	19 Black purple			

FCC Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

RF Exposure Information

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.