

Error Message

[Preface](#)

[Elaboration on Error Message](#)

Preface

It might pop-up some messages as you launch the scanner driver. We will explain the errors on the following list.

Elaboration on Error Message

The error message list

Error Message	Solution
Insufficient memory to operate.	<ul style="list-style-type: none">○ Adjust the width of the scan area or the resolution.○ Close all the other applications.
Can't load dynamic library. Failed to load the scanner driver.	<ul style="list-style-type: none">○ Close all the other applications which are probably using the driver.○ Reinstall the driver from drive disk or Scanner CD.
Mail system has not been set up in your computer. Failed to load your E-mail function from the mail library. Failed to log on MAPI. Failed to send the documents via MAPI. Failed to log off MAPI. Failed to log on E-mail system. Failed to send documents via E-mail system. Can't log off.	<ul style="list-style-type: none">○ Check whether the Microsoft Mail is setup in your computer correctly.
Errors occurred in calibrating.	<ul style="list-style-type: none">○ Check whether the scanner is well connected to the computer.○ Make sure that the scanner is

	powered on , and the LED is on.
No default printer.	<ul style="list-style-type: none"> ○ Install a printer driver and connect the printer to the computer.
Can't print. Failed to activate the printer. Failed to prepare the printing job.	<ul style="list-style-type: none"> ○ Make sure that the printer and its driver are set up properly.
Failed to activate the fax.	<ul style="list-style-type: none"> ○ Make sure that the fax modem and its driver are set up properly.
Failed to send the scanned image to the Clipboard!	<ul style="list-style-type: none"> ○ Not enough system memory. ○ Close the other applications.
The image is too large to export to the Clipboard! Image size exceeds 15.9375MB.	<ul style="list-style-type: none"> ○ Reduce the image size by adjusting the width or resolution of the scan area.
Cannot save the file. Insufficient disk space.	<ul style="list-style-type: none"> ○ Reduce the width of the scan area or the resolution. ○ Increase disk space.
