

"SafeTalk" HANDS FREE™

INSTRUCTIONS FOR USE

PRECAUTIONS:

- Initial set up procedures should be performed while your vehicle is stationary.
- The cell phone and automobile radio must be turned on to function properly.
- The "LED" light indicator should be illuminated indicating proper connection with the cigarette lighter.

IMPORTANT TIPS:

- Use the car radio volume dial to achieve your desired hands free volume level.
- For enhanced audio quality, you may wish to adjust the base and treble controls of your car radio to neutral.
- For optimal performance, use of the external microphone by plugging it into the hands free module and directing the microphone toward the user.
- Do not leave the hands free unit connected to your cellular phone when not in use. This may discharge the battery.

INITIAL SET UP INSTRUCTIONS:

1. Insert the hands free plug-end unit into the cigarette lighter receptacle (red LED indicator illuminated).
2. Attach the other end of the hands free phone jack to the base of your cellular phone, ensuring the plug is properly aligned correctly.
3. Power "ON" your cellular phone.
4. Tune your car radio station to 87.9 on the FM band of your car radio.
5. Designate this FM position on your car radio by storing it into memory as one of your pre-set stations. This will be your SafeTalk HANDS FREE™ station on your car radio!
6. Recommended cellular phone VOLUME to set at MED LEVEL.



TO RECEIVE A CALL:

1. The audible ring of the cellular phone will signal an incoming call.
2. To access your "SafeTalk HANDS FREE™" feature:
 - a. Press the pre-set station on the radio (87.9 FM).
 - b. Press the appropriate button on your cellular phone to receive calls.
3. Adjust your car radio volume dial for desired sound volume.
4. When the call is completed, terminate your call as you would normally.
5. If you desire, press the radio station of your choice to return to the normal operation of your radio.

➤ For optimum performance, use the external microphone by plugging it into the hands free unit and attach or direct the microphone towards the user. (DO NOT plug the microphone into your phone's earphone jack!).

TO INITIATE A CALL:

1. To access your "SafeTalk HANDS FREE™" feature:
 - a. Press the pre-set station on the radio (87.9 FM).
 - b. Dial the number you wish to call or use the memory/dialer on your cellular phone to initiate the call as you would in the normal manner.
2. Adjust your car radio volume dial for desired sound volume.
3. When the call is completed, terminate your call as you would normally.
4. If you desire, press the radio station of your choice to return to the normal operation of your radio.
5. For optimum performance, use the external microphone by plugging it into the hands free unit and attach or direct the microphone towards the user. (DO NOT plug the microphone into your phone's earphone jack!).

(2)

NOTE:

When using the "SafeTalk" HANDS FREE™ unit, the display may indicate "NOT CHARGING." This is normal when a hands free unit is inserted into the phone. This is temporary and the phone will start to indicate that charging of the battery is taking place. If there is no indication of the battery charging, shut the phone off and turn the phone on. This "reset" sequence will start the battery charging on the phone.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

WARRANTY

Innovative Wireless Products provides a warranty on its products to be free defects in workmanship or material for a period of 1 year from the date of purchase. Proof of purchase with original purchase receipt with date is necessary for all warranty claims. Innovative Wireless Products will repair or replace all parts found to be defective and return the replaced or repaired products to the purchaser. The warranty does not apply to products damaged through misuse, abuse, improper installation, alteration, or unauthorized repair.

INNOVATIVE WIRELESS PRODUCTS

E-mail: sales@innovproduct.com
Internet: www.innovproduct.com