



## Composition of the Equipment.

### The main body

: As a main composition of the HandsFree kits, which is composed of PCB circuit board, magnetic, the flash battery, the clip for car visor use.

### The sound-amplification microphone(type of tongs)

: If there is no earphone plug in a mobile phone, this equipment enables to using any mobile phone with a main body.

## The procedure of operating

- 1> A package of this equipment contains a main body, a sound-amplification microphone, two pieces of flash battery.
- 2> After taking off the battery cover, put the flash battery( AA 1.5V )into the battery box.
- 3> After that turn on the power switch that attached the side of the Cardio. If the lighting system is on the front side, this equipment is in the normal operation.
- 4> Install the Cardio to the front side of the car visor which located on just above a driver seat. It is possible to install the Cardio on the back side of the car visor because of the easiness to inserting and taking off the clip.
- 5> Tune the radio in to FM frequency of 100.9MHz.
- 6> Plug in the connector of the Cardio to the mobile's earphone plug, after that put a mobile phone on the upper board of the Cardio. If using the sound-amplification , turn a changeover switch A into B. Secondly, fasten a mobile phone receiver with the sound-amplification , and then put the mobile phone on the board of the Cardio.
- 7> It is possible to have a comfortable call through the car radio by pushing the radio channel button that memorized in advance after pushing the function key or open the flip of the mobile phone. Though listening to the radio, if the FM frequency should be memorized in advance, it is possible to have a instant phone call.

