

Product Instruction Manual

Before Using:

1. The Transmitter should be connected to your Cell Phone while the other end of the Audio Cable should be inserted all the way into the Earphone Jack.
2. Please check first if the Wireless Earpiece is charged, if not, please charge it for at least 1 to 2 hours before using.

How to charge the Battery:

1. Please make sure that the Transmitter is connected to the Cell Phone with the Audio Cable connected into the Earphone Jack and the Wireless Earphone connected to the Transmitter.
2. Turn OFF the Power Switch on the Wireless Earpiece to enable the Transmitter to relay the power from the Cell Phone directly to the earpiece, charging it in the process.
3. The LED on the Wireless Earpiece will be lit during the course of charging.
4. We would like to remind you to "Charge Every time, Use Anytime".

How to make a call:

1. Take out the Wireless earpiece from the Transmitter and place it snugly into your ear. This Earpiece was ergonomically designed to comfortably fit both your left and right ear.
2. Dial on your Cell Phone like you would normally do and start communicating.

How to receive a call:

1. During an incoming phone call, take out, put on and just flick ON the Power Switch of the Wireless Earpiece and you're ready to communicate.
2. If you desire to adjust the Volume on the Earpiece, you can do so by adjusting the volume on your Cell Phone.
3. If you desire to automatically answer your Cell Phone, you can do so by enabling the "Automatic / Hands Free" Answer Mode on your Phone Setup.
4. If for some reason that there is static during use or maybe there is little or no Power on the Wireless Earpiece just simply take out the Audio Cable and continue talking using the Cell Phone directly.
- 5.

How to end a call:

1. Terminate your call, as you would normally do with a Cell Phone.
2. Once a call is terminated, flick OFF the Power Switch on the Earpiece. There is no immediate need to charge the Earpiece if it still has power. If you do need to charge it, please plug it back to the Transmitter while it's OFF.
3. The original battery that comes with the package is specifically made for this item. Charging it every time prolongs battery life, therefore extending Talk Time

Important Notice:

- For best results, please use this Wireless Solution within a 1-meter range, so as to minimize static interference and improve quality Cell Phone reception.
- Included in this package is a pair of Ear Foams which when used with the Wireless Earpiece will enable amore comfortable fit.

Model:NC-GT2

FCC ID: PZ6222068

THIS DEVICE COMPLIES WITH PART 15 OF THE FCC RULES. OPERATIONS IS SUBJECT TO THE FOLLOWING TWO CONDITIONS: (1) THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE AND (2) THIS DEVICE MUST ACCEPT ANY INTERFERENCE RECEIVED, INCLUDING INTERFERENCE THAT MAY CAUSE UNDESIRE OPERATION.

Caution : Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.