

Operation Description

The ERS Bath Station offers the user the flexibility of being able to position a ERS Bath Station anywhere in the room. This makes it ideal for strategically positioning near furniture or in a bathroom or shower. It makes it a cost effective "Add on" to the system without costly installation or wiring upgrades. Calls are initiated by pulling on the nylon pull cord. A call assurance LED illuminates briefly and a soft tone sounds at the Station to confirm the Placement of the call. The call can be cancelled at the Station by pressing a cancel button.

An illuminated LED and a tone at the Station confirm the cancellation of the call. The Wireless Pull Cord Station is suitable for surface mounting directly to a wall. No back box or special mounting hardware is required.