

# User Operation Guide for Priolite Basic Flash Trigger

The device is build and designed only for the purpose of triggering Priolite Studio Flash lights.

The device must not be used for any other purposes.

The device transmits short Radio Signals by pressing the Test button.

How to use:

Insert 3 batteries type AA with the correct polarity.

Switch the device on by pressing the On button.

To transmit trigger signals there a 2 options:

Press the red button placed on the remote camera shoe.

This way the flash can be triggered for test purposes without camera.

Slide the device into the hot shoe of a camera and secure it by fasten the black screw.

Press the shutter release of the camera. This will enable the device to sent the trigger signal.

After use switch of the unit off by pressing the On Button for one second.

This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions:

- 1.This device may not cause harmful interference and,
- 2.this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

Priolite GmbH

Würzburg, March 11, 2013