

Table of Contents

1. Introduction
2. Mini Bluetooth diagram and function introduction
3. Mini Bluetooth hands free usage guide
4. Troubleshooting
5. Federal Communications Commission(FCC)Statement
6. FCC RF Radiation Exposure Statement:

1. Introduction

The Mini Bluetooth hands free uses Bluetooth technology as a means of wireless communication, it can be used with all Bluetooth audio enabled mobile phones and devices that support the Bluetooth headset and hand free profile. Its stylish and compact design combined with its excellent audio quality and reliable performance make the Mini Bluetooth hands free a must have device.

2. Mini Bluetooth diagram and function introduction

3. Mini Bluetooth hands free usage guide

You must complete the following procedures in order to use the Mini Bluetooth hands free:

3.1 Charging the Mini Bluetooth hands free

The Mini Bluetooth hands free contains a built-in Lithium battery, it is suggested that you recharge the battery before use. You can recharge the Mini Bluetooth hands free by completing the following:

- 3.1.1 Connect the charger to a power source then connect the DC connector to the DC socket of the Mini Bluetooth hands free to commence charging (approximately 3 hours), remove the charger once charging is over.

- * When charging If the Mini Bluetooth hands free indicator lights will emit a continuous red light. The red light will fade and turn off once charging has finished.

3.2 Pairing the Mini Bluetooth hands free

As mobile phone menu and operating system differ from one another, please refer to your Bluetooth mobile phone user manual for specific information on pairing and using the Mini Bluetooth hands free. When pairing the Bluetooth hands free with your mobile phone, please ensure that the distance does not exceed 1 meter.

- 3.2.1 Press and hold the call control button until the Mini Bluetooth hands free emits a series of flashing green and red lights.

- 3.2.2 Turn on your mobile phone, enable Bluetooth then search for the

Bluetooth handsfree.

3.2.3 Please enter the pin code 1234 in order to add/pair the Bluetooth hands free.

3.2.4 Once pairing is complete, connect the Bluetooth hands free to your mobile phone. The indicator lights will now emit a series of flashing green lights. Exit and save the changes and you will now be able to use you Bluetooth hands free.

3.2.5 Turning off the Mini Bluetooth hands free

3.3 Wearing the Mini Bluetooth hands free

As illustrated in image 3.1 hook the hands free around your ear and then insert the speaker section of the Mini Bluetooth hands free into your ear like a normal ear phone. The ear hook can be removed by pulling the ear hook downwards and put back on by pushing it back up into the slot, allowing you to use the hands free on both ears.

You can also wear the Mini Bluetooth handfree without the ear hook.

3.4 Using the Mini Bluetooth hands free

*Please note: The Mini Bluetooth hands free can only be operated with the mobile phone when the mobile phone's Bluetooth services is enabled and that the range between the phone and the hands free is within 10 meters.

When the pairing of the hands free and mobile phone is complete you can use the hands free to answer or make outgoing calls

3.4.1 Answering a phone call

To answer a incoming call with the Mini Bluetooth hands free press the Call control button. once you hear the ring tone from the hands free. If you want to end the call, press the Call Control again.

3.4.2 Rejecting a phone call

To reject an incoming call with the Mini Bluetooth hands free press and hold the Call control button for 2 to 3 seconds until you hear a warning sound. It indicates that call has been rejected.

3.4.3 using voice control commands

You can also use voice control commands to ring, redial, answer, reject calls etc. Your mobile phone will need to support these features, for more information please refer to the user manual of your mobile phone.

3.4.4 Volume adjustment

During phone call you may adjust the volume of the call by

pressing the increase volume button and decrease volume button.

3.4.5 Resetting the Mini Bluetooth hands free

To reset the Mini Bluetooth hands free press and hold the Call control button for a maximum of 10 second, the hands free will emit a series of flashing red light which will indicate that the hands free is now off and has been reset.

*This operation will remove all previous pairing on the Mini Bluetooth hands free and will reset it to its default setting.

3.4.6 Turning off the Mini Bluetooth hands free

Press and hold on to the Call control button until you hear 2 beeps and see the flashing red indicator lights, this will indicate that the Mini Bluetooth hands free is now off.

4. Troubleshooting

4.1 Audio signal is not transmitted between the Mini Bluetooth hands free and the mobile phone:

Ensure that pairing is successful.

The Mini Bluetooth hands free is within range of the mobile phone.

Ensure that there are no large obstacles blocking the signal.

If the mobile phone signal is weak, reposition the mobile phone in an area with stronger signal or search the signal in network setting of your mobile phone again.

4.2The Mini Bluetooth hands free is emitting a flashing red light:

This indicates that the battery is low and talking time and standby time of the hands free is limited, please recharge the hands free.

4.3 There is no Indicator light when charging the Mini Bluetooth hands free:

This indicates that the battery of the Mini Bluetooth hands free is empty or has not been used in a long time, after charging for approximately 30 minutes the light will return. However please also ensure that the chargecable is plugged in correctly and securely.

4.4 The Mini Bluetooth hands free turn off by itself:

When the hands free is low on power and the indicator lights will emit a flashing red light and the speaker will emit a warning sound before turning off. Please recharge the hands free.

4.5 In environments of extremely hot temperatures, the Mini Bluetooth hands free may not operate properly:

Please place the hands free in room temperature and allow it to cool for a period of time before turning the Mini Bluetooth hands free back on.

4.6 Echo is heard during calling

Readjust the volume levels for optimum sound quality.

4.7 Noise is heard during calling

During a call the Mini Bluetooth hands free cannot be away from the mobile phone for more than 10 meters, for optimum performance the recommended distance is from 1 to 7 meters. If there is noise during calling please adjust the distance between the mobile phone and the Bluetooth hands free.

5.Federal Communications Commission(FCC)Statement

5.1

You are cautioned that changes or modifications not expressly approved by the part responsible for compliance could void the user's authority to operate the equipment.

5.2

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of more the following measures:

Federal Communications Commission(FCC)Statement

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

6.FCC RF Radiation Exposure Statement:

This Transmitter must not be co-located or operating in conjunction with any other antenna or transmitter:

You are cautioned that changes or modifications not expressly approved by the party responsible for compliance could void your authority to operate the equipment.