







Project Lifesaver - Client Transmitter Battery change, Maintenance & Daily Testing

**THIS INSTRUCTION PAGE MUST BE INCLUDED WITH ALL TRANSMITTERS SHIPPED TO
PROJECT LIFESAVER AGENCIES**

Client Transmitter Battery Change

<p>1. Unscrew battery cap (with a coin or screw driver) counter clockwise</p> 	<p>2. Remove and replace old Tadiran battery, Complete Transmitter Maintenance</p> 
<p>3. Add new Tadiran 30 day battery to Transmitter</p> 	<p>4. Place combined transmitter and battery into transmitter case</p> 
<p>5. Screw cap on clockwise until it stops and cap is level with transmitter case bottom</p> 	<p>5a. Correct Cap position – line up FCC imprinting with edge of Transmitter case</p> 

FCC COMPLIANCE: The transmitter is authorized by rule under the Low Power Radio Service (47 C.F.R. Part 95) and must not cause harmful interference to TV reception or Federal Government Radar.

CAUTION: Any changes or modifications to this device could void the user's authority to operate the equipment.