USER GUIDE JBD

CONTENTS
JBD ANATOMY
GET CONNECTED
GET TALKING & MORE
SAFETY INFORMATION

WATCH TUTORIAL VIDEOS AT JAWBONE.COM/ICON/VIDEOS

JBD ANATOMY

IF THE LED IS . . . QUICKLY FLASHING The JBD is trying to pair with your Jawbone.

SLOWLY FLASHING The JBD is paired with your Jawbone and ready for use.

GET CONNECTED

- 1.1 PREPARE YOUR JAWBONE
- 1 Press & hold the TALK BUTTON
- 2 Slide the POWER SWITCH on
- 3 Wait for the LED RING to fl ash red & white
- 4 Release the TALK BUTTON
- 1.2 CONNECT WITH YOUR COMPUTER
- 1 Prepare your Jawbone. See 1.1
- 2 Plug Jawbone JBD into your computer
- 3 Press and hold the CONNECT button
- 4 Wait for the **LED RING** on your Jawbone

ICON to display white and then disappear

- 5 Release the CONNECT button
- 1.3 CONNECT WITH YOUR PHONE
- 1 Prepare your Jawbone. See 1 .1
- 2 Turn on Bluetooth®

ON AN IPHONE®
Go to SETTINGS > GENERAL > and enable BLUETOOTH
8

ON A BLACKBERRY®
Go to SETTINGS/OPTIONS >
BLUETOOTH and enable BLUETOOTH
OTHER CELL PHONES

Go to **JAWBONE.COM/PAIRING** or review the instruction manual that came with your phone.

3 Go to your phone's Bluetooth® settings.

ADD OR SEARCH FOR DEVICES When "Jawbone ICON" appears, select it. IF ASKED FOR A PASSCODE

Enter "0000"

This is a one-time event per phone. To pair your Jawbone headset to another phone, repeat steps 1 1 to 1 3

GET TALKING & MORE

2.1 MAKE A CALL

Use your computer to dial via Skype®, Google Talk (SM), and others. Listen and talk through your Jawbone ICON.

2.2 STREAM AUDIO

Use your phone or computer to dial as usual. Listen and talk through your Jawbone.

2.3 ADJUST THE VOLUME

Use the volume control on your phone or computer. Or, while on a call or listening to music, **PRESS + HOLD** the **TALK BUTTON** and the volume level will cycle up and down. When you find the most comfortable volume level, release the button and your volume will be set.

2 . 4 SWITCH BETWEEN AUDIO & CALLS (OR SIMULTANEOUS MULTIPOINT)

Listen and talk on your computer while staying connected to your mobile phone. The audio from your computer will fade away when you answer or make a call on your mobile phone and resume when you hang up.

SAFETY INFORMATION

WARNING

Failure to follow these safety instructions could result in hearing damage or in fire, electric shock, or other injury or damage.

Avoiding Hearing Damage

Permanent hearing loss may occur if the Jawbone® headset is used at a high volume. Set the volume to a safe level. Even though you may become accustomed to a higher volume of sound, and even though it may sound normal, any higher volume of sound can be damaging to your hearing. If you experience ringing in your ears or muffled speech, stop listening and have your hearing checked. The louder the volume, the less time is required before your hearing could be affected. The Jawbone® headset has been initially set at a medium volume for sound. Do not increase the level of volume unless you are in conditions where you need a higher level for a short period of time. If this level of volume is uncomfortably high for you, you should decrease this level.

hearing e x perts suggest that to protect your hearing:

- 1 Limit the amount of time you use the Jawbone® headset including use at high volume.
- 2 Avoid turning up the volume to block out noisy surroundings.

3 Turn the volume down if you can't hear people speaking near you.

Jawbone Headset Care

- Do not expose your Jawbone® headset to liquid, moisture, humidity, or rain. The Jawbone® headset is not waterproof.
- Do not tamper with or abuse the Jawbone® headset. For example, without limitation, do not drop, disassemble, open, crush, bend, deform, puncture, shred, microwave, incinerate, paint, or insert foreign objects into the Jawbone® headset.
- Do not use abrasive cleaners to clean your Jawbone® headset.
- Do not expose your Jawbone® headset to extremely high or low temperatures.
- Do not leave your Jawbone® headset in direct sunlight for an extended period of time.
- Do not leave your Jawbone® headset near open flames such as cooking burners.
- Do not dispose of your Jawbone® headset in a fire. The battery could explode.
- Do not bring your Jawbone® headset into contact with any sharp objects. This can cause scratches and damage.
- Do not insert anything into your Jawbone® headset unless otherwise specified in the user manual. This may damage the internal components.
- Do not attempt to disassemble your Jawbone® headset, it does not contain serviceable components.
- Do not wear your Jawbone headset without an AliphCom approved earbud.

Built-in Battery Care

- Do not attempt to replace your Jawbone® headset's battery. It is built-in and not changeable.
- Charge the battery in accordance with the instructions supplied with this guide.
- Use only the charger supplied by Jawbone® headset's original manufacturer to charge the battery.

13

Charger Care

- Use only the charger supplied by the Jawbone® headset's original manufacturer to charge your Jawbone® headset. Other chargers may look similar but using them could be dangerous and could damage the Jawbone® headset.
- Do not attempt to disassemble the charger as it may expose you to dangerous electric shock.
- Do not use the charger outdoors or in damp areas.
- Only charge your Jawbone® headset's built-in battery in accordance with the instructions described in this guide.
- Avoid charging your Jawbone® headset in extremely high or low temperatures.
- Do not use your Jawbone® headset while it is charging.
- Do not connect the Jawbone® headset to the charger while on an active call.

Safety Information

- Check and observe local laws regarding the use of a mobile phone and headset while driving. If you use the Jawbone® headset while driving, ensure that you maintain your full attention and focus; it is your responsibility to drive safely. Consider pulling off the road before making or answering a call.
- Never allow children to play with the Jawbone® headset; the small components of the headset may be a choking hazard.
- Do not leave or store the Jawbone® headset or any of its accessories in the area over the air bag or in the air bag deployment area of an automobile as serious injury may result when an air bag deploys.
- Observe all signs and displays that require an electrical device or RF radio product to be switched off in designated areas.
- Turn off your Jawbone® headset prior to boarding aircraft. Do not use the

Jawbone® headset inside an aircraft in flight unless allowed by your airline.

- Never use the Jawbone® headset while taking a bath.
- Do not use the Jawbone® headset in a sauna or steam room.
- Do not keep your Jawbone® headset near a sink or other wet areas.
- Do not clean your Jawbone® headset while it is being charged. Always unplug the charger first before cleaning the Jawbone® headset.
- Do not attempt to repair or modify the Jawbone® headset yourself. The Jawbone® headset does not contain any user-serviceable parts. If the Jawbone® headset has been submerged in water, punctured, or subjected to a severe fall, do not use it until you take it back to your original place of purchase.
- Do not attempt to force open the built-in battery.
- Dispose of the battery in the Jawbone® headset according to local regulations. Do not dispose of the battery with household waste.
- Disposal of the packaging and your Jawbone® headset should be done in accordance with local regulations.
- Please only use with the power supply adapter provided, Jawbone model number S PA- K 9 01.
- The short wave radio frequency signals of a Bluetooth device may impair the operation of other electronic and medical devices.
- Switch off the device where it is prohibited. Do not use the device in medical facilities, aircraft, refueling points, close to automatic doors, automatic fire alarms or other automatically controlled devices.
- Keep this device at least 20 cm from pacemakers and other medical devices. Radio waves may impair the operation of pacemakers and other medical devices.

Other Notes

packaging and product disposal Dispose of the packaging and this product in accordance with the latest provisions.

FCC NOTICE

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -Reorient or relocate the receiving antenna.
- -Increase the separation between the equipment and receiver.
- -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -Consult the dealer or an experienced radio/ TV technician for help.

CAUTIONS Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC COMPLIANCE This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- 1 This device may not cause harmful interference, and
- 2 This device must accept any interference received, including interference that may cause undesired operation.

IC RSS-GEN Operation is subject to the following two conditions:

- 1 this device may not cause interference, and
- 2 this device must accept any interference, including interference that may cause undesired operation of the

FCC I D: V3 J - J BG . I C: 7589A-JBG .

To locate the FCC and IC identification numbers, please remove the earbud from the Jawbone headset.

GET MORE HELP (IF YOU NEED IT) **VISIT jawbone .com / support** for video tutorials

CALL 1 - 877 - 254 - 7426

Go to jawbone .com /warranty for warranty info

Purchase the official Jawbone Cable Kit, Fit Kit and other accessories at **www.Jawbone.com**

Become a fan of Jawbone on Facebook® Visit JAWBONE.com / FACEBOOK

This product is compliant with the CE directive. All returns must be made to the original place of purchase.

©2010 AL I PHCOM. AL L RIGHT S R E S E RVED. 7 70 - 00204 R EV A