

You can press the button quickly to find the following information:

1. If the red light blinks 1 time, the device is powered on and in standby mode.
2. If the red light blinks 1 time and blue light blinks for 10 seconds, the device is on.
3. If no light blinks, the device is off.



- * LifeBeacon must have adequate cellular signal in order to function properly.
- * Please test your device at least once per month
- * Please remember to charge your device daily.



1. Charging Device



Place power cord into wall plug. Plug into wall. Place device on charging station. Light will blink when charging.

2. Powering On



Press and hold red SOS button. Device will chime as device is powering on.

3. Using Device

Press SOS button



Speak to operator



Get Help



Three easy steps to get help

4. Powering Off



To power off device, press and hold small button inside pinhole below the SOS button.