

SMOKE ALARM: 3 Long beeps, repeating.
CO ALARM: 4 quick beeps, repeating.

STANDBY: Green LED blink every 60s.

FAULT: Amber LED blink every 5s, chirp every 30s.

LOW BATTERY: Amber LED blink every 5s, chirp every 60s.

END OF LIFE: Amber LED blink every 5s, chirp twice every 30s.

FREEZE WARNING : Red LED blink every 20 min.

Push button to test weekly.

See user guide for more information

10 year warranty. Made in China.

2560-7101-00

SENSOR ID

Clean alarm openings annually
using vacuum or compressed air.

Product is sealed with no
serviceable parts.

Do not use where
ambient temp exceeds
100° F (37.8° C).

Constant exposure to
high/low temps or high
humidity may lower
battery life. Power up
time 15 sec.

Heat sensor rating:
Fixed 135° F (57° C).

Rate of rise

>15 °F/min (8.3 °C/min)
(after 85 °F/29.4 °C).

41°F freeze warning
notification to panel.

CO alarm time:
400ppm within 4-15 min

For service return to:
UTC Fire & Security Americas
Corporation, Inc.
3211 Progress Drive,
Lincolnton, NC, 28092, USA



Model/Modèle CDX-135Z

DC Photoelectric Smoke/Fixed & Rate of Rise Heat
/Freeze/CO Detector, with Wireless
DC Smoke photoélectrique / fixe et taux de Rise Heat
/ Freeze / détecteur de CO, sans fil

SIGNALING

S1816

SIGNALATION

SYNTHÉTIQUE



SINGLE AND / OR MULTIPLE
STATION SMOKE ALARM.
ALSO SUITABLE AS A SINGLE
AND / OR MULTIPLE STATION
CARBON MONOXIDE ALARM.
ISSUE NO. XXXXXX

AVERTISSEUR DE FUMÉE AUTONOME ET /
OU MULTIPONCTUEL. STÉRILO-
ÉGALEMENT COMME AVERTISSEUR DE
MONOXYDE DE CARBONE. AUTONOME
ET/OU MULTIPONCTUEL.

Smoke sensitivity : 2.32+/-1.35 %/ft OBS

YYYY, MMM, DD

2560-7103-00

ON

PERMANENTLY
DISABLE
AND
DISCHARGE
alarm

If unit chirps for
LOW BATTERY
or END OF LIFE:

- (1) Push in the dashed area
to break tab
- (2) Rotate slotted arrow
clockwise to PERMANENTLY
DISABLE and DISCHARGE
alarm location (necessary to
avoid lithium battery fire
hazard).
- (3) Install new alarm.



FCC ID: SAK25609702
IC: 7145A-25609702

⚠ WARNING:

Carbon monoxide cannot be seen or smelled
but can kill you. If alarm sounds:

- 1.) Operate Test/Hush button.
- 2.) Call your emergency services (Fire Dept. or 911).
- 3.) Immediately move to fresh air, outdoors
or by an open window or outside door.

2560-7101-00_CD-X-135Z