


Dangbei

PadOnGo
Smart Screen



User Manual

Language

English	001-025
Deutsch	026-050
Français	051-075
日本語	076-099

Contents

Read before Use	001
Packing List	002
Installation Instructions	003
Product Overview	011
Power On	012
Using the Button	012
Using the Touch Screen	013
Connecting to Wi-Fi	013
Adjusting the Angle and Height	014
Using the Built-In Battery	015
Connections	016
Troubleshooting	017
Safety Precautions	018
Statement	022

Read before Use

Please read the product instructions carefully:

Thank you for purchasing and using these products. For your safety and interests, please read the Product Instructions carefully before using the product.

About the Product Instructions:

The trademarks and names mentioned in the Product Instructions are the property of their respective owners.

All Product Instructions shown are for illustration purposes only.


The actual product may vary due to product enhancements.

We shall not be liable for any personal injury, property damage, or other damages caused by the failure of the user to comply with the Product Instructions or precautions.


* Dangbei reserves the right to interpret and modify the Product Instructions.

Packing List


Before using the product, please check that all items are included in the box.




Lifting stand



Mobile power base




Display screen




Installation Tools




Disassembly tool



User manual




Power cord



Power adapter




Installation Instructions

- 1 Open the packaging box and take out the first layer as a whole. Then take out the mobile power base from the second layer.



Installation Instructions

- 2** Place the mobile power base in the first layer as shown in the figure below, aligning the round groove on the base with the concave groove on the packaging. Then insert the lifting stand into the mobile power base.






Align with this slot and insert

Note: Please insert the stand tightly for fixing screws in the later steps.

Installation Instructions

- 3** Find the installation tools in the package, take out the hexagonal wrench and four screws, and secure the screws.




Notes:

- Make sure that the lifting stand and mobile power base are connected firmly to avoid product damage or injury.
- It is recommended to use the diagonal fixing method, first lock the two diagonal screws and then fix the other two screws, which can make it easier to complete this step.


Installation Instructions

- 4 Place the assembled mobile stand upright on a level ground. Take out the display screen and on the back of the screen, find the hanging grooves as indicated by the arrows below.



Installation Instructions

- 5** Hold the display screen with both hands with the back facing you, as shown in the figure. Insert the two hooks on the top of the stand into the hanging grooves. When you hear a click sound, the screen is successfully installed.




Note:

- The side with buttons and camera is the top of the screen. Do not invert it.

Installation Instructions

- 6** Organize the power cord on the stand counterclockwise as shown in the figure, then insert it into the power port on the back of the screen. Press and hold the power button for 3 seconds to turn on the screen and ensure a successful connection.





Notes:


- The power port on the screen is brand specific. Only use the provided TYPE-C power.
- Make sure that the cord is connected correctly and firmly to prevent product damage or injury.
- If the screen doesn't turn on normally, check the cable connection or try using the power adapter with the base.

Installation Instructions


- 7 Organize the power cord into the groove, then rotate the screen 90° counterclockwise. Align the triangular mark on the back of the screen with the red mark on the ring cover and install the cover.



Triangular mark on the back of screen



Red mark on the ring cover



Align the two marks and push the ring cover inward



Notes:

- It is recommended to turn on the screen before installing the ring cover to ensure that the power cord has been securely plugged.
- If you need to remove the ring cover, find the quick release on the edge of the cover, then use the disassembly tool to pry it up.
- Disassembly operation has the risk of damaging the product and personal injury, please operate with caution.

Important:

- Please place and move the product in an upright position. The product may fall and cause product failure or injury.
- Be careful not to get your hands or fingers stuck in the stand or the height adjustment area.
- When moving the device, please hold the stand in the middle to avoid product damage or injury.
- If there is foreign objects on the base wheels, please use a cotton cloth to gently wipe it away.
- If the base cover is dirty, you can remove it for cleaning and then reassemble on the base after drying.


Product Overview



- ① Camera
- ② Display touch screen
- ③ Lifting stand
- ④ Mobile power base
- ⑤ Power on/off
- ⑥ Volume control
- ⑦ Camera toggle switch
- ⑧ Screen release lever
- ⑨ HDMI
- ⑩ USB3.0
- ⑪ DC IN
- ⑫ Lifting stand fixing screws
- ⑬ Universal wheel

Power On


- When turning on the product for the first time, connect the adaptor first so that the product turns on properly.
- Press and hold the power button for 3 seconds to turn on the device.



Notes:

- When connecting or disconnecting the power adapter, hold the plug and connect or disconnect it horizontally.
- Make sure it is fully inserted. Do not move it once it is connected.

Using the Button




Button	Description
Power on/off	Press to turn the screen on/off. Press and hold for 3s to power the device on/off
Volume +	Press to increase volume
Volume —	Press to decrease volume


Note:

- Please do not use foreign objects to block the Mic or light sensor to avoid abnormal voice control and adaptive brightness control.

Using the Touch Screen



Connecting to Wi-Fi




Connecting to Wi-Fi

- Go to Settings, and select Network & internet.
- Tap Internet, select your network and enter the correct password.

Adjusting the Angle and Height

The height and angle of the display can be adjusted for comfortable viewing.




Notes:

- The display defaults to landscape mode. Some apps do not support portrait mode.
- Please adjust the screen within the specified angle and height range.
- Do not let your hands or fingers get stuck in the area where the screen is adjusted.
- Do not insert foreign objects into the gaps of the lifting stand to avoid jamming the track.

Using the Built-In Battery

This product has a battery built into the stand, which allows use of the product for a period of time without an additional power supply.



Notes:

- It takes about 6 hours to fully charge the battery.
- The battery life and usage time after charging decrease in proportion to the period and duration of use of the product.
- Battery charging may not be possible at temperatures below 0°C.
- Even when not in use, the remaining charge of the battery will naturally decrease.
- For a longer battery life, charge the battery after using it for a certain period of time instead of keeping the battery charged.
- Keeping the battery level at 50 % helps extend battery life.
- The usage time shown in this manual is based on measurements conducted by Dangbei. The actual time may vary depending on usage.
- The usage time may vary depending on factors such as the external device connected, operating temperature, period of use, and user settings.

Warning

- There is a risk of explosion if the wrong battery model is used for replacement. The battery must be disassembled and replaced by professionals. Users should not disassemble or replace the battery by themselves.
- Do not disassemble, impact, squeeze, or throw the battery into fire. If it swells, do not continue to use it. Do not place it in a high temperature environment. Do not use it after it has been immersed in water.

Connections

Other devices, such as HDMI, can be connected to the product.

HDMI connection

The HDMI port at the bottom of the screen can support input from external devices.



Notes:

- Use a certified cable or device with the HDMI logo attached.
If you do not use a certified HDMI cable or device, the screen may not display or a connection error may occur.
- It is recommended to use HDMI cables that support HDMI 2.0 or above.
- If you connect a gaming device to the product, use the cable supplied with the gaming device.
- If you connect a computer or laptop to the product, some displays may be abnormal, depending on the graphics card of the external device.

USB connection

The USB port of this product is a standard USB 3.0 port. It can be used to connect external devices such as U disks, mobile hard drives, keyboards and mice, etc.



Troubleshooting

1. No display or sound

- a. Check if the product is turned on properly.
- b. Check if the adapter is properly connected to the power source.
- c. Check if the power port on the back of the screen is properly connected.
- d. Check if the four mounting screws on the power base are tightened.

2. Product suddenly turns off

- a. Check if the battery is drained.
- b. Check if the automatic shutdown function is activated on the set time.
- c. If the battery overheats, the product automatically turns off to protect itself.

3. No signal from external HDMI

- a. Restart the product and try again.
- b. Reconnect the HDMI cable.
- c. Restart the external device while the product is turned on.

4. Abnormal display

- a. This screen contains millions of pixels. You may see tiny black dots and/or brightly coloured dots at a size of 1 ppm on the screen. This does not indicate a malfunction and does not affect the performance and reliability of the product. This phenomenon also occurs in third-party products and is not subject to exchange or refund.
- b. You may find different brightness and colour of the screen depending on your viewing position. This phenomenon occurs due to the characteristic of the screen. It is not related with the product performance, and it is not malfunction.

Safety Precautions

This product has been designed with safety in mind and has undergone rigorous testing to ensure personal safety. Incorrect installation or usage may result in hazards such as electric shock or fire. To ensure safety, prolong the product's lifespan, and guarantee optimal performance, please carefully read all usage instructions before using this product, adhere to the following safety precautions, and store the user manual properly for future reference.

- If any of the following occur, unplug the product immediately and contact your local customer service:
 1. If you smell smoke or other odors coming from the product.
 2. When the power cord or plug is damaged or worn.
 3. When the product is damaged due to falling or collision, or if any liquid or foreign object enters the product.
- When cleaning the screen, make sure to unplug the power cord, and refrain from using liquid cleaners or spray cleaners directly on the screen. Instead, use a soft damp cloth to wipe the screen. If it remains unclean, use LED screen cleaner.
- Do not use accessories not authorized by the manufacturer, as this may pose risks.
- Opening or moving the casing may expose high voltage or other dangers. Do not attempt to repair the product yourself; contact qualified technicians for comprehensive repairs.
- In the event of the following situations, unplug the product and contact qualified technicians for repair:
 - a. When the power cord or plug is damaged or worn.
 - b. If the display screen falls or the casing is damaged.
 - c. If the display screen exhibits obvious abnormalities.
- Please store the monitor in an environment with temperatures ranging from 0°C to 40°C.

- A display may fall, causing serious personal injury or death. Many injuries, particularly to children, can be avoided by taking simple precautions such as:
 - a. Always educate children about the dangers of climbing on furniture to reach the display or its controls.
 - b. Never place a display in an unstable location.
 - c. Never place items that might tempt children to climb, such as toys and remote controls, on the top of the display or furniture on which the display is placed.
- Prolonged display of the same image or the presence of long-standing static elements such as text or icons on the screen may result in "image retention," where a faint trace remains on the screen for a significant period after shutdown. This phenomenon is not covered under warranty.
- Healthy product usage:
 1. Ensure adequate lighting conditions when viewing the screen, as insufficient light or prolonged screen viewing may harm your eyesight.
 2. Adjust the volume to avoid excessively high levels that may damage your hearing.
- If the product will not be used for an extended period due to reasons such as extended absence, it's essential to power off the product and unplug the power cord.

Warning:

- This product should only be used with the type of power supply indicated on its nameplate. If you have any doubts about the type of power supply you are using, please consult the official customer service.
- Do not dismantle the adapter or power cord, as it may result in fire or electric shock.
- Avoid damaging the power cord:
 1. Do not modify the power cord.
 2. Do not place heavy objects on the power cord.
 3. Keep the power cord away from heat sources.
 4. When unplugging the power plug, do not pull the power cord. Please hold the power plug by hand and then unplug the power cord.
- Do not place open flames (such as lit candles) near this product, as it may cause electric shock or fire.
- Do not place containers filled with water on this product to avoid water droplets or splashes, which may cause electric shock or fire.
- Do not insert any sharp objects, metal, or liquid into the ventilation holes, or touch the signal connectors, to prevent circuit shorts and product damage, which may also pose an electric shock hazard.
- Use a soft cloth to clean the charging port. If the charging port is dirty or has foreign objects on it, the battery may not charge normally or may cause a fire.
- Do not use this product during heavy rain, especially during thunderstorms. Please unplug the power plug promptly to prevent lightning strikes.
- Do not attempt to disassemble or assemble this product by yourself, as it may cause electric shock or fire.
- Keep small accessories out of reach of children to prevent accidental swallowing.
- Ensure that minors do not play, frolic, chase, run, jump, or handle this product in any way to avoid tipping or damaging the product.
- Do not place heavy objects on top of the product.
- Do not use the product as a stepping stool.
- Do not rub, strike, twist, or squeeze the display screen with hard objects.
- When cleaning this product, unplug the power plug, use a soft cloth to wipe it. Do not use industrial chemicals, and be careful to prevent foreign objects from entering the machine.

- Incorrect cleaning methods (such as using cleaning solutions or water) may result in damage to the product's appearance, erasing printed information on the product, or even causing liquid to enter the internal components, rendering the machine unable to display.
- When moving this product, disconnect all cable connections and move it slowly to prevent it from falling.
- Do not immediately use the machine after moving it from a cold place to a warm place, as this may cause condensation inside the product and lead to malfunctions.
- Do not place this product in areas with strong electromagnetic fields, as it may be affected and damaged by electromagnetic waves.
- If the display screen is broken and the solution splashes onto the skin, rinse immediately with water for 15 minutes and consult a doctor. When manually transporting this product, grasp it by the four corners and support the bottom, avoiding applying pressure to the screen.
- This product's base contains a built-in battery, so handle it with care during use!
- If the battery leaks liquid, stop using it immediately to avoid contact with your skin and eyes. Accidental contact may cause blindness or burns. If any unusual symptoms occur where the liquid has touched the body, wash the affected area thoroughly with plenty of water and seek medical advice.
- When charging the battery, do not use any other power source or circuit outside the specified range. There is a risk of battery damage or fire.
- If the battery is completely discharged and left unused for a long time, it may become completely unable to charge or reduce its usage lifespan.
- Do not disconnect, disassemble, or short-circuit the battery. Doing so may cause electric shock, injury, or fire.
- Dispose of the battery properly. Improper disposal of the battery may lead to explosions or fires. Battery disposal guidelines may vary depending on the country and region.

Statement



HDMI High-Definition Multimedia Interface, and the HDMI Logo are trademarks or registered trademarks of HDMI Licensing Administrator, Inc.



Excessive blue light of display products can cause eye fatigue, insomnia and other adverse reactions. This product is a low blue TÜV Rheinland certified products, by reducing the blue light component technology, can reduce eye fatigue and other adverse reactions to some extent.

In order to protect your eyesight, it is still recommended avoiding watching for a long time. If you feel eye strain, it can be relieved by looking into the distance or doing eye health exercises.



There are strict restrictions on the flicker capability within the frequency range visible and invisible to the human body.



We declare that this device is in compliance with the essential requirements and other relevant provisions of Directive 2014/53/EU.



Satisfies all the technical regulations applicable to the product within the scope of UK Radio Equipment Regulations (SI 2017/1206); UK Electrical Equipment (Safety) Regulations (SI 2016/1101); and UK Electromagnetic Compatibility Regulations (SI 2016/1091).

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Statement

This device operating frequency:

2402-2480MHz(EIRP<20dBm),2412-2472MHz(EIRP<20dBm),5150~5250MHz(EIRP<23dBm),

5250~5350MHz(EIRP<20dBm),5470~5725MHz(EIRP<27dBm),5725~5850MHz(EIRP<13.98dBm).

THIS DEVICE COMPLIES WITH DHHS RULES 21 CFR CHAPTER I SUBCHAPTER J.
CAN ICES-3 (B)/NMB-3 (B)

This Class B digital apparatus complies with Canadian ICES-003.

Cet appareil numérique de classe B est conforme à la norme canadienne ICES-003.

This device contains licence-exempt transmitter(s)/receiver(s) that comply with
Innovation, Science and Economic Development Canada's licence-exempt RSS(s).
Operation is subject to the following two conditions:

(1) This device may not cause interference.

(2) This device must accept any interference, including interference that may cause
undesired operation of the device

L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme
aux CNR d'Innovation, Sciences et Développement économique Canada applicables
aux appareils radio exempts de licence.

L'exploitation est autorisée aux deux conditions suivantes :

1.L'appareil ne doit pas produire de brouillage;

2.L'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est
susceptible d'en compromettre le fonctionnement.

For projectors only

The distance between user and products should be no less than 20cm.

La distance entre l'utilisateur et le produit ne doit pas être inférieure à 20 cm.

5150-5350MHz band is restricted to indoor use only.

La bande de 5150-5350MHz est réservée à l'usage intérieur.



WARNING: This product can expose you to Lead, which is known to the State of California to cause cancer and birth defects or other reproductive harm. For more information go to www.P65Warnings.ca.gov

EU DECLARATION OF CONFORMITY



Product : Smart screen machine
Trademark : Dangbei
Model Designation : DBPADGO1
Manufacturer’s Name : Shenzhen Dangs Science and Technology Co., Ltd.
Manufacturer’s Address : 901, GDC Building, Gaoxin Mid 3nd Road,
Maling Community, Yuehai Sub-district, Nanshan District, Shenzhen,China.
Manufacturer’s Phone : 86-755-26907499

We, Shenzhen Dangs Science and Technology Co.,Ltd.declare under our sole responsibility that the above referenced product is in conformity with the applicable requirements of the following directives:

RED Directive:	2014/53/EU	
RoHS Directive:	2011/65/EU	(EU) 2015/863
WEEE Directive:	2012/19/EU	
REACH Regulation:	2006/1907/EC	

Conformity with these directives has been assessed for the product by demonstrating compliance to the following harmonized standards and/or regulations:

- EN 62311:2008
- EN IEC 62368-1:2020+A11:2020
- EN 301489-1 V2.2.3 (2019-11)
- EN 301489-3 V2.3.2 (2023-01)
- EN 301489-17 V3.2.4 (2020-09)
- EN 55032:2015+A11:2020
- EN 55035:2017+A11:2020
- EN 61000-3-2:2019+A1:2021
- EN 61000-3-3:2013+A2:2021
- EN 301893 V2.1.1 (2017-05)
- EN 300440 V2.1.1 (2017-03)
- EN 300328 V2.2.2 (2019-07)
- 2011/65/EU, (EU) 2015/863
- 2006/1907/EC
- 2012/19/EU

Signed for and on behalf of: Shenzhen Dangs Science and Technology Co., Ltd.
Place : Shenzhen, China
Name: Libing Zhang
Signature: *Libing Zhang*

Date: 2024-02-07
Position: Certification Engineer

UKCA DECLARATION OF CONFORMITY



Product : Smart screen machine

Trademark : Dangbei

Model Designation : DBPADGO1

Manufacturer's Name : Shenzhen Dangs Science and Technology Co., Ltd.

Manufacturer's Address : 901, GDC Building, Gaoxin Mid 3rd Road,
Maling Community, Yuehai Sub-district, Nanshan District, Shenzhen, China.

Manufacturer's Phone : 86-755-26907499

We, Shenzhen Dangs Science and Technology Co., Ltd. declare under our sole responsibility that the above referenced product is in conformity with the applicable requirements of the following directives:

RoHS Directive:	SI 2022 No.622
REACH Directive:	SI 2019 No.758
RED Directive:	SI 2017 No. 1206
PSTI Directive:	SI 2023 No.1007

Conformity with these directives has been assessed for the product by demonstrating compliance to the following harmonized standards and/or regulations:

BS EN IEC 62311:2008
BS EN IEC 62368-1:2020+A11:2020
ETSI EN 301489-1 V2.2.3 (2019-11)
ETSI EN 301489-3 V2.3.2 (2023-01)
ETSI EN 301489-17 V3.2.4 (2020-09)
BS EN 55032:2015+A11:2020
BS EN 55035:2017+A11:2020
BS EN 61000-3-2:2019+A1:2021
BS EN 61000-3-3:2013+A2:2021
ETSI EN 301893 V2.1.1 (2017-05)
ETSI EN 300440 V2.1.1 (2017-03)
ETSI EN 300328 V2.2.2 (2019-07)
SI 2022 No.622
SI 2019 No.758 and its amendment(UK REACH)
EISI EN 303 645 V2.1.1(2020-06)
ISO/IEC 29147:2018

Signed for and on behalf of: Shenzhen Dangs Science and Technology Co., Ltd.

Place: Shenzhen, China

Date: 2024-02-07

Name: Libing Zhang

Position: Certification Engineer

Signature: A handwritten signature in black ink that reads 'Libing Zhang' in a cursive style.

Language

English	001-025
Deutsch	026-050
Français	051-075
日本語	076-099

Inhalt

Vor gebrauch lesen	027
Lieferumfang	028
Installationsanweisungen	029
Produktübersicht	037
Einschalten	038
Tastenbenutzung	038
Verwendung des Touchscreens	039
Verbindungsherstellung mit dem WLAN	039
Einstellung von Winkel und Höhe	040
Verwendung des integrierten Akkus	041
Anschlüsse	042
Fehlerbehebung	043
Sicherheitsvorkehrungen	044
Statement	048

Vor gebrauch lesen

Bitte lesen Sie die Produktanweisungen sorgfältig durch:

Wir danken Ihnen für den Kauf und die Verwendung unserer Produkte.

Für Ihre Sicherheit und zu Ihrer Information, lesen Sie bitte die Anleitung sorgfältig durch, bevor Sie das Produkt verwenden.

Über die Produktanweisungen:

Alle in den Produktanweisungen erwähnten Marken und Namen sind Eigentum der jeweiligen Inhaber.


Alle abgebildeten Produktabbildungen dienen nur zu Illustrationszwecken. Das tatsächliche Produkt kann aufgrund von Produktverbesserungen abweichen.

Wir haften nicht für Personen-, Sach- oder sonstige Schäden, die durch die Nichtbeachtung der Produktanweisungen bzw. Vorsichtsmaßnahmen seitens des Benutzers verursacht werden.


* Dangbei behält sich das Recht zur Auslegung und Änderung der Produktanweisungen vor.

Lieferumfang


Bevor Sie das Gerät in Betrieb nehmen, überprüfen Sie bitte, ob alle Teile im Karton enthalten sind.




Hebeständer



Mobiles elektrisches Unterteil




Anzeigebildschirm




Installationswerkzeuge




Demontagewerkzeug



Bedienungsanleitung




Anschlusskabel



Netzteil




Installationsanweisung

- 1 Öffnen Sie den Verpackungskarton und entnehmen Sie den oberen Packungseinsatz. Entnehmen Sie dann das mobile elektrische Unterteil aus der Bodenlage der Verpackung.



Installationsanweisung

- 2** Legen Sie das mobile elektrische Unterteil in den oberen Packungseinsatz, wie in der Abbildung unten dargestellt. Richten Sie dabei die runde Nut des Unterteils an der konkaven Nut der Verpackung aus. Setzen Sie dann den Hebeständer in das mobile elektrische Unterteil ein.






Richten Sie ihn auf diesen Schlitz aus und setzen Sie ihn ein

Anmerkung: Bitte setzen Sie den Ständer fest ein, um die Schrauben in den späteren Schritten befestigen zu können.

Installationsanweisung

- 3** Lokalisieren Sie das Montagewerkzeug in der Verpackung. Entnehmen Sie den Inbusschlüssel und die vier Schrauben und ziehen Sie die Schrauben an.




Anmerkungen:

- Vergewissern Sie sich, dass der Hebeständer und das mobile elektrische Unterteil fest miteinander verbunden sind, um Beschädigungen am Produkt bzw. Verletzungen zu vermeiden.
- Es wird empfohlen, das diagonale Befestigungsverfahren anzuwenden, d. h. ziehen Sie zuerst beide diagonalen Schrauben fest und daraufhin die beiden restlichen Schrauben. Dies vereinfacht diesen Montageschritt.


Installationsanweisung

- 4** Es wird empfohlen, das diagonale Befestigungsverfahren anzuwenden, d. h. ziehen Sie zuerst beide diagonalen Schrauben fest und daraufhin die beiden restlichen Schrauben. Dies vereinfacht diesen Montageschritt.



Installationsanweisung

- 5** Halten Sie den Bildschirm mit beiden Händen so, dass die Rückseite Ihnen zugewandt ist, wie in der Abbildung dargestellt. Führen Sie die beiden Haken an der Oberseite des Ständers in die Aufhängeschlitze ein. Sobald Sie ein Klickgeräusch hören, ist der Bildschirm erfolgreich installiert.




Anmerkung:

- Die Oberseite des Bildschirms ist die Seite mit den Tasten und der Kamera. Achten Sie auf die richtige Ausrichtung.

Installationsanweisung

- 6** Verlegen Sie das Anschlusskabel, wie in der Abbildung dargestellt, gegen den Uhrzeigersinn auf dem Unterteil des Ständers und stecken Sie es dann in den Stromanschluss auf der Rückseite des Bildschirms. Stellen Sie den erfolgreichen Anschluss sicher und halten Sie zum Einschalten des Bildschirms die Ein-/Aus-Taste für 3 Sekunden gedrückt.





Anmerkungen:


- Der Stromanschluss am Bildschirm ist markenspezifisch. Verwenden Sie nur das mitgelieferte USB Typ-C-Anschlusskabel.
- Vergewissern Sie sich, dass das Kabel ordnungsgemäß und fest angeschlossen ist, um Beschädigungen am Gerät bzw. Verletzungen zu vermeiden.
- Falls sich der Bildschirm nicht normal einschalten lässt, prüfen Sie die Kabelverbindung bzw. prüfen Sie den Anschluss des Netzteils am Unterteil.

Installationsanweisung


- 7** Legen Sie das Anschlusskabel in die Nut und drehen Sie den Bildschirm um 90° gegen den Uhrzeigersinn. Richten Sie die dreieckige Markierung auf der Rückseite des Bildschirms auf die rote Markierung an der Ringabdeckung aus und bringen Sie die Abdeckung an.



Dreieckige Markierung auf der Rückseite des Bildschirms



Rote Markierung an der Ringabdeckung



Beide Markierungen aufeinander ausrichten und die Ringabdeckung nach innen drücken.



Anmerkungen:

- Es wird empfohlen, den Bildschirm vor dem Anbringen der Ringabdeckung einzuschalten, um zu prüfen, ob das Anschlusskabel richtig eingesteckt ist.
- Falls Sie die Ringabdeckung abnehmen müssen, suchen Sie den Schnellverschluss am Rand der Abdeckung und hebeln Sie sie mit dem Demontagewerkzeug auf.
- Bei der Demontage besteht ein potentiell Verletzungsrisiko und die Möglichkeit einer Beschädigung des Geräts, gehen Sie daher bitte vorsichtig vor.

Wichtig:

- Bitte platzieren und bewegen Sie das Gerät in aufrechter Position. Das Gerät könnte herunterfallen und zu Schäden oder Verletzungen führen.
- Achten Sie darauf, dass Sie sich nicht die Hände oder Finger im Ständer oder im Höhenverstellungsmechanismus einklemmen.
- Um Schäden oder Verletzungen beim Bewegen des Geräts zu vermeiden, halten Sie bitte den Ständer in der Mitte fest.
- Falls sich Fremdkörper auf den Rollen am Unterteil befinden, wischen Sie diese bitte vorsichtig mit einem Baumwolltuch ab.
- Falls sich Schmutz auf der Abdeckung des Unterteils befindet, können Sie diese zum Reinigen abnehmen und nach dem Trocknen wieder am Unterteil anbringen.


Produktübersicht



- ① Kamera
- ② Touchscreen des Bildschirms
- ③ Hebeständer
- ④ Mobiles Unterteil
- ⑤ Ein/Aus
- ⑥ Lautstärkeregler
- ⑦ Schiebetaste für die Kamera
- ⑧ Bildschirm-Entriegelungshebel
- ⑨ HDMI
- ⑩ USB3.0
- ⑪ DC-EINGANG
- ⑫ Befestigungsschrauben für den Hebeständer
- ⑬ Laufrolle

Einschalten


- Schließen Sie bei der Erstinbetriebnahme des Geräts zunächst das Netzteil an, damit das Gerät ordnungsgemäß eingeschaltet werden kann.
- Halten Sie die Ein-/Aus-Taste für 3 Sekunden gedrückt, um das Gerät einzuschalten.



Anmerkungen:

- Umfassen Sie beim Anschließen oder Abziehen des Netzteils den Stecker und stecken Sie bzw. ziehen Sie ihn in waagerechter Richtung ein/ab.
- Vergewissern Sie sich, dass er vollständig eingesteckt ist. Sobald er angeschlossen ist, bewegen Sie ihn nicht mehr.

Tastenbenutzung




Taste	Beschreibung
Taste	Drücken Sie die Taste, um den Bildschirm ein-/auszuschalten. Halten Sie die Taste für 3 Sekunden gedrückt, um das Gerät ein-/auszuschalten.
Lautstärke +	Drücken Sie die Taste, um die Lautstärke zu erhöhen
Lautstärke —	Drücken Sie die Taste, um die Lautstärke zu verringern


Anmerkung:

- Bitte verwenden Sie keine fremdartigen Gegenstände, um das Mikrofon oder den Lichtsensor zu blockieren, damit die Sprachsteuerung und die adaptive Helligkeitsregelung nicht beeinträchtigt werden.

Verwendung des Touchscreens



Verbindungsherstellung mit dem WLAN




Verbindungsherstellung mit dem WLAN


- Gehen Sie auf Einstellungen und wählen Sie Netzwerk & Internet.
- Tippen Sie auf Internet, wählen Sie Ihr Netzwerk und geben Sie das richtige Passwort ein.

Einstellung von Winkel und Höhe


Die Höhe und der Winkel des Bildschirms können für eine bequeme Betrachtung angepasst werden.



Kippwinkel: $25\pm 3^\circ$
Neigungswinkel: $30\pm 3^\circ$



Einstellbare Höhe:
7,87 Inch (20 cm)




Anmerkungen:

- Der Bildschirm ist standardmäßig für das Querformat voreingestellt. Einige Anwendungen unterstützen den Hochformatmodus nicht.
- Bitte passen Sie den Bildschirm innerhalb des angegebenen Winkel- und Höhenbereichs an.
- Achten Sie darauf, dass Ihre Hände oder Finger nicht in dem Verstellmechanismus des Bildschirms eingeklemmt werden.
- Stecken Sie keine Fremdkörper in die Schlitze des Hebeständers, um Blockierungen zu vermeiden.

Verwendung des integrierten Akkus

Dieses Gerät verfügt über einen in den Ständer integrierten Akku, der es ermöglicht, das Gerät zeitweise ohne zusätzliche Netzstromversorgung zu verwenden.



Anmerkungen:

- Es dauert etwa 6 Stunden, bis der Akku vollständig aufgeladen ist.
- Die Lebensdauer des Akkus und die Betriebsdauer nach dem Ladevorgang verringern sich verhältnismäßig zur Nutzungsdauer des Geräts.
- Das Aufladen des Akkus ist bei Temperaturen unter 0 °C gegebenenfalls nicht möglich.
- Selbst bei Nichtbenutzung des Geräts, nimmt die verbleibende Akkuladung selbstverständlich ab.
- Um die Lebensdauer des Akkus zu verlängern, laden Sie den Akku nach einer bestimmten Betriebszeit wieder auf, anstatt den Akku ständig aufgeladen zu halten.
- Wenn Sie den Ladezustand des Akkus bei 50 % halten, verlängert sich die Akkulebensdauer.
- Die in dieser Bedienungsanleitung angegebene Betriebsdauer basiert auf von Dangbei durchgeführten Messungen. Die tatsächliche Dauer kann je nach Nutzung variieren.
- Die Betriebsdauer unterliegt Faktoren wie angeschlossenen externen Geräten, Betriebstemperatur, Nutzungsdauer und Benutzereinstellungen.

Warnung

- Es besteht Explosionsgefahr, wenn der falsche Akkutyp zum Austausch verwendet wird. Der Akku muss von Fachleuten ausgebaut und ausgetauscht werden. Benutzer dürfen den Akku nicht selbstständig ausbauen oder ersetzen.
- Der Benutzer darf den Akku nicht zerlegen, Stoßeinwirkungen aussetzen, quetschen oder ins Feuer werfen. Falls der Akku sich verformt, verwenden Sie ihn nicht weiter. Platzieren Sie ihn nicht in einer Umgebung mit hohen Temperaturen. Verwenden Sie ihn nicht, nachdem er in Wasser getaucht wurde.

Anschlüsse

Andere Geräte können an das Produkt angeschlossen werden, wie z. B. über HDMI.

HDMI-Anschluss

Der HDMI-Anschluss an der Unterseite des Bildschirms kann Eingaben von externen Geräten unterstützen.



Anmerkungen:

- Verwenden Sie ein zertifiziertes Kabel oder Gerät, das mit dem HDMI-Logo versehen ist. Falls Sie kein zertifiziertes HDMI-Kabel oder -Gerät verwenden, wird der Inhalt möglicherweise nicht auf dem Bildschirm angezeigt oder es tritt ein Verbindungsfehler auf.
- Es wird empfohlen, HDMI-Kabel zu verwenden, die HDMI 2.0 oder höher unterstützen.
- Wenn Sie eine Spielkonsole o.ä. an das Gerät anschließen, verwenden Sie das mit der Spielkonsole mitgelieferte Kabel.
- Falls Sie einen Computer oder Laptop an das Gerät anschließen, kann es je nach Grafikkarte des externen Geräts zu einer fehlerhaften Anzeige kommen.

USB-Anschluss

Der USB-Anschluss dieses Geräts ist ein standardmäßiger USB-3.0-Anschluss. Er kann für den Anschluss externer Geräte wie U-Disks, mobile Festplatten, Tastaturen und Mäuse usw. verwendet werden.



Fehlerbehebung

1. Keine Anzeige oder Ton

- a. Prüfen Sie, ob das Gerät ordnungsgemäß eingeschaltet ist.
- b. Prüfen Sie, ob das Netzteil ordnungsgemäß an die Stromquelle angeschlossen ist.
- c. Prüfen Sie, ob der Stromanschluss auf der Rückseite des Bildschirms richtig verbunden wurde.
- d. Prüfen Sie, ob die vier Befestigungsschrauben am elektrischen Unterteil fest angezogen sind.

2. Das Gerät schaltet abrupt aus

- a. Prüfen Sie, ob der Akku leer ist.
- b. Prüfen Sie, ob die automatische Abschaltfunktion zur eingestellten Zeit aktiviert wurde.
- c. Bei Überhitzung des Akkus, wird das Gerät zum Selbstschutz automatisch ausgeschaltet.

3. Kein Signal von externem HDMI-Gerät

- a. Starten Sie das Gerät neu und versuchen Sie es erneut.
- b. Schließen Sie das HDMI-Kabel erneut an.
- c. Starten Sie das externe Gerät neu, während dieses Gerät bereits eingeschaltet ist.

4. Fehlerhafte Anzeige

- a. Dieser Bildschirm besitzt Millionen von Pixeln. Es könnten winzige schwarze Punkte und/oder bunte Punkte in einer Größe von 1 ppm auf dem Bildschirm zu sehen sein. Dies deutet nicht auf eine Fehlfunktion hin und beeinträchtigt nicht die Leistung und Zuverlässigkeit des Geräts. Dieses Phänomen tritt auch bei Geräten von Drittanbietern auf und unterliegt nicht den Garantiebedingungen für einen Umtausch oder eine Rückerstattung.
- b. Helligkeit und Farbe des Bildschirms können je nach Betrachtungsposition unterschiedlich sein. Dieses Phänomen wird durch die Eigenschaften des Bildschirms bedingt. Es stellt kein Mangel der Geräteleistung dar und ist keine Fehlfunktion.

Sicherheitsvorkehrungen

Dieses Gerät wurde mit Augenmerk auf Sicherheit entwickelt und strengen Tests unterzogen, um die Personensicherheit zu gewährleisten. Eine unsachgemäße Installation oder Benutzung kann zu Gefahrensituationen wie einem Stromschlag oder Brand führen. Um die Sicherheit, eine optimale Leistung sowie die Verlängerung der Gerätelebensdauer zu gewährleisten, lesen Sie bitte vor der Verwendung alle Gebrauchsanweisungen sorgfältig durch, beachten Sie die folgenden Sicherheitsvorkehrungen und bewahren Sie die Bedienungsanleitung zum späteren Nachschlagen sorgsam auf.

- Ziehen Sie sofort den Netzstecker heraus und wenden Sie sich an Ihren örtlichen Kundendienst, falls eine der folgenden Situationen eintritt:
 1. Wenn Sie Rauch- oder andere Geruchsbildungen aus dem Gerät wahrnehmen.
 2. Wenn das Netzkabel oder der Stecker beschädigt oder abgenutzt sind.
 3. Wenn das Gerät durch einen Sturz oder Stoßeinwirkung beschädigt wurde oder wenn Flüssigkeiten oder Fremdkörper in das Gerät gelangt sind.
- Achten Sie beim Reinigen des Bildschirms darauf, den Netzstecker abzuziehen, und benutzen Sie keine Flüssigreiniger oder Reinigungssprays direkt auf dem Bildschirm. Verwenden Sie stattdessen zum Abwischen des Bildschirms ein weiches, feuchtes Tuch. Falls der Bildschirm dennoch nicht sauber wird, verwenden Sie einen LED-Bildschirmreiniger.
- Verwenden Sie kein anderes als das vom Hersteller empfohlene Zubehör, da diese Risiken bergen könnten.
- Das Öffnen oder Verschieben des Gehäuses kann zu einem Stromschlag mit hoher Spannung oder sonstigen Gefahrensituationen führen. Versuchen Sie nicht, das Gerät eigenständig zu reparieren. Wenden Sie sich für umfassende Reparaturen an qualifizierte Techniker.
- Ziehen Sie in den folgenden Fällen den Stecker aus der Steckdose und wenden Sie sich für eine Reparatur an qualifizierte Techniker:
 - a. Wenn das Netzkabel oder der Stecker beschädigt oder abgenutzt sind.
 - b. Wenn der Bildschirm herunterfällt oder das Gehäuse beschädigt ist.
 - c. Wenn der Bildschirm offensichtliche Störungen zeigt.
- Bitte lagern Sie den Monitor in einer Umgebung mit Temperaturen zwischen 0–40 °C.

- Ein Bildschirm kann herunterfallen und zu schweren Verletzungen oder zum Tode führen. Viele Verletzungen, insbesondere bei Kindern, können durch Befolgung einfacher Vorsichtsmaßnahmen vermieden werden, wie z. B.:
 - a. Klären Sie Kinder stets über bestehende Gefahren auf, z. B. wenn diese auf Möbel klettern, um den Bildschirm oder seine Bedienelemente zu erreichen.
 - b. Stellen Sie den Bildschirm niemals an einem ungeeigneten Ort wie instabilen Flächen auf.
 - c. Platzieren Sie niemals Gegenstände, die Kinder zum Klettern verleiten könnten, wie z. B. Spielzeug und Fernbedienungen, oben auf den Bildschirm oder auf die Möbel, auf denen der Bildschirm steht.

- Die fortdauernde Anzeige desselben Bildes bzw. lang angezeigte statische Elemente wie Text oder Symbole auf dem Bildschirm können zu einem „Nachleuchten“ führen, dabei verbleibt nach dem Abschalten für einen längeren Zeitraum eine schwache Spur auf dem Bildschirm. Dieses Phänomen ist nicht durch die Garantie abgedeckt.

- Gesunde Gerätenutzung:
 1. Achten Sie beim Betrachten des Bildschirms auf angemessene Lichtverhältnisse, da unzureichendes Licht oder längeres Betrachten des Bildschirms Ihre Sehkraft beeinträchtigen könnte.
 2. Stellen Sie die Lautstärke so ein, dass sie übermäßig hohe Lautstärkepegel vermeiden, die Ihr Gehör schädigen können.

- Falls Sie das Gerät über einen längeren Zeitraum nicht benutzen, z. B. wegen längerer Abwesenheit, schalten Sie es unbedingt aus und ziehen Sie den Netzstecker ab.

Warnung:

- Dieses Gerät darf nur an Stromnetzen betrieben werden, welche den Angaben auf dem Typenschild entsprechen. Wenn Sie Zweifel an der Art des verwendeten Stromnetzes haben, wenden Sie sich bitte an den offiziellen Kundendienst.
- Zerlegen Sie nicht das Netzteil bzw. demontieren Sie nicht das Netzkabel, da dies zu einem Brand oder Stromschlag führen könnte.
- Vermeiden Sie eine Beschädigung des Netzkabels:

1. Modifizieren Sie nicht das Netzkabel.
2. Stellen Sie keine schweren Gegenstände auf das Netzkabel.
3. Halten Sie das Netzkabel von Wärmequellen fern.
4. Ziehen Sie beim Herausziehen des Netzsteckers nicht am Netzkabel. Umgreifen Sie stattdessen den Netzstecker und ziehen Sie dann erst den Netzstecker heraus.

- Bringen Sie keine offenen Flammen (wie z. B. brennende Kerzen) in die Nähe des Geräts, da diese zu einem elektrischen Schlag oder Brand führen könnten.
- Stellen Sie keine mit Wasser gefüllten Behälter auf das Gerät, um Wasserspritzer oder -Tropfenbildung zu vermeiden, die zu einem elektrischen Schlag oder Brand führen könnten.
- Stecken Sie keine scharfen Gegenstände oder Metallteile in die Belüftungsöffnungen und gießen Sie keine Flüssigkeiten ein. Berühren Sie nicht die Signalanschlüsse, um Kurzschlüsse und Geräteschäden zu vermeiden, die gleichfalls zu einem elektrischen Schlag führen könnten.
- Verwenden Sie zur Reinigung des Ladeanschlusses ein weiches Tuch. Wenn der Ladeanschluss schmutzig ist oder sich Fremdkörper darauf befinden, könnte der Akku nicht regulär geladen werden oder sogar einen Brand verursachen.
- Verwenden Sie dieses Gerät nicht bei starkem Regen, insbesondere bei Gewitter. Ziehen Sie in diesem Fall bitte umgehend den Netzstecker ab, um Blitzeinschläge zu vermeiden.
- Versuchen Sie nicht, dieses Gerät eigenständig zu zerlegen oder zusammenzubauen, da dies zu einem elektrischen Schlag oder Brand führen kann.
- Bewahren Sie Kleinstzubehör außerhalb der Reichweite von Kindern auf, um ein versehentliches Verschlucken zu verhindern.
- Achten Sie darauf, dass Minderjährige nicht mit diesem Gerät spielen, in dem Bereich herumtollen, herumjagen, rennen, springen oder es in irgendeiner Weise handhaben, um ein Umkippen oder eine Beschädigung des Geräts zu vermeiden.
- Stellen Sie keine schweren Gegenstände auf das Gerät.
- Verwenden Sie das Gerät nicht als Trittschemel.
- Reiben, berühren, drücken oder spannen Sie keine harten Gegenständen an den Bildschirm.
- Ziehen Sie vor der Gerätereinigung den Netzstecker und wischen Sie es mit einem weichen Tuch ab. Verwenden Sie keine Industriechemikalien, und achten Sie darauf, dass keine Fremdkörper in das Gerät gelangen.

- Falsche Reinigungsmethoden (z. B. die Verwendung von Reinigungslösungen oder Wasser) können die Geräteoptik beschädigen, aufgedruckte Informationen auf dem Gerät unkenntlich machen oder dazu führen, dass Flüssigkeiten in die internen Komponenten eindringen und dadurch die Bilddarstellung des Geräts nicht mehr funktioniert.
- Trennen Sie vor dem Bewegen des Geräts alle Kabelverbindungen und bewegen Sie es langsam, damit es nicht umfällt.
- Verwenden Sie das Gerät nicht sofort, nachdem Sie es von einem kalten an einen warmen Ort gebracht haben, da dies zur Kondensationsbildung im Inneren des Geräts und somit zu Fehlfunktionen führen kann.
- Stellen Sie das Gerät nicht in Bereichen mit starken elektromagnetischen Feldern auf, da es durch elektromagnetische Wellen beeinträchtigt und beschädigt werden kann.
- Falls der Bildschirm beschädigt wird und Lösung auf die Haut spritzt, spülen Sie diese sofort 15 Minuten lang mit Wasser ab und suchen Sie einen Arzt auf. Beim manuellen Transport dieses Geräts, halten Sie es an den vier Ecken hoch und stützen Sie es an der Unterseite ab, ohne Druck auf den Bildschirm auszuüben.
- Das Unterteil dieses Geräts enthält einen integrierten Akku, gehen Sie deshalb während des Gebrauchs vorsichtig damit um!
- Wenn aus dem Akku Flüssigkeit austritt, stellen Sie die Verwendung sofort ein, um den Kontakt mit der Haut und den Augen zu vermeiden. Ein versehentlicher Kontakt kann zu Erblindung oder Verbrennungen führen. Wenn an der Körperstelle, die mit der Flüssigkeit in Berührung gekommen ist, ungewöhnliche Symptome auftreten, waschen Sie die betroffene Stelle mit reichlich Wasser ab und holen Sie ärztlichen Rat ein.
- Verwenden Sie beim Aufladen des Akkus keine anderen Stromquellen oder eine andere Stromspannung außer den genannten. Es besteht die Gefahr einer Beschädigung des Akkus oder eines Brandes.
- Bei vollständiger Entladung des Akkus und langer Nichtbenutzung, könnte er sich möglicherweise nicht mehr aufladen lassen oder seine Nutzungsdauer verkürzt sein.
- Entnehmen Sie den Akku nicht, zerlegen Sie ihn nicht und schließen Sie ihn nicht kurz. Dies könnte zu einem elektrischen Schlag, Verletzungen oder einem Brand führen.
- Entsorgen Sie den Akku ordnungsgemäß. Eine unsachgemäße Entsorgung des Akkus kann zu einer Explosion oder einem Brand führen. Die Richtlinien für die Entsorgung von Batterien können je nach Land und Region abweichen.

Statement



HDMI High-Definition Multimedia Interface, and the HDMI Logo are trademarks or registered trademarks of HDMI Licensing Administrator, Inc.



Excessive blue light of display products can cause eye fatigue, insomnia and other adverse reactions. This product is a low blue TÜV Rheinland certified products, by reducing the blue light component technology, can reduce eye fatigue and other adverse reactions to some extent.

In order to protect your eyesight, it is still recommended avoiding watching for a long time. If you feel eye strain, it can be relieved by looking into the distance or doing eye health exercises.



There are strict restrictions on the flicker capability within the frequency range visible and invisible to the human body.



We declare that this device is in compliance with the essential requirements and other relevant provisions of Directive 2014/53/EU.



Satisfies all the technical regulations applicable to the product within the scope of UK Radio Equipment Regulations (SI 2017/1206); UK Electrical Equipment (Safety) Regulations (SI 2016/1101); and UK Electromagnetic Compatibility Regulations (SI 2016/1091).

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Statement

This device operating frequency:

2402-2480MHz(EIRP<20dBm),2412-2472MHz(EIRP<20dBm),5150~5250MHz(EIRP<23dBm),

5250~5350MHz(EIRP<20dBm),5470~5725MHz(EIRP<27dBm),5725~5850MHz(EIRP<13.98dBm).

THIS DEVICE COMPLIES WITH DHHS RULES 21 CFR CHAPTER I SUBCHAPTER J.
CAN ICES-3 (B)/NMB-3 (B)

This Class B digital apparatus complies with Canadian ICES-003.

Cet appareil numérique de classe B est conforme à la norme canadienne ICES-003.

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s).
Operation is subject to the following two conditions:

(1) This device may not cause interference.

(2) This device must accept any interference, including interference that may cause undesired operation of the device

L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence.

L'exploitation est autorisée aux deux conditions suivantes :

1.L'appareil ne doit pas produire de brouillage;

2.L'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

For projectors only

The distance between user and products should be no less than 20cm.

La distance entre l'utilisateur et le produit ne doit pas être inférieure à 20 cm.

5150-5350MHz band is restricted to indoor use only.

La bande de 5150-5350MHz est réservée à l'usage intérieur.



WARNING: This product can expose you to Lead, which is known to the State of California to cause cancer and birth defects or other reproductive harm. For more information go to www.P65Warnings.ca.gov