

SP1

Owner's Manual

Model: 100000



Important Notice

Travel in avalanche terrain is inherently dangerous. You are responsible for your own actions and decisions. Knowledge and experience are essential to reduce the risk of injury or even death. Do not travel in snow terrain without an experienced guide or equivalent training. Never travel alone. By using the AvaTech SP1, each user confirms that:

- User has read and understands the user manual, terms of use, and privacy policy.
- User understands the limitations of the Avatech SP1.
- User agrees that the AvaTech SP1 is not a substitute for users' own judgment.

Activities in snow are inherently dangerous. Use the AvaTech SP1 at your own risk.

Letter to the Customer

At AvaTech, we believe safety in the mountains starts with a community empowered to share knowledge, communicate effectively, and make good, data-driven decisions. We started AvaTech because of our passion for the mountains and personal experiences with life-threatening avalanches. On Monday mornings we have a team meeting that starts by asking ourselves the question: "Why do we exist?" The answer: We exist to serve you, and in doing so we aim to leave a lasting impact on the safety of our fellow mountain travelers all over the world.

We want to express our most sincere appreciation for your early adoption of our products and belief in us at AvaTech. Without you, we do not exist. As one of our first customers, you will experience an entirely new proactive avalanche safety system. The SP1 and AvaNet, when combined together, allow you to gather, share, and analyze many valuable types of snowpack data all over the world. These tools are powerful, but let's always remember that they are just tools. The SP1 does not replace a snowpit or your education, judgment, and experiences in the mountains. The avalanche puzzle is complicated, but we believe that new technologies designed to facilitate your observations and decision-making process can be valuable tools in your toolkit. Even more exciting is how these tools enable us to access the shared wisdom of the community. With AvaNet we can learn from not only our own observations, but from our neighbor's observations days, hours, or even minutes before we set foot in the backcountry.

And finally, AvaTech was founded out of MIT, but our technologies were not the products of years holed up in a lab. Ask anyone who knows us and you'll learn about our process. Our technologies are the products of deep engagement with hundreds of experts and influencers in our industry over two years of intense product development.

Ultimately, knowledge alone will not set us free. As a community we must come together to gather, share, and discuss information that can help us all make better decisions, stay safe, and enjoy the beautiful snowcapped mountains that inspire our lives. Enjoy the snow, be proactive, and let's find out what we can all do when we work together!

Sincerely,

the AvaTech Team

Copyright Notice

Contact us

For more information about the SP1 or AvaNet, please visit www.avatech.com.

Sales: sales@avatech.com

Customer Inquiries: contact@avatech.com

Product Support & Troubleshooting: service@avatech.com

Phone Number: (435) 214-4692

Address:

AvaTech, Inc.
2700 Rasmussen Rd.
Park City, UT 84098

1.0 Getting Started

1.1 Read and Understand All Instructions and Warnings

1.2 Sign up for AvaNet

AvaNet allows professionals around the world to map and share SP1 snowpack data, manual snowpits, test results, and avalanche observations. Signing up will give you the ability to register and keep your SP1 up to date with the latest firmware. If you have not signed up for AvaNet, please do so at www.avanet.avatech.com/register

1.3 Register your SP1

To register your SP1, sign in to AvaNet and click on SP1 registration in your organization's profile. Your SP1 must be registered in order for members of your organization to be able to upload their data.

1.4 SP1 Anatomy

Picture of device highlighting features

- Pressure Sensor
- Depth Sensor
- Eye
- Slider Tube
- Battery door
- Pole strap

1.5 What's in the box?

- SP1, Model: 100000
- USB Cable
- SP1 Travel Sleeve
- SP1 Quick Start Guide

1.6 Battery Information and Installation

Battery Type

The SP1 is designed for use in cold temperatures. Only use 2 non-rechargeable **Lithium 1.5 volt AA batteries** of the same type to power the SP1. Do not use alkaline batteries, because they do not have sufficient load capacity for this device.

Caution

Risk of explosion if batteries are replaced by an incorrect type. Please contact your local waste disposal department to properly recycle used batteries.

Notice

Batteries lose a significant amount of their capacity as the temperature decreases. The temperature rating for the SP1 may exceed the usable range of some batteries. For best battery-life performance in cold temperatures:

- Keep the SP1 powered-off when not in use.
- Warm up the SP1 inside of your jacket prior to use.

Battery Installation

1. To open the battery door, turn the D-ring counter-clockwise.
2. Remove the battery contact protector sheet.
3. Check to make sure the provided batteries are installed correctly.
4. To close the battery door, orient the D-ring vertically. Apply pressure and turn the D-ring clockwise 90 degrees.

1.7 Buttons and Navigation

LEFT	Press to power on, do left button action, or hold to power off.
RIGHT	Press to do right button action.
▲▼	Press to select menu options.
TEST	Press to start a test.



1.8 Power-on & SP1 Setup

1. Power on your SP1 by pressing the LEFT button.
2. Input the date and time information.
3. Select your time zone and daylight savings time setting.

Daylight Savings Time: The user must control this setting manually. Generally Daylight Savings Time is ON during the summer months and OFF during the winter months. When turned ON, the clock is advanced forward by one hour.

Warning: Proper date and time settings are critical to keeping accurate records of snowpack data. Please take care to input them correctly.

Notice: Date and time settings will automatically update when a GPS signal is acquired. Be sure to set the proper time zone, and check the settings after a GPS signal is acquired. Toggle on/off the daylight savings time to adjust accordingly.

2.0 Using your SP1

2.1 Settings Configuration

The device settings can be accessed from the main menu.

Date & Time

After a GPS signal is acquired, you can adjust the time format, time zone, and daylight savings time setting.

GPS

When a satellite signal is acquired, indicated by the (gps) icon, latitude and longitude coordinates for each test are saved in decimal degree format. Turning the GPS off will disable all signal searching and location services.

Notice: GPS accuracy and signal connectivity are dependent on location and terrain features. It may take 60 to 90 seconds to acquire satellite signals.

Bluetooth

Bluetooth Low Energy allows you to wirelessly sync SP1 snow profiles to AvaNet via the AvaNet mobile app. The Bluetooth setting must be turned on in order for the SP1 to communicate with the mobile app.

[To download the mobile app, ...](#)

Graph Detail

This setting can be adjusted to change viewing resolution of the snow profile graphs. Setting 1 is the default “high resolution” view, and setting 5 is the most blocky “low resolution” view. This setting can be adjusted when viewing graph options as well.

Notice: The graph detail setting only affects the viewing of the snow profile data, and it does not impact the stored data or BLE synced data in any way.

Compass Calibration

Before using the Slope Angle & Aspect feature, you may be required to calibrate the compass:

1. Collapse the SP1 and connect the pole strap.
2. Enter the compass calibration screen from the settings menu.
3. Hold the SP1 horizontal, and press the RIGHT button to begin.
4. Roll the SP1 one full revolution in five seconds.
5. Spin the SP1 one full revolution in five seconds.
6. Flip the SP1 one full revolution in five seconds.

Caution: Compass calibration should be done outdoors, away from objects that can disturb magnetic fields such as cars, buildings, power lines, and handheld electronic devices.

Notice: The compass must be re-calibrated after replacing the batteries.

2.2 Extending & collapsing the probe

To extend the probe:

1. While holding the handle, disconnect the pole strap and let the pole sections hang down.
2. Grip the pole section just below the slider tube, and pull down firmly until the spring button clicks into place.

To collapse the probe:

1. While holding the probe vertically, press the spring button and push the pole segment up into the slider tube as far as possible.
2. Separate the lower pole segments one at a time and fold at each joint.
3. Align the poles into the grooves and reconnect the pole strap.

Caution: Take care to evenly distribute the cable slack throughout the folding joints. Tightness at a joint may cause pinching and potential damage to the internal electrical wiring.

[\(illustrated instructions\)](#)

2.3 Collecting snowpack data

You can enter the test mode at any time by pressing the TEST button. The primary test, called a “snow profile”, is a measurement of snow structure – hardness over depth. Snow profile measurements are gathered along with date and time, and GPS location, and can be supplemented with slope angle and aspect.

To conduct a snow profile measurement:

1. With the probe fully extended, press TEST to enter the test mode.
2. Align the probe vertically, holding the tip 1 to 5 cm above the snow surface.
3. When ready, press TEST to begin. A beep indicates when you can start pushing the probe into the snow.
Caution: The screen will show “calibrating” before the first beep. Take care to keep the tip out of the snow until after the first beep is heard.
4. Probe at a constant speed, aiming to finish the probe strike in 2 to 3 seconds. A double-beep indicates that the test is almost complete.
Caution: Avoid jamming the tip into dirt, rocks, or buried vegetation.
5. Wait until the screen says “Processing Data...” to remove the SP1 from the snow.

Slope angle and aspect can be measured at any time by pressing the RIGHT button from the test mode screen. If you want to add slope angle and aspect information to a snow profile measurement, follow these steps:

1. Open the graph of the snow profile, and access the graph options by pressing the RIGHT button.

2. Navigate up to the slope angle and aspect icon, and press the RIGHT button to record.
3. With the SP1 extended, lay the pole on the slope with the handle pointing directly uphill and the screen facing the sky. The angle shown on the screen is the angle of the pole itself. The aspect shown on the screen is the direction that the probe tip is pointing.
[images to explain]
4. Press the RIGHT button to save the slope angle and aspect.

2.4 Viewing snowpack data

Snow profile measurements are sorted into folders for each day of testing. Within a given day, snow profiles are numbered in chronological order. This makes it easier to quickly recall a profile and keep track of your snow measurement process.

You can choose to tag snow profile measurements and add them to your “favorites” folder. This can be useful if you come across an interesting snow structure and you want to be able to easily find it for future reference. Favorite profiles are marked with an asterisk icon.

Snow Profile Graph

The snow profile graph shows the penetration hardness of the snow layers (horizontal axis) along with the snow layer depth (vertical axis). Penetration hardness is measured in kPa on a natural logarithmic scale. This scaling helps to show the variations in softer layers of snow, much like the industry hand-hardness graphing and AvaTech Snowpit Editor.

Snow Profile Options

*	Creates a copy of the snow profile in the favorites folder.
< ^	Displays slope angle and aspect data for the current snow profile.
O	Displays GPS coordinates for the current snow profile.
5	Adjusts the detail level of the snow profile graph display.
X	Permanently deletes the current snow profile.

2.5 Syncing and sharing with AvaNet

You can sync and share the snow profile data from your SP1 with the AvaNet mobile app. Syncing your data is a great way to back it up to a secure location, and sharing is a great way to support your mountain community with valuable information.

The process to sync data from your SP1 is controlled through the AvaNet mobile app. Simply make sure your SP1 Bluetooth setting is turned ON, then use the app interface to pair your phone and SP1.

3.0 About your SP1

3.1 Product Specifications

Weight	500 grams (XX lbs.)
Collapsed length	49 cm (19.3 in.)
Measurement length	150 cm (59 in.)
Operating temperature range	Viewing: -20 ° to 50 °C (-4 ° to 122 °F) Testing: XX to XX (requires Sam's input)
Radio frequency and protocols	Bluetooth 4.0 (Bluetooth Low Energy) 2.4GHz (2.402 – 2.48 MHz) GPS
Water Resistance	IP55 Water Resistant rating
Battery type	Two non-rechargeable lithium 1.5 volt AA batteries

3.2 Measurement Specifications

Snow profiles
Depth
Hardness
Slope angle and aspect
GPS

3.3 Interference Warnings

Beacons
Cell phones
Other?

4.0 Maintenance

4.1 Firmware updates

AvaTech will periodically release updates to the SP1 firmware. A subscription to AvaNet will give you access to the latest firmware updates. To update the firmware on your SP1, follow these steps:

1. If you do not yet have the SP1 Firmware Updater desktop app, go to SP1update.avatech.com to download client for your PC or Mac computer.
2. Run the SP1 Firmware Updater and follow the instructions on-screen. The desktop app will automatically check for new updates and install them.
3. Once complete, unplug your SP1 from your computer, and press the RIGHT button to reboot. A blank screen follows a beep while the device is updating. This process may take a few seconds to complete.

To ensure your SP1 is operating on the latest version of firmware, check for updates regularly.

4.2 Cleaning

Tip

(need Sam's input)

Pole Sections

Dust and debris may build up in the ends of the pole segments and on the ferrules. To clean the segments, use a rag to wipe down the inner and outer surfaces.

Notice: Do not clean the SP1 with harsh abrasives or chemicals. A semi-damp cloth should suffice to wipe off dust and dirt.

4.3 Storage

Let the probe sections air-dry before storing them in the SP1 Travel Sleeve or other container. Remove the batteries for long-term storage.

4.4 Adjusting cable tension

Adjusting SP1 cable tension: Over time the SP1 cable may slightly stretch from normal use. This will cause a gap between the slider tube and spring button that results in a loose feeling when fully extended. This can be fixed by adjusting the tension in the cable.

1. Collapse the SP1 and expose the threaded ferrule between the lower pole segments.
2. Using your fingers or an 11 mm wrench, turn the threaded ferrule clockwise to tighten or counter-clockwise to loosen.

4.5 Tip o-ring replacement

(Need Sam's input)

4.6 Service Centers

United States

AvaTech, Inc.
2700 Rasmussen Rd.
Park City, UT 84098
Phone: (435) 214-4692

Europe

Concept Pro Shop
100 Place de l'Aiguille du Midi
74400 Chamonix-Mont-Blanc
France
Phone: +33 4 50 54 21 43

5.0 Troubleshooting

The screen is frozen and the device won't respond. If your SP1 stops responding, there are a few steps you should take to restart it. Don't worry, your data and settings won't be lost!

1. First, try to power-cycle the device. If this doesn't work, or if the device is still behaving strangely after this process, move to step 2.
 - a. Power-down by pressing and holding the LEFT button for 2 seconds.
 - b. Wait for 5 seconds, then power-on by pressing the LEFT button.
2. If the first method didn't solve the problem, follow these steps. Your data and settings won't be lost, however it will require that you re-enter the Date and Time for temporary use until a GPS signal is achieved.
 - a. Open the battery door and completely remove the batteries.
 - b. Wait 5 seconds, then replace the batteries. Close the battery door and power-on by pressing the LEFT button.

Snow profile graphs don't match my expectations. Sometimes snow profile graphs may not meet your expectations, while other times they may make perfect sense. If graphs vary from your own snowpit observations, a few things can be happening:

1. An SP1 profile, while often correlated to manual hand-hardness, is inherently a different measurement. Firstly, the SP1 measures vertical penetration hardness while hands measure horizontal penetration hardness. Secondly, the SP1 features a small, conical tip to measure changes in penetration force, while hand-hardness uses a constant force and various sizes to measure changes in required penetration

pressure. These differences are subtle, but they do result in some differences when quantifying snow hardness.

2. Sometimes underbrush, rocks, or debris in the snow may affect layers we expect to see. Ski tracks and compaction will also have an effect on SP1 profile measurements. Be aware of spatial variability, **even on a micro-scale**.
3. If the snow profile graph shows layers as weaker than you'd expect, or if there are no visible hardness variations even when you could feel them, then the tip sensor may be jammed. Check the tip sensor for debris between the tip and tip cone. Dirt and/or ice build-up can be removed with a fingernail or head of a small nail.

O-ring missing/present?

Notice: Do not pull the tip away from the cone. Be gentle when removing debris from the groove.

I get a lot of “Test Error” messages during my snow profile measurements. (need Sam's input here)

The device won't turn on. If your SP1 won't turn on when you press the power button, try the following steps:

1. First, try replacing the batteries and confirm that they are 2 non-rechargeable **Lithium 1.5 volt AA batteries** of the same type.
2. If the first step didn't solve the issue, You may need to reboot the firmware. To do this, follow these steps:
 - a. Hold the **RIGHT** button and press the **LEFT** button. If done properly, you should hear a beep. If no beep is heard, go to step 3.
 - b. If a beep is heard, wait for approximately 15 seconds while the firmware reboots. Upon successful reboot, the AvaTech logo should appear, and the device should return to normal operation.
3. If the second step didn't solve the issue, you may need to reset the device and reinstall the latest firmware. To do this, follow these steps:
 - a. Hold the **RIGHT** and **TEST** buttons, and press the **LEFT** button. If done properly, you should hear a long beep.
 - b. If a beep is heard, wait for approximately 15 seconds while the device resets itself. Upon successful reset, the AvaTech logo should appear, followed by a screen that says “Connect Device to PC”.
 - c. Follow the instructions to update your device firmware, described in section 4.1 Firmware Updates.

The device can't get a satellite GPS signal. GPS accuracy and signal connectivity are dependent on location and terrain features. It may take 60 to 90 seconds to acquire satellite signals. If your SP1 is unable to achieve a signal, try the following steps:

1. Check to make sure the GPS is turned on in the settings menu.
2. Be sure to step away from any large obstacles that may impact connectivity, such as buildings, trees, and large terrain features.
3. Wait while the device searches for satellites. The (gps) icon will appear at the top of the screen when the device has acquired satellite signals.

Product Warranty

AvaTech Every SP1 comes with a 1-year warranty against manufacturing defects from the date of shipment. In case of a warranty claim, all parts that can be shown to have material or production defects will be replaced free of charge. Damage that can be traced to incorrect handling or normal wear and tear is excluded. The warranty is voided if the buyer or any non-authorized third party opens the device. Warranty repairs do not extend the duration of the warranty. There is a six-month warranty on spare parts. Warranty repairs will only be conducted if the device is sent in along with the receipt. The owner will be charged for the shipping. No other warranty shall exist. Any liability for any kind of loss or damage including but not limited to any direct, indirect or consequential damage is explicitly excluded.

FCC ID: 2ADY4-SP1

IC: 12664A-SP1

Made in China

Importer: XXXXX (TBD)

Manufacturer

AvaTech, Inc.
2700 Rasmussen Rd.
Park City, UT 84098, USA

FCC STATEMENT

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.

-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-Consult the dealer or an experienced radio/TV technician for help.

NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

IC STATEMENT

This device complies with Industry Canada licence-exempt RSS standard(s): Operation is subject to the following Two conditions:(1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

CAN ICES-3 (B)/NMB-3(B)

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.