


<p>Halo Lighted Bluetooth® Headphones</p> <p>IC ID: 21530-100200 FCC ID: 2AGR4-100200</p> <p>BC</p> <p>Instruction Manual</p>	<p>OVERVIEW</p>  <p>1. LED light key(M) 2. Multi-function button (MFB) 3. Volume+ 4. Volume- 5. Microphone 6. TF card slot 7. LED light 8. 3.5mm audio port 9. USB Charging Port</p>	<p>BLUETOOTH® OPERATION</p> <ol style="list-style-type: none"> 1. Please ensure that the Bluetooth function has been turned on in the settings of your Bluetooth enabled device. 2. Turn the headphone on by holding down the MFB for about 2 seconds. The LED indicator light will flash to detect Bluetooth enabled devices near you and will enter pairing mode. 3. "GEMLINE HP" will appear on the Bluetooth device list, select "GEMLINE HP" to establish pairing. If instructed to enter a PIN code, please enter '0000'. 4. The LED indicator light will turn blue to indicate successful pairing. 5. When you want to play audio from another Bluetooth device, disconnect the headphone from the original device and follow steps 1-3 to re-pair the headphones with a new Bluetooth enabled device. 	<p>BUTTON CONTROL</p> <ul style="list-style-type: none"> ● Power On/Off: long press the MFB button ● Play/Pause: Short press the MFB button ● PREV: Long press - to select the previous song ● NEXT: Long press + to select the next song ● Volume Up: Short press + button to increase volume ● Volume Down: Short press - button to decrease volume <p>HANDS-FREE PHONE USE</p> <ul style="list-style-type: none"> ● Answer incoming call: Short press MFB button ● End call: Short press MFB button once ● Redial last call: Dual press MFB button ● Reject incoming call: Press MFB button for 2 seconds <p>AUX PLAYBACK OPERATION</p> <ol style="list-style-type: none"> 1. Turn on the headphone. 2. Connect the headphone to a smartphone, audio device, or laptop with the 3.5mm AUX cable(included) 3. The next/previous song, volume, and play/pause buttons can only be adjusted on the device that is connected through the 3.5mm AUX cable. 	<p>SD CARD PLAYING</p> <p>Insert a SD card, the headphone will play the music on the card automatically. Short press Mode switch can be changed to Bluetooth mode.</p> <p>CHARGING THE HEADPHONE</p> <ol style="list-style-type: none"> 1. When the battery is low, please charge via the included USB cable. The charging time is approximately 2 hours and provides up to 5.5 hours of continuous operation. Standby time is approximately 12 hours. 2. The LED indicator light will be red during charging and the blue light will be bright once it is fully charged. <p>WARNING</p> <ol style="list-style-type: none"> 1. Do not disassemble, repair, or modify the headphone. 2. Do not place product in or near fire to avoid danger, as it uses a lithium battery. 3. Avoid storage at extreme temperatures, this can shorten the battery life and may affect the headphone.
---	---	---	--	--

Front Cover

page 02

page 03

page 04

page 05

<p>SPECIFICATION</p> <p>Model: 100200-001B</p> <p>Bluetooth Specification: Bluetooth® V4.2</p> <p>Profiles Supported: AVRCP.TS.1.6.0/A2DP.TS.1.3.1/HFP.TS.1.7.0/RF.TS.4.2.0/BB.TS.4.2.0</p> <p>Wireless Working Range: 10m (without obstacles)</p> <p>Built-in Battery: 3.7V/300mAh</p> <p>USB Recharge Voltage: DC 5V</p> <p>Output Power: 15mW</p> <p>Frequency Response: 20Hz-20KHz</p> <p>PACKING LIST</p> <ul style="list-style-type: none"> • Halo Lighted Bluetooth® Headphone • USB Charging Cable • 3.5mm AUX Cable • Storage Pouch • User Manual • Gift Box 	<p>4. Keep the headphone dry and do not store the headphone in damp areas to avoid damage to the headphone.</p> <p>5. Avoid dropping the headphone as it may cause damage to the product.</p> <p>KIND REMINDER</p> <ol style="list-style-type: none"> 1. To prolong the headphone life span and to avoid hearing damage, please do not listen to music under high volume for long periods of time. 2. When an error occurs with the headphone, please turn off the headphone and restart it to troubleshoot. 3. When the headphone power is low, the Bluetooth range may be affected. Please charge the headphone to avoid disruptions during use. <table border="1" data-bbox="938 1428 1416 1639"> <thead> <tr> <th>Problem</th><th>Troubleshooting Method</th></tr> </thead> <tbody> <tr> <td>Unable to pair the headphone with a mobile device</td><td> <ol style="list-style-type: none"> 1. Inspect whether the headphones are searching for a Bluetooth enabled device to connect to. If not, restart the headphone. 2. Difficulty in searching and connecting to a desired device can be affected if multiple devices are equipped, turned on, and in range for Bluetooth connectivity. Please turn off or disable the Bluetooth function on the other devices. 3. The power of the battery is insufficient, please recharge the headphone. </td></tr> </tbody> </table> <p>The Bluetooth® word mark and logos are registered trademarks owned by the Bluetooth SIG, Inc. and any use of such marks by The Gem Group is under license. Other trademarks and trade names are those of their respective owners.</p>	Problem	Troubleshooting Method	Unable to pair the headphone with a mobile device	<ol style="list-style-type: none"> 1. Inspect whether the headphones are searching for a Bluetooth enabled device to connect to. If not, restart the headphone. 2. Difficulty in searching and connecting to a desired device can be affected if multiple devices are equipped, turned on, and in range for Bluetooth connectivity. Please turn off or disable the Bluetooth function on the other devices. 3. The power of the battery is insufficient, please recharge the headphone. 	<table border="1" data-bbox="1487 1132 2036 1481"> <thead> <tr> <th>Problem</th><th>Troubleshooting Method</th></tr> </thead> <tbody> <tr> <td>The music stops from time to time</td><td> <ol style="list-style-type: none"> 1. Inspect the distance between the headphone and the Bluetooth enabled device, it may exceed the Bluetooth transmission range. 2. Inspect if there is an obstacle between the headphone and the Bluetooth enabled device. 3. The power of the battery is insufficient, please recharge the headphone. </td></tr> <tr> <td>The sound is low or distorted</td><td> <ol style="list-style-type: none"> 1. Inspect the volume of the connected headphone or Bluetooth enabled device and adjust the volume as needed. 2. The power of the battery is insufficient, please recharge the headphone. </td></tr> <tr> <td>The Bluetooth indicator light remains OFF</td><td> <ol style="list-style-type: none"> 1. The power of the battery is insufficient, please recharge the headphone. 2. Restart the headphone. </td></tr> </tbody> </table> <p>The Bluetooth® word mark and logos are registered trademarks owned by the Bluetooth SIG, Inc. and any use of such marks by The Gem Group is under license. Other trademarks and trade names are those of their respective owners.</p>	Problem	Troubleshooting Method	The music stops from time to time	<ol style="list-style-type: none"> 1. Inspect the distance between the headphone and the Bluetooth enabled device, it may exceed the Bluetooth transmission range. 2. Inspect if there is an obstacle between the headphone and the Bluetooth enabled device. 3. The power of the battery is insufficient, please recharge the headphone. 	The sound is low or distorted	<ol style="list-style-type: none"> 1. Inspect the volume of the connected headphone or Bluetooth enabled device and adjust the volume as needed. 2. The power of the battery is insufficient, please recharge the headphone. 	The Bluetooth indicator light remains OFF	<ol style="list-style-type: none"> 1. The power of the battery is insufficient, please recharge the headphone. 2. Restart the headphone. 	<p>This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:(1) This device may not cause interference.(2) This device must accept any interference, including interference that may cause undesired operation of the device.</p> <p>L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :</p> <p>(1) L'appareil ne doit pas produire de brouillage;</p> <p>(2) L'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.</p> <p>NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the</p>	<p>instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:</p> <ul style="list-style-type: none"> -Reorient or relocate the receiving antenna. -Increase the separation between the equipment and receiver. -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. -Consult the dealer or an experienced radio/TV technician for help. <p>Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:</p> <p>(1) this device may not cause harmful interference, and</p> <p>(2) this device must accept any interference received, including interference that may cause undesired operation.</p>
Problem	Troubleshooting Method															
Unable to pair the headphone with a mobile device	<ol style="list-style-type: none"> 1. Inspect whether the headphones are searching for a Bluetooth enabled device to connect to. If not, restart the headphone. 2. Difficulty in searching and connecting to a desired device can be affected if multiple devices are equipped, turned on, and in range for Bluetooth connectivity. Please turn off or disable the Bluetooth function on the other devices. 3. The power of the battery is insufficient, please recharge the headphone. 															
Problem	Troubleshooting Method															
The music stops from time to time	<ol style="list-style-type: none"> 1. Inspect the distance between the headphone and the Bluetooth enabled device, it may exceed the Bluetooth transmission range. 2. Inspect if there is an obstacle between the headphone and the Bluetooth enabled device. 3. The power of the battery is insufficient, please recharge the headphone. 															
The sound is low or distorted	<ol style="list-style-type: none"> 1. Inspect the volume of the connected headphone or Bluetooth enabled device and adjust the volume as needed. 2. The power of the battery is insufficient, please recharge the headphone. 															
The Bluetooth indicator light remains OFF	<ol style="list-style-type: none"> 1. The power of the battery is insufficient, please recharge the headphone. 2. Restart the headphone. 															

Back Cover

page 06

page 07

page 08

page 09