



**SOFTWARE AND
USER MANUAL**

THE INTELLIGENT RETRIEVABLE INCIDENT SYSTEM (IRIS) BODY CAMERA COMES WITH A LIMITED HARDWARE WARRANTY AS SET FORTH IN ACCORDANCE WITH <https://www.pointblankenterprises.com/limitedwarranty>, TO THE FULLEST EXTENT PERMISSIBLE UNDER APPLICABLE LAW. THIS LIMITED HARDWARE WARRANTY AND THE REMEDIES SET FORTH THEREIN ARE EXCLUSIVE AND IN LIEU OF ALL OTHER WARRANTIES, REMEDIES, AND CONDITIONS, WHETHER ORAL OR WRITTEN, STATUTORY, EXPRESS OR IMPLIED WITH RESPECT TO THE IRIS BODY CAMERA, INCLUDING ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE.

FCC Statement:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Please see <https://www.pointblankenterprises.com> for additional product information.

Table of Contents

USER MANUAL	1
IRIS CAM Overview	6
Unit Description and Operation.....	8
Functions.....	9
Power On/Off.....	9
Power On and Auto Record	9
Resetting the Device	9
Video Recording.....	9
Voice Recording	9
Photo Capturing.....	10
Infra-Red (IR) Settings	10
LCD Display Settings.....	10
GPS Function.....	10
Tagging Button.....	11
Playback	11
Push To Talk Function For Two Way Radio.....	11
Mini Camera and Radio Cables	11
Menu Settings	12
Resolution	12
Photo Size	12
Record Overwrite.....	13
Record File Size	13
Auto IR (Infra-Red)	13
Flicker.....	13
Motion Detection.....	13
G-Sensor Set.....	13

Pre-Record	14
Post Record	14
Car Mode	14
Video Flip	14
Auto LCD Off	14
Auto Power Off	14
Date Format	15
GPS Setup	15
GPS Auto Update Time	15
GMT Setup	15
Language	15
Volume	15
LED Status	15
Silent Mode	16
Recording Alert	16
Free Space	16
Officer ID	16
Firmware Version	16
Default Settings	16
WIFI Mode	16
Troubleshooting	17
Cannot Power On	17
Video Appear to be in Black And White	17
No GPS Signal	17
Device Frozen or Unresponsive	17
Default Settings	19
SOFTWARE MANUAL	20

Overview	21
Features	21
Minimum Requirements	21
Compatible Devices	21
Setup	22
Client Installation	22
Connect	26
Client Uninstallation	26
Login	26
Device Setup	28
Modify Password	28
Browse Password	28
User Info Tab	29
Parameters Tab	30
Device Control Tab	31

IRIS CAM Overview






The IRIS CAM is an innovative video surveillance solution providing complete personal surveillance for officers. The IRIS CAM is a high-definition body worn camera device. The small, secure, lightweight, and versatile design makes the IRIS CAM a truly portable video recording system. Due to its unique versatile design, the IRIS CAM is the perfect surveillance solution for law enforcement and military applications. Users can utilize the camera system to collect evidence, strengthen officer performance and accountability, document encounters between police and the public, standardize behavioral conduct, and play back video to assure accuracy and transparency.

Firmware Version:

PBP05GE.20160319.W

IMPORTANT: IRIS CAM should be fully charged for at least 3 hours prior to first use. The red indicator LED on the front side of the IRIS CAM will turn on while charging and will turn off when the battery is fully charged. The green indicator LED will turn on when the device is on and will flash while recording.



Unit Description and Operation

1. Left Button - Up / Zoom Out Button / Laser Pointer	13. Accessory Port
2. Menu Button / Back Button	14. Speaker
3. OK / Enter Button	15. Record Button
4. Right Button - Down / Zoom In Button / Flash Light	16. Flash Light
5. Clip Rail	17. Infrared Light
6. LCD Screen	18. Camera Lens
7. LED Indicator Lights	19. Laser Pointer
8. Charger Connection Points	20. Push to Talk Button
9. Battery Access	21. Power Button
10. Photo Capture Button	22. HDMI Port / Reset Button
11. Audio Record Button	23. USB Port
12. Tagging Event / IR Button	

Functions

Power On/Off

To Power On: Press and hold the power button (21) for 2 seconds. The device will power on and enter into preview mode.

To Power Off: Press and hold the power button (21) for 2 seconds and the device will power off.

Power On and Auto Record

Press and hold the Record Button (15) for 3 seconds. IRIS CAM will automatically turn on and begin recording.

Resetting the Device

If the device fails to power on or off or is not functioning properly, users can use the reset switch located under the HDMI port. This can be done by pressing the button with a thin object, such as a paper clip. Caution must be taken as materials broken off in the reset switch opening can prevent button access.

Video Recording

Press the Record Button (15) to begin recording. The camera icon in the upper left of the LCD screen will turn red. Additionally, the LED around the record button will turn red. The evidence will be saved to the internal memory as .MP4 files. To stop recording press and hold the Record button for 3 seconds. The up and down buttons can be used to zoom in and out.

Voice Recording

Press the Audio Record (11) button to start voice recording. To stop recording, press the Audio Record (11) Button again. Your Audio files will be saved as .WAV files.

Photo Capturing

Press the Photo Capture Button (10) to take picture(s). Pictures can also be taken while recording. Your pictures will be saved as .JPG files.

Infra-Red (IR) Settings

In low light situations, videos and pictures can be captured using the Infra-red (IR) function. To turn on/off IR (manually), press and hold the Tagging/IR Button (12) for 2 seconds. This process will turn on and off the infrared light and the IRIS CAM will automatically activate and deactivate the Infrared Filter. The IR symbol on top of the screen will turn green from white when the Infrared function is activated and will turn back to white when deactivated.

LCD Display Settings

When viewing the LCD, icons and settings will show the camera resolution, WIFI, GPS, microphone, battery life, date, time and device ID.

GPS Function

With the GPS function enabled, the IRIS CAM will show an embedded GPS location (coordinates) on the videos and photos. With GPS, users can simultaneously watch the recorded videos while viewing the location on Google Maps in the application.



GPS On

When GPS is connected the satellite icon on the LCD will show green.

Important: Like any other GPS device, IRIS CAM may not be able to connect to the satellites when operating inside of some buildings.

Tagging Button

By pressing the tagging button, an event type list will display. Select the event type by using the left/right button to scroll through the list. Press OK to select an event type.

Playback

Recorded evidence can be seen as thumbnails by pressing the menu button (2) once, the media gallery will display. Users can choose the videos, pictures and audio to review by pressing the OK button, then the left and right buttons (1, 4) and clicking the OK button to select the media to play/pause (3). While watching a video, left and right buttons (1, 4) will change the video speed to fast forward and slow motion.

NOTE: To exit out of preview and media gallery, click the menu button.

Push To Talk Function For Two Way Radio

If the device is connected to a two way radio, it can be used to replace the microphone. You can activate this function by pressing the PTT button (20).

Mini Camera and Radio Cables

Additional accessories such as mini cameras and radio cables can be used with the accessory port.

NOTE: Make sure to power off the device before connecting/disconnecting accessories.

Menu Settings

Under the LCD screen, press the Menu button (2) twice to access the device's menu settings. To scroll settings use the left right buttons. Pressing once more will take you back to the main screen.

Important: The default password to change the settings is: 000000

Password: 000000



Resolution

To change the video Resolution, highlight “Resolution” and click the OK button (3). Users can select the desired video resolution and options are from highest quality to normal quality and include: (2304x1296/30F), (1920x1080/30F), (1280x720/30F) and (848x480/30F).

Photo Size

To select the photo size, highlight “Photo Size” and click the OK button (3). Users can choose the desired photo size from the options. 16 Mega-pixels (16M as displayed on the menu) will be the largest picture size, while 2 Mega-pixels (2M as displayed on the menu) is the smallest picture size available on the device.

Record Overwrite

Record Overwrite can be set to On or Off. When out of space on the device, this function allows the oldest videos to be overwritten in order to create space when recording new videos.

Record File Size

This features allows users to set the length of the video files that are produced when recording. Users can choose to split videos into files anywhere from 1 minute to 15 minutes.

Auto IR (Infra-Red)

The Auto IR option allows users to disable or select manual and automatic. By selecting “Manual,” users will need to turn the IR on and off when desired, using the IR Button (12). In automatic mode, the IR will turn on automatically when low light is detected.

Flicker

This function allows users to select a desired refresh rate. Users can change the display refresh rate to 50Hz, 60Hz or to Auto to avoid screen flickering.

Motion Detection

The Motion Detection option can be enabled to trigger recording when the camera detects motion.

G-Sensor Set

G-sensor measures movement through 3 axes; up and down, left and right, forward and backward. The G-sensor function will detect and automatically start recording significant or sudden movements. You can choose the sensor sensitivity from High to Low or turn the sensor off.

Pre-Record

The Pre-Record option is available with or without audio. If the Pre-Record option is enabled, the device will continuously buffer the video recording and will then save up to 30 seconds of video prior to the button being pressed whenever recording is activated.

Post Record

Post record option is available from 3 seconds to 15 seconds to continue capturing video after the recording has been stopped by the user.

Car Mode

Car mode option will trigger the device to start recording when it is place into the dock.

Video Flip

The Video Flip option allows will adjust the LCD if flipped upside down. User can select from off, on, and auto.

Auto LCD Off

This option will set the LCD Screen timeout duration. Duration can be set from 30 seconds to 3 minutes or the timeout can be turned off completely. Users can also turn the display off manually by clicking the power button.

Auto Power Off

Auto power off function will set the time duration for the device to power off in order to save battery life. It can be selected from 3 minutes to 5 minutes. The auto power off function will not turn off the device while it is actively recording.

Date Format

This option is to set the date display format for the device. Users can select from MM-DD-YYYY, YYYY-MM-DD, or DD-MM-YYYY.

GPS Setup

This function turns the GPS connection on or off.

GPS Auto Update Time

If GPS auto update time option is enabled, the device's internal clock will be updated based on information from the GPS signal.

GMT Setup

GMT setup allows users to change the local time zone.

Language

The language function allows for selection of the language that the device will use for its menus.

Volume

This option allows users to set the device volume. It displays the options of Low, Med, High, or Off.

LED Status

The LED Status function allows the users to turn on and off the red LED ring, located around the record button. This LED ring only displays when recording.

Silent Mode

The Silent Mode function gives users the ability to turn off all sounds from the device.

Recording Alert

When the Recording Alert is enabled, users will hear an audio alert indicating that the device is currently recording. This alert can be specified to play every 30 seconds, 1 minute, 2 minutes, 3 minutes, or it can be disabled.

Free Space

This shows the user the amount of storage space available on the device.

Officer ID

The configured Officer ID is shown here. This can be setup through the software. Once the Officer ID is set, it will display on any video evidence recorded by the device.

Firmware Version

This option shows the current firmware version.

Default Settings

By clicking OK on the Default Settings option, the device will restart and reset the settings back to the original factory default settings.

WIFI Mode

WIFI Mode will display AP and can be changed to Dispatch.

Troubleshooting

Cannot Power On

Push the reset button. If the device does not power on, change the battery. Next step would be try plugging the device into a power source to recharge.

NOTE: *If battery life is fully depleted, the camera will not turn on even if plugged into power source, until it has partially charged.*

Video Appear to be in Black And White

Check if the Infra-red function is turned on.

No GPS Signal

First, check if the GPS icon (satellite) is showing. If not, go to GPS setting and turn on. When GPS is connected, GPS icon will turn green.

NOTE: *GPS connections can't always be made from inside buildings.*

Device Frozen or Unresponsive

Reset the device by using the reset button.

IRIS CAM LIMITED ONE YEAR WARRANTY

The IRIS CAM will be free from defects in material and workmanship and will meet the stated specifications in our materials, under normal use and service when correctly installed, operated and maintained. This product warranty is effective for the period of one (1) year. If within one (1) year from the date of purchase the IRIS CAM and/or its radio cable fails due to a defect in material or workmanship, Point Blank Advanced Technology Group will repair, if possible, or replace it free of charge. This warranty applies only to the original purchaser and is not transferable.

POINT BLANK ADVANCED TECHNOLOGY GROUP WILL NOT BE LIABLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES TO PURCHASER, OR ANY OTHER PARTY, FOR ANY LOSS, DAMAGE, INJURY OR EXPENSE OF ANY KIND OR NATURE CAUSED DIRECTLY OR INDIRECTLY BY THE PRODUCT OR THE FAILURE OF THE PRODUCT TO OPERATE PROPERLY.

THIS WARRANTY IS IN LIEU OF ALL OTHER EXPRESS OR IMPLIED WARRANTIES. ALL IMPLIED WARRANTIES, INCLUDING THE WARRANTY OF MERCHANTABILITY AND THE WARRANTY OF FITNESS FOR A PARTICULAR PURPOSE, ARE HEREBY MODIFIED TO EXIST ONLY AS CONTAINED IN THIS LIMITED WARRANTY, AND SHALL BE OF THE SAME DURATION AS THE WARRANTY PERIOD STATED ABOVE.

This warranty covers the entire IRIS CAM unit and radio cable. Due to daily wear and tear, it does not cover car DVR kits, shoulder harnesses or other accessories.

The warranty does not apply to:

(a) damage caused by accident or abuse in handling, such as dropping; (b) acts of God; (c) water damage; (d) units which have been subject to unauthorized repair, opened, taken apart or otherwise modified; (e) units not used in accordance with directions; (f) damages exceeding the cost of the product; (g) depreciated or loss of charge time; (h) the finish on any portion of the product, such as surface scratches and/or weathering, as this is considered normal wear and tear.

Warranty service is available by contacting your authorized Point Blank Advanced Technology Group. A valid copy of original invoice and a Return Merchandise Authorization (or RMA) are required for all warranty services.

Sunlight Damage: Do not leave the product exposed to direct sunlight where it can cause the device temperature to exceed 120°F. Extended exposure to direct sunlight can damage the product.

Default Settings

RESOLUTION.....	1280x720/30F
PHOTO SIZE.....	.5M
RECORD OVERWRITE.....	OFF
RECORD FILE SIZE.....	10 MIN
IR CUT.....	MANUAL
FLICKER.....	50Hz
DETECTION.....	OFF
G_SENSOR SET.....	OFF
PRE RECORD.....	OFF
POST RECORD.....	OFF
CAR MODE.....	OFF
VIDEO FLIP.....	OFF
AUTO LCD OFF.....	30 SEC
AUTO POWER OFF.....	3 MIN
DATE FORMAT.....	MM-DD-YYYY
GPS SETUP.....	ON
GPS AUTO UPDAET TIME.....	ON
GMT SETUP.....	-4
LANGUAGE.....	ENGLISH
VOLUME.....	HIGH
LED STATUS.....	ON
SILENT MODE.....	OFF
RECORDING ALERT.....	OFF
FREE SPACE.....	Depending on amount of files on device
OFFICER ID.....	Empty
FIRMWARE VERSION.....	Firmware version will display
DEFAULT SETTING.....	NO
WIFI MODE.....	AP

(*)(GMT)United States Time Zones: (-12) — Baker Island and Howland Island

(-11) — American Samoa, Jarvis Island, Kingman Reef, Midway Atoll and Palmyra Atoll

(-10) — Hawaii, most of the Aleutian Islands, and Johnston Atoll

(-09) — most of the state of Alaska

(-08) — the states on the Pacific coast plus Nevada and parts of Idaho

(-07) — Arizona, Colorado, Montana, New Mexico, Utah, parts of Idaho, Kansas, Oregon, North/South Dakota and Texas

(-06) — Gulf Coast, Tennessee Valley, U.S. Interior Highlands, Great Plains, and most of Texas

(-05) — the states on the Atlantic coast, the eastern two-thirds of the Ohio Valley, most of Michigan

(-04) — Puerto Rico, the U.S. Virgin Islands and Palmer Station

(+10) — Guam and the Northern Mariana Islands


(+12) — Wake Island, McMurdo Station, and Amundsen-Scott South Pole Station



IRIS CAM

Intelligent Retrievable Incident System

SOFTWARE MANUAL



Overview

This manual is intended to provide the user with the information required for proper installation, initial setup and explanation of the individual programming options.

Features

- Allow user activate via USB
- Allow User login
- Sync IRIS CAM to computer clock
- Modify login password and user ID
- Allow user to define Police ID
- Allow user to define Video Resolution, Photo Quality and Photo Size

Minimum Requirements

- Windows XP (Service Pack 3)
- Windows 7 (32 and 64 bit)
- Additional or external hard drive storage (recommended for archiving video)


Compatible Devices



IRIS CAM Body Camera



Setup



- To install IRIS CAM Client application, double click on setup.exe file.

Client Installation









Connect


After software is installed, the IRIS CAM icon will appear on your desktop.



Double click on the IRIS CAM icon to start the software. If you use Windows 7, run as Administrator to make sure all functions work properly.

Client Uninstallation

Go to START – ALL PROGRAMS – IRIS CAM: Select Uninstall to delete IRIS CAM Client.



Login


The Login Screen for the IRIS CAM Client application will appear on your desktop.

Next, start the IRIS CAM Client application.

- Double click on the “IRIS CAM” icon located on the desktop. Alternatively, the program can also be started by clicking “Start,” selecting “All Programs,” selecting “IRIS CAM” and clicking on “IRIS CAM.”




The program will open.



To copy video from the IRIS CAM to your computer, connect the provided USB cable to the device and the computer. The IRIS CAM will turn on automatically. **Make sure the device is not already plugged in and ON before opening the application.**

This will connect the software application to the device.


Enter your password and click the “Login” button. **The default password is 000000.**



Device Setup

Modify Password

- Click the “Modify” button located next to the password field. The Change Password page will display.



- Enter current password into the “Password” field. Then type the new password into the “New password” section and “Retype password” field to confirm.
- Click the “Modify” button. The password will be updated.

Browse Password


At the bottom of the change password page is the “Set Browse Password” section. This is for a separate application that displays GPS and the video evidence together.

- Enter current password into the “Password” field and type the new password into the “New password” section and “Retype password” field to confirm.

- Click the “Apply” button. The password will update.

User Info Tab

The “User Info” tab for the IRIS CAM is displayed by default.




On this screen, users are able to view Device ID, Department Number, User ID and User name.

Once logged in the device information will display automatically. To change any of the fields, update the desired field and click “Apply.” This will apply the changes.

Parameters Tab

- Click the “Parameters” tab.




On this screen, users are able to change the Video Resolution, Photo Resolution, Video Length and view the available storage space on the device.

To change any of these features on the device, click the drop down menu and select the option(s) you prefer.

- Once selected, click the “Apply” button. This will apply the new settings to the device.


Device Control Tab

- Click the “Device Control” tab.




This screen allows users to sync their device with their computer's date and time by clicking the Manually Set Time and Date button, access their recordings on the device by clicking the Enter Data Storage and delete the contents of the device using the Format button.


- Click “Manually set time and date.” The device will synchronize with the computer’s date and time.
- Click the “Enter Data Storage” button. This will give access to manage the recorded files.



Videos are located under the DCIM folder.



- To delete the contents off the device, click the “Format” button. A message will pop up stating that this operation will delete the contents off the device.



- Click “Yes” to delete or “No” to cancel the operation.



CORPORATE ADDRESS:

Point Blank Body Armor
2102 Southwest 2nd Street
Pompano Beach, FL 33069

Phone Numbers:

Nationwide: 1 (800) 413-5155

Local/Int'l: (954) 630-0900

Fax: (954) 656-6569

Customer Service: 1 (800) 413-5155

GSA Sales: 1 (800) 413-5155 ext. 1446

International Sales: 1 (800) 413-5155 ext. 13239



IRIS CAM
Intelligent Retrievable Incident System

Point Blank Enterprises

2102 Southwest 2nd Street
Pompano Beach, FL 33069 USA
1(800) 413-5155
Local/Int'l: (954) 630-0900
Fax: (954) 656-6569
Email: IRISCamSupport@pbearmor.com
www.pointblankenterprise.com