


USER MANUAL

REAL MOTION STEERING Simulated Steering Wheel



1. Open the battery compartment under the car and install (3) 1.5V batteries according to the polarity orientation shown. Close the compartment after installing the batteries.
2. Turn the POWER SWITCH to ON and turn the steering wheel to move the car.
3. Fine tune the direction of the wheels of the car to run it in a straight line.
4. Open the battery compartment of the controller and install (3) 1.5V AA batteries according to the polarity orientation shown. Close the compartment after installing the batteries.

changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.