

成品尺寸: 55X88MM

材质: 105G铜版纸

360°Panoramic Camera
Quick Operation Guide

*Please read guide carefully before using

Packing List

Camera Specifications

Device Installation

The camera is mounted to the ceiling. Reference steps below for further instructions:

- Remove the camera's mount base from the camera's bracket base and set the camera's mount base to desired location on ceiling, insert two screws to install the mount base to ceiling.
- Reattach the camera to the mount base.

ATTENTION: The SD card will be automatically formatted when it is inserted into the SD card slot. Please back up any data from the SD card before inserting it into the camera to ensure no data is lost.

Please use only the included power adapter and micro USB cable as the camera's power source. Please contact the distributor/retailer where the camera was originally purchased to buy additional A/C adapter accessories if needed.

Download APP

For Android users, download the Danale APP from the Google Play store by searching "Danale".

For iPhone users, download the Danale APP from the App Store by searching "Danale".

Sign-up and Create APP Account

- Open the Danale APP and click the "Sign-up" button. Enter the mobile number or email you would like to use, click "Next", and wait to receive the verification code that was sent to your mobile phone or email.
- Enter the verification code you received into the designated area, click "Next", and set the account password (click the small eye to see the password entered). Click "OK" to complete account registration.

Note: If the device does not give the prompt "Welcome! Your camera has started; please take a moment to setup your Wi-Fi connection through the App", power cycle the camera or press the reset button till it gives the prompt "Reset Success".

Add Camera

- After camera has A/C adapter connected and plugged in, please wait for the camera to state "Welcome! Your camera has started; please take a moment to setup your Wi-Fi connection through the App". And the power light flashes blue now.
- Open Danale APP and use the registered account to login into the APP, then click the "+" to add the camera.

Input WiFi account and password of local network, then click "Next".

The name of the WiFi network that appears in the box should match the WiFi network that the mobile phone is currently connected to.

3 After submitting the WiFi credentials, the application will open the "search Devices" page. This page will search for and find your IP camera. Once found, select the camera and wait for the camera's audio prompt "Wi-Fi setup success", your camera is being connected to the internet...Please wait "Your camera is now online. Please add your camera in the App"

Once the search is complete and your camera is found, click the "add" button to add the camera.(Note: If the "add" button is missing for the camera or shows that the camera has been added already but the account is not yours, please contact customer service for assistance).

360° Panoramic Camera

Due to different network speeds, 60-100 seconds may be needed to find your camera ID.

APP Function List

Add Device: add the needed device
Alarm Messages: Review the motion detection alarm message
Playback: playback the cloud video record from the camera
Share: share the camera with another user

Icon Description

Two-way Communication

Click on the speaker "()" and microphone "()" buttons to ensure they are on. There may be a dialog box pop-up asking for access to the microphone. Please allow this by pressing "OK" to enable this.

Playback

- You can access video playback by clicking on the "()" and SD card video "()" buttons to ensure they are on. This allows you to access both the cloud and SD card video. (Note: Cloud video viewing requires a cloud video subscription. SD card video playback requires an SD card to be installed in the camera). The video playback will be the same for both the cloud and SD card.
- Click on the tab labeled "SD card video" to view the SD card video playback page. The device automatically plays the earliest video files of the day. Drag the time-line to the left or right to select the time to play. Click on the date to the right of the time-line to select a date to view video playback.

Note: The SD card will be formatted and will begin to record automatically once inserted. It takes 5-10 minutes for the SD card video playback to appear.

Device Share

- Click the share button "()" to share the device. Choose "Manual Input", input the other user's account name (mobile phone or email), and click the "Next" button to share the camera with other users.
- Other users accept sharing requests by clicking the "()" in the APP main interface and click "Message" in the menu to see the permission request. Click "Agree" to accept the video sharing request.

Note: The user you want to share the camera with needs to have a registered Danale account.

Video quality and image rollover adjustment

In the device main screen, click "()" to view full screen mode of camera's live feed. Click "()" to open the "Video Quality" and "Change Screen View" adjustment window. To adjust the video quality, drag the slider to the right to increase clarity and to the left to decrease clarity. To change screen view, select one of the four listed options for the desired affect.

Q & A

1. How to connect to WiFi?
a. Make sure Your Smartphone have connected your Wi-Fi already!
b. Plug in your camera into a power outlet that is close to your router.
c. Click the Smart-Link configuration on the app .
d. Enter the correct Wi-Fi user name and password, then NEXT.
e. They will search for your wifi and your Camera, then they will connect automatically.
f. Please try to configure more times if fails connect.

2. How to do if the camera is offline and cannot view remotely after a long time use in APP?
a. Please recover the camera and 2 minutes later, run the APP and refresh the camera list by pulling down the APP window.
b. Please make sure if the camera is placed within the Wi-Fi signal range
c. Please check if the camera is power off or not.
d. Please check if the WiFi router works.
e. Please check is there any WiFi router name and WiFi password changing recently? If yes, please use the reset tool to reset the camera and do the connection again with the new WiFi router name and password.
f. Beyond warranty period.
Products code can not configured out or not matched.
Failure not related to products quality/ design/ technical/ manufacture.

3. Is it normal for the camera to get warm?
The camera heats up when it is on, especially when the infrared lights are on at night. This is normal - the working temperature range is -50°F - 113°F.

4. What should be avoided when camera is in use?
Please avoid placing the camera lens towards or close to glass or other reflective objects, as the reflected light will cause the image to appear overexposed nearby and dark in the distance. Please make sure there are no objects/barriers obstructing the views from the camera as this will impact the viewing angle and image quality.

Warranty

Thank you for using our products!
Please read below details before installation:
1. The warranty is 1 year once purchased (manufacture date is based on the ID in products). During warranty period, if there is any problem caused by product quality, we promise to fix it for free.
2. Below situation can not be listed for warranty:
Breakdown caused by installed in wrong environment
Improper installation/ operation/ unauthorized maintenance/ modifying/ accident/ force majeure, and any failure caused by outside environment.
Beyond warranty period.
Products code can not be configured out or not matched.
Failure not related to products quality/ design/ technical/ manufacture.
3. Company will take some charge if products can not meet warranty condition.
4. To avoid unnecessary damage, do not send products with SD card/ battery/ hard disk/ cable, it will beyond our obligation if lost.

QC PASS

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

To assure continued compliance, any changes or modifications not expressly approved by the party.

Responsible for compliance could void the user's authority to operate this equipment. (Example- use only shielded interface cables when connecting to computer or peripheral devices).

This equipment complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

FCC Radiation Exposure Statement:

The equipment complies with FCC Radiation exposure limits set forth for uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.

.