

BLUETOOTH

Selfie Stick Manual



Model No:M2P

Material: ABS+Stainless steel

Weight: 85g

Product Size: 115*28*21 mm

Features:

- High-strength stainless steel telescopic tube, eight-stage stretch, stable and solid; high-quality ABS material handle, the surface engraved with pattern texture, feel comfortable, non-slip.
- With upgraded silicone pad on the clamp, holding strong, flexible, solid and stable, do not fall off, do not hurt the phone.
- The maximum expansion length 66cm.

Using Steps :

• Bluetooth Version

1. Long press the power button for 3 seconds to turn on wireless.
2. Wait for the wireless light to start blinking.
3. Open Wireless one the phone, search for Wireless devices. Click "Candy" to connect the Wireless device.
4. If connection failed within 90s will enter sleeping mode and the light will turn off. You can press the shutter button to activate.

Reminder: If you meet problem after first use, you just need to deleting the original Bluetooth "Candy", re-connect the bluetooth of the device.

FCC WARNING

- This device complies with part 15 of the FCC Rules, Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation, Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment,
- **NOTE:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules, These limits are designed to provide reasonable protection against harmful interference in a residential installation, This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications, However, there is no guarantee that interference will not occur in a particular installation,
- If this equipment does cause harmful interference to radio or television reception,
- which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
- -- Reorient or relocate the receiving antenna,
- -- Increase the separation between the equipment and receiver,
- -- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected,
- -- Consult the dealer or an experienced radio/TV technician for help, The device has been evaluated to meet general RF exposure requirement, The device can be used in portable exposure condition without restriction
- FCC ID: 2AQA5-M2P18
-