

TRUE WIRELESS EARBUDS

1 iOS Android

打开蓝牙
Turn on bluetooth.

拿出耳机，靠近已解锁的手机
Take out the earphone and approach the unlocked mobile phone

搜索蓝牙设备PTWS13/BSTWS18点击连接即可
Search for bluetooth device PTWS13/BSTWS18 and click on the link



2 左耳触控方式

暂停/播放(捏一下)
Pause/Play (Squeeze it one)
上一曲(捏两下)
Last song (Squeeze it twice)
唤醒Sir!/
(长按1.5秒出现咚的一声后放手)
Wake up Siri
(Long press for 1.5 seconds, then boom, you let go)
来电接听
(捏一下接听再捏一下挂断)
Answer the phone
(Pinch to answer, pinch to hang up)
拒接电话(长按2秒)
Refuse to answer the phone
(Press for two seconds)



3 右耳触控方式

暂停/播放(捏一下)
Pause/Play (Squeeze it one)
下一曲(捏两下)
Next song (Squeeze it twice)
唤醒Sir!/
(长按1.5秒出现咚的一声后放手)
Wake up Siri
(Long press for 1.5 seconds, then boom, you let go)
来电接听
(捏一下接听再捏一下挂断)
Answer the phone
(Pinch to answer, pinch to hang up)
拒接电话(长按2秒)
Refuse to answer the phone
(Press for two seconds)

FCC WARNING
This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.
If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-- Reorient or relocate the receiving antenna.
-- Increase the separation between the equipment and receiver.
-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-- Consult the dealer or an experienced radio/TV technician for help.
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

USB



充电时 When charging

红灯闪烁



充满电时 When fully charged

红灯常亮



功能定义说明

耳机基本功能

拿出耳机自动弹窗，第二次自动回连
Take out the earphone automatically popover, the second time automatically connect back
关机：放入充电仓自动充电，耳机自动关机
Shutdown: Put into the charging bin for automatic charging, the headset automatically shuts down.
捏一下播放/暂停，捏两下左耳上一曲，右耳下一曲
Pinch to play/pause, and pinch twice, one on the left ear and one under the right ear. Long press 1.5 seconds出现咚的一声放手后唤醒SIRI,长按3.5S出现咚咚两声后不要放手开始音量加减功能(左耳减、右耳加)
Press long for 1.5 seconds to wake SIRI with a thud to let go, and press long for 3.5 seconds to stop after a double thud. The hand starts to increase or decrease the volume (left ear, right ear).
来电时候，捏一下接听、在捏一下挂断，长按2秒拒接电话
When the call, pinch to answer, in the pinch to hang up, long press 2 seconds to refuse to answer the call

6 主要参数

蓝牙	V5.0	耳机按键控制	触摸控制
频率响应	20Hz-20KHz	产品尺寸 (充电盒)	44*53*21mm
灵敏度	107 dB SPL +/- 3 dB	产品重量	130g
支持协议	SBC, AAC, FHSS 不支持 APTX音频编码	包装清单	无线耳机 USB充电线：说明书
充电盒USB 充电	安卓充电线		

使用注意事项

耳机需存放在干燥通风的环境下，避免与油、水汽、蒸触，以免影响产品性能。
The earphones should be stored in a dry and ventilated environment, to avoid oil, water, moisture and dust affecting product performance.
避免使用刺激的，有机溶剂或含有这些成份的物品清洁
Avoid using stimulus, organic solvents or items containing these ingredients to clean the earphones.
耳机需按要求正确规范的使用，注意使用环境对耳机的影响，为保证连接顺畅，建议手机和耳机之间的距离在10米范围内。
The use of earphones should correctly as per the specification, pay attention to use the influence of environment on the earphones.
In order to ensure the smooth connection, it's recommended that the distance between the earphones and phones with in 10 meters.
如耳机有连接不上或通讯不畅等其他问题，请勿私自拆卸耳机本体及其配件，否则不予保修。
If the earphones failed to connect or with poor connection, pls do not take apart the earphones or the accessories on your own. Otherwise, no warranty.
给耳机充电，请选用标配的车载充电器或本公司指定的符合要求的充电器。
Regarding charging earphones. Pls use the standard usb cable or pointed charging cable from our company to charge the earphones.
为保证您正常使用耳机，请确保耳机的电量充足。
In order to ensure normal use, please ensure sufficient power of the earphones. 如个别功能有修改，请联系客服。
Please contact customer service if there are any changes to individual functions.