

XHINKCAR
THINKCAR
LEADING TECH IN DIAGNOSTICS

NUCAR



Automotive Diagnostic Device
TKD01

IC Warning

"This device complies with Industry Canada's license-exempt RSSs. Operation is subject to the following two conditions:

(1) This device may not cause interference; and

(2) This device must accept any interference, including interference that may cause undesired operation of the device."

« Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence.

L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et

(2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement. »

FCC Warning

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device

must accept any interference received, including interference that may cause undesired operation.

NOTE 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against

harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause

harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television

reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.

- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

- Consult the dealer or an experienced radio/TV technician for help.





NOTE 2: Any changes or modifications to this unit not expressly

approved by the party responsible for compliance could void the user's authority to operate the equipment.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

1 Download the ThinkDiag+ App



Search for "ThinkDiag+" in the App Store or in Google Play Store. The ThinkDiag+ App is FREE to download. (as shown in the figure below)



2 Sign In or Sign Up




If you already have a Thinkcar Tech account, please sign in with your credentials. If you do not have an account, please sign up as explained in the following paragraph. Please note that one Thinkcar Tech account is common for all products by Thinkcar Tech. How to Sign Up for an Account:

Open the ThinkDiag+ App, click on "Sign Up". Input your username, email, and verification code (which will be sent to the email you input), then create your own password. Click on "Sign Up" to finish your registration.




3 Activate a Device

After the Bluetooth connection, you can use the functions of your device, such as: All Systems Diagnostic, Maintenance & Service Functions, OBD Diagnostics, Optical THINKDIAG ML, THINKTMS G, THINKEAS Y.






4 Insert the Device into the OBDII port in your vehicle

Usually, the OBDII port is located under the dashboard, above the pedal on the driver's side. Here are the 5 common positions for the OBDII port (as shown in the figure right). Insert the device, there will be a green light which indicates the device is powered on.



5 Bluetooth Connection



Open the ThinkDiag+ App, it will automatically search for activated devices. Select your device and connect it via Bluetooth in the App. Note: Please do not directly connect the device to your phone via Bluetooth settings in your phone OS. Make sure to pair your device with the first page of the Quick Start Guide.



6 Download Diagnostics Software

In the "Diagnostics" interface of the App, you will need to download the corresponding diagnostics software when first time perform "All System Diagnostic" and "OBD Functions". And there is no need to download again next time.

Open the ThinkDiag+ App, click on "Sign Up". Input your username, email, and verification code (which will be sent to the email you input), then create your own password. Click on "Sign Up" to finish your registration.



7 Start to Use Your Device

After the Bluetooth connection, you can use the functions of your device, such as: All Systems Diagnostic, Maintenance & Service Functions, OBD Diagnostics, Optical THINKDIAG ML, THINKTMS G, THINKEAS Y.

8 FAQ

Q: What do the different lights indicate?

A: There are three different lights on THINKDIAG:

Continuous Red Light: Device is powered on.

Continuous Blue Light: Bluetooth is connected.

Flashing Blue Light: Bluetooth is in communication.

Q: Why do I need to download the diagnostics software after downloading the App?

A: Due to a variety of vehicle manufacturers on the market, different

vehicle manufacturers require corresponding diagnostics software.

Therefore, we will recognize the vehicle manufacturer first while

diagnosing, then it will download the corresponding diagnostics

software to work.

Q: What vehicle can diagnose?

A: It is compatible with all vehicles supporting OBDII/EGR protocols

after 1996.

Note: Depending on your vehicle, the diagnosis software size

varies and download speed is different as well. When first

downloading the diagnosis software, it might require a good

network connection.

Q: What are the special functions of THINKDIAG?

A: THINKDIAG supports 15 special functions, including AF, S, RESE,

Elect. Throttle, RL, LR, Immobilizer/EKEY, INJECTOR, RESET BRAKE,

RESET OIL, RESET SAS, RESET LED, RESET TMS,

RESET COX, RESET PPF, RESET PMS, SRS, UNDOOR,

RESET SUS. According to different vehicle manufacturers'

diagnostic software, there will be more specifications to come.

Q: What is the point of a THINKDIAG account? How to use the points?

A: Every user can get points. For example, by recommending others

to purchase our products, participating in Thinkcar Tech's official

activities, etc. Once point redeem, which can be used to

purchase products and services. There will be more ways to get

collect points in the future.

Q: What is the invitation code in ThinkDiag+ App? How to use it?

A: After signing up for your account in the App, you will get your own

invitation code. The code can be shared with your friends and they

will get a discount. Every time the invitation code is used, you will get

points as mentioned in the previous part.

Q: Does THINKDIAG need firmware upgrade?

A: Yes, does. When THINKDIAG device is connected via

Bluetooth to your smartphone, it will automatically check if the

firmware on your device is the latest version. If it is not, it will upgrade

automatically.

Q: What smartphone can download ThinkDiag+ App?

A: ThinkDiag+ App supports smartphones with Android 5.0 and above,

iOS 9.0 and above. It cannot be used on PC with Windows

system.

Q: Can the same App account bind with multiple devices?

A: Yes, you can set them up in the App.

9 Warranty Card

1. In addition to the legal warranty right, you benefit from a 3-day money-back guarantee. The device is also guaranteed for a period of one year.

2. Before replacement, please ensure complete packaging. Before

replacement/repair, please call the service center to get the

shipping address.

3. Product warranty starting date is based on the payment date.

Service Line: 1-99-75199

Customer Service Email: support@mythinkcar.com

Official Website: www.mythinkcar.com

Follow us on Facebook: @thinkcarofficial

Twitter: @thinkcar

