

**Alienware**  
**Tri Mode Wireless Gaming Headset**  
**AW725H**  
**User's Guide**

Regulatory Model: AW725H/ UD2202u

A L I E N W A R E™   
1

 **NOTE:** A NOTE indicates important information that helps you make better use of your computer.

 **CAUTION:** A CAUTION indicates potential damage to hardware or loss of data if instructions are not followed.

 **WARNING:** A WARNING indicates a potential for property damage, personal injury, or death.

**Copyright © 2024 Dell Inc. or its subsidiaries. All rights reserved.** Dell, EMC, and other trademarks are trademarks of Dell Inc. or its subsidiaries. Other trademarks may be trademarks of their respective owners.

2024 – 02


Rev. A00

# Contents

<b>What's in the box .....</b>	<b>5</b>
<b>Features.....</b>	<b>7</b>
Headset.....	7
Accessories .....	8
<b>Charging the headset .....</b>	<b>9</b>
Battery life .....	10
Turning on/off your headset.....	11
Auto power off .....	11
<b>Connecting the headset to your device .....</b>	<b>12</b>
System requirements.....	12
Connecting the headset to your device using Bluetooth .....	12
Connecting the headset to your device using the USB wireless dongle ..	13
Connecting the headset to your device using the inline audio cable.....	15
<b>Configuring the headset on your computer .....</b>	<b>17</b>
<b>Alienware Command Center (AWCC) .....</b>	<b>20</b>
Installing AWCC .....	20
Installing AWCC through Windows Update .....	21
Installing AWCC from the Dell Support website .....	21
<b>Activating Dolby Atmos for Headphones.....</b>	<b>22</b>
<b>Updating the firmware .....</b>	<b>22</b>

Updating the headset firmware manually .....	22
Updating the USB wireless dongle firmware manually .....	23
<b>Using the headset .....</b>	<b>24</b>
Adjusting the headset .....	24
<b>Using features on the headset .....</b>	<b>25</b>
Adjusting the volume .....	25
Adjusting Game/Chat balance control .....	25
Muting/unmuting the microphone.....	26
Replacing the ear pads .....	27
Regulatory label position .....	28
<b>Troubleshooting .....</b>	<b>29</b>
<b>Specifications .....</b>	<b>32</b>
<b>Warranty information .....</b>	<b>33</b>
Limited warranty and return policies .....	33
For U.S. customers:.....	33
For European, Middle Eastern and African customers: .....	33
For non-U.S. customers:.....	33
<b>Safety information .....</b>	<b>34</b>

# What's in the box



1 Alienware Dual Mode Wireless Gaming Headset AW725H	2 USB-A to USB-C charging cable
3 USB-C wireless dongle	4 Documents
5 3.5 mm inline audio cable	6 USB-A to USB-C adapter





**NOTE: Headset must be charged prior to first time use.**



**NOTE: The documents shipped with your headset may vary depending on the region.**


# Features

## Headset




1	LED indicator	2	Power/BT button
3	Volume control	4	Retractable microphone
5	USB-C Charging port	6	Inline audio cable port
7	Game/Chat balance button	8	Microphone mute button

## Accessories



# Charging the headset

To charge the headset, connect USB-C end of the USB-A to USB-C cable to the USB-C port on your headset. Connect the other end to the USB port on your computer.




 **NOTE: For best results, ensure battery is fully charged during first time use.**

 **NOTE: To improve battery life, turn the headset off when the headset is not in use.**

## Battery life

Complete charging from flat to full may take less than 2.5 hours.


Charging indication can be found on both the power and Alienhead LEDs.



Battery status	LED indicator behavior
<b>Fully charged</b>	Power on: LED light stays green and Alienhead logo displays last selected lighting effect. Power off: LED light and Alienhead logo stays green.
<b>While charging</b>	Power on: LED light changes between amber and green. Alienhead logo changes between amber and green for 12 seconds, then returns to the previous lighting effect. Power off: LED light changes between amber and green.
<b>When battery is less than 20%</b>	Power LED: LED light slowly blinks in amber. Alienhead logo: Light fast-blinks in amber until the battery is at 0%.

## Turning on/off your headset

Press the power button on the right ear cup for one second to turn on/off the headset.



## Auto power off

When USB wireless dongle connection is lost (either the computer is turned off or the USB wireless dongle is removed from the USB port), the headset automatically turns off after 30 minutes. To turn on the headset, press and hold the power button for two seconds.


# Connecting the headset to your device

## System requirements


- One USB port for USB wireless dongle
- One USB port for charging (optional)
- Microsoft Windows 10 or Microsoft Windows 11, 64-bit
- PlayStation®/Xbox/Mobile devices with 3.5mm audio port

## Connecting the headset to your device using Bluetooth


1. Turn on the Bluetooth in your computer before connecting the headset using Bluetooth.



2. Press the power button on the right ear cup for one second to turn on the headset.



3. Press the power button on the right ear cup for three seconds to enter Bluetooth pairing mode. User will hear "Bluetooth pairing" and Power LED will fast blink in blue.




4. Connect the headset to computer, laptop, smartphone or tablet and so on.

User will hear "Bluetooth connected", then LED will light up in blue for 3 seconds then slowly blinks in blue.




## **Connecting the headset to your device using the USB wireless dongle**

1. Insert the USB wireless dongle into the USB-A to USB-C adapter, and then connect the adapter to the USB port on your computer.




2. The LED lights up blue when connected.



## **Connecting the headset to your device using the inline audio cable**

1. Connect the microphone end of the 3.5 mm inline audio cable to the port on your headset. Connect the other end of the audio cable to the headphone/headset port on your computer or mobile device.
2. Both audio and microphone functions will now be available via the 3.5mm cable. Buttons and LEDs will be disabled if the headset is turned off.
3. Audio and mic functions will automatically be routed to the 3.5mm cable regardless if the headset is powered on or off. 2.4G mode will be restored once audio cable is removed.
4. When using the 3.5mm inline audio cable, headset will be compatible with audio ports like PlayStation, Xbox and mobile phones.



 **NOTE:** Audio from the 3.5 mm inline audio cable is muted when the headset is charging.


 **NOTE:** Make sure that the audio plug closer to the inline microphone is inserted to the headset port.

# Configuring the headset on your computer

To use your headset for gaming or to listen to music from your computer, it has to be selected as the default playback device and the default recording device in


Windows Audio Settings.

1. On the taskbar, right-click the speaker icon and click **Sounds**. The **Sounds** dialog box appears.




2. Click the **Playback** tab and set the following:


- Set **AW725H Game** as the default playback device.
- Set **AW725H Chat** as the default communication device.



3. Click the **Recording** tab, set Alienware **AW725H Chat** as the default device.



4. Click the **Communications** tab, select **Do nothing**. Click **OK**.



# Alienware Command Center (AWCC)

Alienware Command Center (AWCC) provides a single interface to transform your Windows computer into an enhanced gaming environment. This application enables you to perform the following functions:

1. In the **FX** menu, you can access the following features:

- View the battery level and charging status.
- Change the lighting color and animation in the **Lighting** tab.

2. In the **Settings** tab, you can access the following settings:

- View the firmware version and upgrade the device firmware to the latest version under the **Update** tile.
- Reset the device settings to factory default.

 **NOTE: For more information, please see the AWCC application Online Help.**

## Installing AWCC

To use the AWCC features, uninstall Alienware Headset Center (AWHC) if you have already installed AWHC on your computer. You need to install AWCC to configure the features available in Alienware Wireless Gaming Headset AW725H.

Before installing AWCC on your computer, ensure that your computer is connected to internet. If your computer is preinstalled with AWCC 5.0 or later, you can configure your Alienware gaming headset through FX available in AWCC.

If your computer is not pre-installed with AWCC 5.0 or later, install AWCC through Windows Update or from the Dell Support website at <https://www.dell.com/support>. AWCC requires Windows 10 version 16299 or later and Windows 11.

## Installing AWCC through Windows Update

1. Connect your Alienware USB wireless dongle to your computer through USB port. The AWCC application is downloaded and installed automatically.
2. The AWCC installation may take up to 10 minutes to complete.
3. Go to the program folder to ensure that the AWCC installation is complete. Launch the AWCC application and perform the following steps to download additional software:
  - In the **Settings** window, click **Windows Update**.
  - Click **Check for updates** to check the Alienware driver update progress. If the driver update is not responding on your computer, install AWCC from the Dell support website.

## Installing AWCC from the Dell Support website

1. Download the latest version of the following applications at [\*\*https://www.dell.com/support/drivers\*\*](https://www.dell.com/support/drivers)
  - Alienware Command Center
  - Alienware Gaming Headset driver
2. Go to the folder where you saved the setup files.
3. Double-click the setup file and follow the on-screen instructions to install the application.



**NOTE: You can customize the headset features and lighting effects by using the AWCC application.**

# Activating Dolby Atmos for Headphones

The headset automatically activates Dolby Atmos when connected to Microsoft

Windows 10 or Microsoft Windows 11 computer by following the steps below:

1. Go to the Microsoft Store.
2. Download the free Dolby Access app.
3. Connect the headset to the computer.
4. Once connected, Dolby Access will detect your device and activate Dolby Atmos for Headphones.

## Updating the firmware

For best performance, update your headset and USB wireless dongle firmware to the latest version.

### Updating the headset firmware manually

1. Go to <http://www.dell.com/support> and search for AW725H.
2. From the **Drivers & Downloads** tab, download **AW725H Headset FW update tool**.
3. Connect your headset to your computer through the USB cable.
4. Open the downloaded **AW725H Headset FW update tool** file.
5. Click on the **Update** button. Once the firmware update is complete, the **"Update Complete! OK"** message is displayed.
6. Close the window.

**⚠ CAUTION: Disconnecting the USB cable from the computer, closing the AWCC software, or shut down of computer during firmware update may damage the headset.**

## Updating the USB wireless dongle firmware manually

1. Go to <http://www.dell.com/support> and search for AW725H.
2. From the **Drivers & Downloads** tab, download **AW725H Dongle FW update tool**.
3. Connect your dongle to your computer through.
4. Open the downloaded **AW725H Dongle FW update tool** file.
5. Click on the **Update Dongle** button. Once the firmware update is complete, the "**Update Complete! OK**" message is displayed. Close the window.


 **CAUTION:** Disconnecting the USB wireless dongle, closing the AWCC software, or shut down of computer during firmware update may damage the USB wireless dongle.

 **NOTE:** Make sure to update both Headset and Dongle Firmware.

# Using the headset

## Adjusting the headset

Adjust the headband to find your optimal fit. The elastic band can be shifted up and down for the best fit. It is also detachable. When using the microphone, position it approximately two centimeters away from your mouth.



# Using features on the headset



## Adjusting the volume

Scroll the volume control wheel to increase or decrease the volume. Scroll up for volume up, scroll down for volume down.

## Adjusting Game/Chat balance control

The volume balance of game and chat is 100% for each mode when using the headset for the first time.


- Push **up** the game chat balance button to increase **game** volume or decrease **chat** volume.
- Push **down** the game chat balance button to increase **chat** volume or decrease **game** volume.




 **NOTE: We recommend keeping game and chat device volume on Windows at 100%, and adjusting volume via the volume dial on right ear cup.**

## Muting/unmuting the microphone

When the microphone is retracted fully into the headset, the microphone will be muted and the mic mute button will be disabled. When the microphone is extended, user can mute or unmute by pressing the microphone mute button. Mic mute LED lights up red when the microphone is muted.




If the headset is connected to your device using the 3.5 mm inline audio cable, use the mute slider on audio cable to mute or unmute the microphone.



## Replacing the ear pads


To remove ear pads, hold the ear pad firmly, twist toward the back of the headset and pull straight out. Note that left and right ear pads are different. Match the arrow marks on the ear pad and the ear cup to replace the ear pad.




## Regulatory label position

The regulatory labels are on the left ear cup. Remove the ear pad to find their positions.

Left ear cup



Right ear cup



# Troubleshooting

Problems	Possible solutions
Headset has no sound	<p>Ensure that the headset is powered on, and properly connected through the wireless dongle or inline audio cable.</p> <p>Ensure that you are not using the headset with inline audio connection while charging.</p> <p>Ensure that the device/media player is not muted.</p> <p>Check the playback setting on the computer, and ensure that the default device is set to AW725H Game.</p> <p>Check the headset is within range (10 m) of the wireless dongle.</p> <p>We recommend using the headset in wireless mode when gaming on your computer.</p>
The person on the other end cannot hear me	<p>Ensure that the microphone is positioned 2 cm away to the mouth.</p> <p>Ensure the microphone is not muted by checking the mic mute LED. It should be turned off. If the headset is connected using the inline audio cable, ensure that the mute slider on the inline audio cable is not muted.</p> <p>Check the recording tab in Sounds settings, and ensure that the default device is set to AW725H Chat.</p> <p>Ensure that the headset is within range (10 m) of the wireless dongle.</p>

	If the headset is connected using the inline audio cable, ensure that the plug closer to the inline microphone is inserted to the headset port, and the other end to your device.
Abnormal sounds coming out of the headset	<p>Check if something is obstructing the headset.</p> <p>Adjust the volume level up and down, and check if the abnormal sound changes.</p>
	Ensure that the headset is within range (10 m) of the wireless dongle.
	If the headset is connected using the inline audio cable, ensure that the inline audio plug is fully inserted into the audio port of your device.
Unbalanced sound in the headset	<p>Check the computer volume balance is set correctly.</p> <ul style="list-style-type: none"><li>- Right-click on the headset icon.</li><li>- Select playback devices.</li><li>- Right-click on the default playback devices, and select <b>Properties</b>.</li><li>- Select <b>Levels</b>, and click <b>Balance</b>. Ensure that the L and R values are the same.</li></ul>
Headset lights do not light up	<p>Ensure that the headset is turned on.</p> <p>Inline cable connection won't show lighting.</p>
	Open Alienware Command Center, and ensure that the lights are turned on.
Wireless range is too short	Ensure that the wireless dongle is not covered or blocked by metal or electronic objects.
	Try connecting the wireless dongle to the USB port on the side of your computer, rather than the USB port at the back of your computer.
	Ensure that no other USB device is connected adjacent to the wireless dongle.

Microphone picks up too much background noise	Ensure that the microphone is positioned close to the mouth.  Open Alienware Command Center, and reduce the microphone volume.
Microphone mute is not working when connected with inline audio cable	Ensure that audio plugs on both ends are inserted properly into the headset and audio device ports.  Ensure that the red portion of the microphone mute button is covered.
Alienware command center does not recognize the headset	Ensure that the headset is powered on and connected to the computer via the wireless dongle.  Reconnect the wireless dongle or restart Alienware Command Center.

# Specifications

Specifications	Value
Headset weight	348 g
Headset dimensions	Length: 183.91 mm (7.24 inches) Width: 111.67 mm (4.40 inches) Height: 214.39 mm (8.44 inches)
Microphones	Noise Reduction microphone
Speaker	40 mm Dynamic PureSound speaker (Hi-Fi)
Speaker maximum input power	50 mW
Speaker frequency range	20Hz to 40kHz
Operating temperature	5°C to 40°C (41°F to 104°F)
Storage temperature	-5°C to 45°C (23°F to 113°F)
Operating humidity	5% to 90% relative humidity

# **Warranty information**

## **Limited warranty and return policies**

The Alienware Dual Mode Wireless Gaming Headset AW725H carries a 2-years limited hardware warranty. If purchased together with a Dell computer, it will follow the system warranty.

### **For U.S. customers:**

This purchase and your use of this product are subject to Dell's end user agreement, which you can find at <https://www.dell.com/terms>. This document contains a binding arbitration clause.

### **For European, Middle Eastern and African customers:**

Dell-branded products that are sold and used are subject to applicable national consumer legal rights, the terms of any retailer sale agreement that you have entered into (which will apply between you and the retailer) and Dell's end user contract terms.

Dell may also provide an additional hardware warranty – full details of the Dell end user contract and warranty terms can be found by going to <https://www.dell.com>, select your country from the list at the bottom of the "home" page, and then click the "terms and conditions" link for the end user terms or the "support" link for the warranty terms.

### **For non-U.S. customers:**

Dell-branded products that are sold and used are subject to applicable national consumer legal rights, the terms of any retailer sale agreement that you have entered into (which will apply between you and the retailer) and Dell's warranty terms. Dell may also provide an additional hardware warranty – full details of Dell's warranty terms can be found by going to:

<https://www.dell.com/terms>, select your country from the list at the bottom of the "home" page, and then click the "terms and conditions" link or the "support" link for the warranty terms.

## **Safety information**

 Keep the volume at optimal levels while in use. Do not listen at high volume levels for a long period. Prolonged exposure to a high volume may cause a high sound pressure and may cause a risk of hearing damage.

### **Federal Communication Commission Interference Statement:**

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Any changes or modifications not expressly approved by the party responsible for compliance could void your authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

### **RF exposure statements:**

This product is based on SAR assessment and the user manual must have the following warnings "This device meets the government's requirements for exposure to radio waves. This device is designed and manufactured not to exceed the emission limits for exposure to radio frequency (RF) energy set by the Federal Communications Commission of the U.S. Government. The exposure standard employs a unit of measurement known as the Specific Absorption Rate, or SAR. The SAR limit set by the FCC is 1.6 W/kg. Tests for SAR are conducted using standard operating positions accepted by the FCC with the EUT transmitting at the specified power level in different channels. The FCC has granted an Equipment Authorization for this device with all reported SAR levels evaluated as in compliance with the FCC RF exposure guidelines. SAR information on this device is on file with the FCC and can be found under the Display Grant section of [www.fcc.gov/oet/ea/fccid](http://www.fcc.gov/oet/ea/fccid)."

**Industry Canada statement:**

This device complies with Industry Canada license-exempt RSSs. Operation is subject to the following two conditions:

- 1) This device may not cause interference, and
- 2) This device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

- 1) l'appareil ne doit pas produire de brouillage;
- 2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

**Radiation Exposure Statement:**

This EUT is compliance with SAR for general population/uncontrolled exposure limits in IC RSS-102 and had been tested in accordance with the measurement methods and procedures specified in IEEE 1528 and IEC 62209.

This device and its antenna(s) must not be co-located or operating in conjunction with any other antenna or transmitter.

Cet appareil est conforme aux limites d'exposition DAS incontrôlée pour la population générale de la norme CNR-102 d'Industrie Canada et a été testé en conformité avec les méthodes de mesure et procédures spécifiées dans IEEE 1528 et IEC 62209.

取得審驗證明之低功率射頻器材，非經核准，公司、商號或使用者均不得擅自變更頻率、加大功率或變更原設計之特性及功能。低功率射頻器材之使用不得影響飛航安全及干擾合法通信；經發現有干擾現象時，應立即停用，並改善至無干擾時方得繼續使用。前述合法通信，指依電信管理法規定作業之無線電通信。低功率射頻器材須忍受合法通信或工業、科學及醫療用電波輻射性電機設備之干擾。