

www.anran-cctv.com
support@anran-cctv.com
1-866-958-6988 (US)
44-20 8610 1559 (UK)

Scan the QR code above to extend your warranty

Warranty Tips

Please fill in the following information or scan QR code to activate the free 12-month warranty from the order date on.

After finish filling or scanning, please take a picture and send it to the email (support@anran-cctv.com). Then your free warranty will take effect!

During the warranty period, if any parts of product are damaged, please contact us immediately and we will provide satisfactory resolution.

Order Date: _____

Order Number/ID: _____

Buyer E-mail: _____

Buyer Tel: _____

Contact us

www.anran-cctv.com
support@anran-cctv.com
1-866-958-6988 (US)
44-20 8610 1559 (UK)

Scan the QR code above to extend your warranty

4. PIR Motion Detection Settings

Enter the application - "Parameter Setting" - "Motion Detection" interface.

Sensitivity	Detecting Distance (For moving objects)
Level 1-3 (Low)	Up to 4-5 meters
Level 4-7 (Med)	Up to 5-8 meters
Level 8-10 (High)	Up to 8-13 meters


Warm Tips:

- When you encounter the missed or delayed alarm frequently in using this camera, you can adjust the motion detection sensitivity to solve them.
- If you notice the poor performance of motion detection in the night environment, try to turn off "Night Detection".

5. Product Specification

Resolution	2MP/3MP/5MP @ 12-15fps
Storage	TF Card (max. 128GB), Cloud Storage
Wi-Fi	Only 2.4GHz

1. Product Introduction



CAUTION: Please insert the Micro SD Card according to the direction shown in the diagram. Micro SD Card might JAM if inserted incorrectly and device could be damaged.

SD Card Port: Support micro SD card for local storage (Max 128GB). Reset button: Used to restore the camera to factory settings (Press and hold on 5-8s). Card capacity requirements: 8-128GB. Read and write speed requirements: class10 level. File format: FAT32.

1

2. APP Installation and Account Registration

2.1 Download "ANRAN" APP

Method 1: Download "ANRAN" APP from APP Store (iOS) or Play Store (Android);
Method 2: Scan "ANRAN" APP QR code to download it.



Tips: Please turn on 2 permissions below when use this APP at the first time.
1. Allow "ANRAN" APP to access mobile cellular data and wireless LAN, or it will be failed to add IP camera.
2. Allow "ANRAN" APP to receive pushed message, or the cellphone will not receive alarm push when motion detection or audible alarm is triggered.


2

3.1 Power on Camera

- Please long press the power button for 5s to power the camera.
- The indicator with red light blinking slowly means the camera is started successfully.

3.2 Connect the Camera

Put the camera and smart phone 1 to 3 feet (30 to 100 cm) away from the router to set Wi-Fi.




3.3 How to Add Camera to APP

Warning Tip: Please insert the Micro SD card before power on, otherwise, the SD card can not be detected.

3

Wi-Fi Connection Steps:



6

6. FAQs

1) The device prompts offline?

- Check whether the equipment is in the power-on state, and observe whether the working light of the equipment is on normally.
- Check whether the Wi-Fi network is in good condition and restart the router.
- If the device is located far away from the router, which results in the inability to obtain a good Wi-Fi signal, it is recommended to move the router to a closer place or add a Wi-Fi amplifier to improve the Wi-Fi performance of the home.
- Delete the camera from your ANRAN account and add it again after resetting the device.
- Check whether the device firmware and application program are the latest version.

2) Update router or Wi-Fi password?

Delete the camera from your ANRAN account. After resetting the device, use the new Wi-Fi and password to add it again.

3) Can't play historical video?

- Check the status of the SD card in "Settings" to ensure that the SD card has been successfully recognized.
- Reinsert the SD card.
- In the application, format the SD card.
- Try another new SD card

4) Why doesn't the device identify the SD card?

- Please insert the Micro SD card before power on.
- It is recommended to use San Disk, Samsung and other brand cards;
- It is recommended to use a standard class 10 TF card;
- Only FAT32 format is supported.
- TF card can't be identified when the internet environment is not good.

5) Why the battery life of my device is poor?

- Please check whether the number of alarms is too frequent. Because the working time of the device determines the battery life. The more frequent PIR wake-ups, the faster the battery consume due to the longer working time. It is recommended to appropriately lower the motion detection sensitivity of the device and set the alarm interval and alarm time plan. (Note: Outdoor air conditioning units, moving cars and the passing pedestrians will cause frequent alarms. Please adjust the angle of the device to avoid these objects.)

- In cold weather, the battery capacity will be reduced, which will affect the endurance of the device.
- The device has a low temperature charging protection module, please don't charge the device at low temperatures.

6) The phone cannot receive the alarm push?

- Turn on all the push permissions of the "ANRAN" app.

application in the system settings of your mobile phone.

- Make sure that the device's motion detection function is successfully turned on.
- Restart the phone, and clear the cache on Android phones.
- Check whether the network is good.

7) How to judge whether the charging is successful?

The device's charging indicator light is red, which means it is charging. A blue light means that charging is complete. It will take approximately 10 hours or more to fully charge.

8) What should I do if the charge fails?

- Determine whether the power adapter is good, try another one.
- Determine whether the Type-C charging cable is good, try another one.
- The charging indicator may be defective, please check the charging condition in the phone APP.
- Determine whether the charging port of the device is not in good contact with the Type-C charging cable.
- The device has a low temperature charging protection module, please don't charge the device at low temperatures.

FCC Warning Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules.

Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

RF Exposure Statement

To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum distance of 20cm the radiator your body. This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter.

www.anran-cctv.com
support@anran-cctv.com
1-866-958-6988 (US)
44-20 8610 1559 (UK)



Scan the QR code above to extend your warranty

7

8

9

10

11