

# eHub

## Sentrics

### User's Guide

## Contents

1. Safety Information, *P4-5*
  - 1.1 Warning, *P4*
  - 1.2 Precautions, *P4-5*
  - 1.3 Handling Cautions, *P5*
2. Introduction, *P6-9*
  - 2.1 Package Contents, *P6*
  - 2.2 Product Features, *P6*
  - 2.3 Panel Introduction, *P7*
  - 2.4 Remote Controller, *P8*
  - 2.5 Setup Connection, *P8*
  - 2.6 Display when Power Up, *P9*
3. Settings, *P9-24*
  - 3.1 WiFi, *P10*
  - 3.2 Bluetooth, *P11*
  - 3.3 Ethernet, *P12*
  - 3.4 Data Saver, *P12*
  - 3.5 Networks & internet, *P13*
  - 3.6 Multiple users, *P13*
  - 3.7 Sound, *P14*
  - 3.8 Display, *P14-16*
  - 3.9 Storage, *P17*
  - 3.10 Apps&notifications, *P17*
  - 3.11 Google services, *P18*
  - 3.12 Notification, *P18*
  - 3.13 Location, *P19*

- 3.14 Security, *P19*
- 3.15 Languages & input, *P20*
- 3.16 Reset options, *P20*
- 3.17 Sleep, *P21*
- 3.18 Add an account, *P21*
- 3.19 Date & Time, *P22*
- 3.20 Choose wallpaper from, *P22*
- 3.21 Screen saver, *P23*
- 3.22 About device, *P23*
- 3.23 Camera settings, *P24*
- 3.24 HDMI, *P24*
- 3.25 IR blaster& RS232 mode *P25*

- 4. Apps Install & Uninstall, *P25*
- 5. Firmware Update, *P26*
- 6. Trouble Shooting/FAQ, *P26*
- 7. Repairs, *P26*
- 8. Specification, *P26-27*
- 9. Trademark Notice, *P28*

## 1. Safety Information

Read and understand all instructions before using this product. If damage is caused by failure to follow the instructions, the warranty does not apply.

### 1.1 Warning

To reduce the risk of electric shock, DO NOT remove the cover (or back). DO NOT attempt to repair the product, this could lead to the risk of injury, damage to the product.

To reduce the risk of fire or electric shock, keep this product away from exposed direct sunlight, naked flames or heat, large amounts of moisture, dust, and sand.

#### FCC Note (for U.S.A)

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on.

The user is encouraged to try to correct the interference by one or more of the following measures.

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Consult the dealer or an experienced radio/TV technician for help.
- This class B digital product meets all requirements of the Canadian Interference - Causing Equipment Regulations.

### 1.2 Precautions

#### Important Safety Instructions

Read these operating instructions carefully before using the unit. Follow all the safety instructions listed below.

Keep these operating instructions handy for future reference.

1.2.1 Read these instructions.

1.2.2 Keep these instructions.

1.2.3 Heed all warnings.

1.2.4 Follow all instructions.

1.2.5 DO NOT use this apparatus near water.

1.2.6 DO NOT clean with any chemical detergent. Clean only with a dry cloth.

1.2.7 DO NOT block any ventilation openings. Install in accordance with the manufacturer's instructions.

1.2.8 DO NOT install near any heat sources such as radiators, heat registers, stoves, or other apparatus that produce heat.

1.2.9 Protect the power cord from being walked on or pinched particularly at plugs,

convenience receptacles, and the point where it exits the apparatus.

1.2.10 Only use attachments/accessories specified by the manufacturer.

1.2.11 Use only with the cart, stand, tripod, bracket, or table specified by the manufacturer, or sold with the apparatus. When a cart is used, use caution when moving the cart/apparatus combination to avoid injury from tip-over.

1.2.12 Unplug this apparatus during lightning storms or when unused for long period of time.

1.2.13 Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as when the power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.

### **1.3 Handling Cautions**

1.3.1 DO NOT expose this apparatus to dripping or splashing. Do not put objects filled with liquids, such as vases on the apparatus.

1.3.2 To turn this apparatus off completely, you must pull the power plug out of the wall socket. Consequently, the power plug must be easily and readily accessible at all times.

1.3.3 DO NOT plug multiple electric devices into the same wall socket. Overloading a socket can cause it to overheat, resulting in a fire.

1.3.4 Before connecting other components to this player, be sure to turn them off.

1.3.5 If the product makes an abnormal noise or produces a burning smell or smoke, turn off the power switch immediately and disconnect the power plug from the wall outlet. Then, contact the nearest customer service center for technical assistance. Do not use the product. Using the product as it is may cause a fire or an electric shock.

## 2. Introduction

### 2.1 Package Contents

RK3566 Commercial Display player – eHub  
User's Guide  
HDMI Cable  
Fiber Optical Cable, RJ45 Network Cable  
IR Remote Controller (IR RC)  
Optional Remote Controller  
Power Adapter, Input: AC100 ~ 240V, 50/60Hz, Output:12.0V-2A

### 2.2 Product Features

(I) Rockchip RK3566 Quad-core Cortex-A55, build-in NPU up to 1TOPs, and with GPU Mali-G52-2EE

- ARM Mali-G52-2EE GPU support OpenGL ES1.1/2.0/3.0, OpenCL1.2, DirectX11.1 etc.
- Support 2GB/4GB LPDDR4, 8G~128GB eMMC flash, external expansion storage TF card (Max 512G)
- Built-in Tuner Module, support ATSC1.0, Android OS 11
- Built-in WiFi(2.4G/5.8G) /BT (4.2 / 5.0 Optional)
- 10/100/1000M LAN interface
- 2 \* USB Type-A (USB2.0+USB3.0),
- 1 \* HDMI Out, support 4K video play
- WatchDog
- App Installer for application installation from USB/TF card


### 2.3 Panel Introduction

## 2.6 Display when Power Up

2.6.1 After booting up, during the loading process, the TV will first display the "Android" interface, and then there will be a booting animation of "Enjoy TV". When the load is complete, it will go to the home screen.




### 2.6.2 Home Screen display.



## 3. Settings

Using Navigation (4 directions), OK, EXIT, and Menu keys of Remote Controller to select the options, the option selected will be highlighted and confirmed by pressing OK key. Same operation for text input if needed.

Select  icon then press OK key.




### 3.1 WiFi

3.1.1 It will automatically scan ambient WiFi networks when select “ON”.

Connect an available WiFi network. If connect a secured WiFi network, corresponding password will be input firstly. Or fail to connect and need reset password. Once build up the connection with a certain WiFi network successfully, eHub will connect this WiFi network automatically when restart.

Note: If factory reset, the password of WiFi network have to be reset.




### 3.1.2 Wi-Fi hotspot

If you want to share WIFI with your friends, you can set the wi-fi hotspot here, set the wi-fi password, and turn on the hostpot switch for transmission.



## 3.2 Bluetooth




### 3.3 Ethernet



### 3.4 Data Saver

Data Saver prevents some apps from sending or receiving data in the background




## 3.5 Networks & internet



## 3.6 Multiple users

You can add user or configuration here



## 3.7 Sound

### 3.7.1 Volumes


Increase or decrease sound volumes

### 3.7.2 Touch Sounds

If enable Touch sound, sound will be heard while move remote controller.

### 3.7.3 Sound Input Devices

### 3.7.4 Sound Output Devices



## 3.8 Display


### 3.8.1 Display size

make the items on your screen smaller or larger. Some apps on your screen may change position.




### 3.8.2 Font size

Change the font size of OSD., Make the text on screen smaller or larger




### 3.8.3 Cast screen



### 3.8.4 Screenshot

Here you can set the screen shot time and select the image location




## 3.9 Storage

Shows the storage used of the OS and SD card.




## 3.10 Apps & notifications

List all apps installed.




You can choose an application and force to shut down the app, uninstall the app, clear user data, move to SD card and clear cache data.


### 3.11 Google services




### 3.12 Notification



## 3.13 Location



## 3.14 Security



### 3.15 Languages & input




Change OSD language and input method.

The default input method is android standard keyboard.

If you are using our IR remote control, enter into “Default” option and switch to remote controller input method.

### 3.16 Reset options




Factory data rest:

You can reset all the settings and apps to factory default.


Note: You might want to backup important data before resetting the box. Once you choose to rest to factory default, all data/apps will be deleted.

### 3.17 Sleep

Find the display button and find Sleep. You can select the Sleep time of the product. There are 8 options for sleep time. The shortest is 'Never' and the longest is 30 minutes.



### 3.18 Add an account




### 3.19 Date & time




### 3.20 Choose wallpaper from

Users can choose wallpaper photos from albums and historical wallpapers according to their preferences.




### 3.21 Screen saver


Interface Settings: can set the clock, color, theme, page photos.



### 3.22 About device.




### 3.23 Camera settings



### 3.24 HDMI

User can set the screen, display resolution, zoom in/out screen, rotate screen, dual screen display in this part.



## 4. Apps Install & Uninstall

On eHub, you can install apps from Android Market over the Internet or other sources, such as other online sources, the internal storage and the USB storage device and SD card that you have mounted onto eHub.

You also can manage apps oneHub and SD card, install/uninstall apps, stop running apps, or select other options.

## 5. Firmware Update

You can download newest firmware from Geniatech Official website:

[www.geniatech.com](http://www.geniatech.com)

## 6. Trouble Shooting/FAQ

### 6.1 No Picture

Refer to the TV user manual for how to select the correct video input channel.

### 6.2 USB Content cannot be read

- . The format of USB storage device is not supported
- . The supported memory size is 32G maximum.
- . Make sure that this player supports these files.

### 6.3 Remote Controller cannot respond quickly to the pressing of keys

Make sure that batteries have enough power.

### 6.4 The firmware updating is not complete after a long time

If you update the firmware over the online service, it may take a long time to download the firmware update files from the server. To save your time, update the firmware through the SD card.

## 7. Repairs

If you contact us to repair your player, an administration fee may be charged if either:

An engineer is called out to your home at your request and there is no defect in the product.

You bring the unit to a repair center and there is no defect in the product.

We will provide you with the amount of the administration fee before we make a

home visit or begin any work on your player.

We recommend you read this manual thoroughly, search for a solution on line at [www.geniatech.com](http://www.geniatech.com), or contact Geniatech Customer Care before seeking to repair your player.

## 8. Specification

CPU	Quad-core Cortex-A55, build-in NPU up to 1TOPs GPU Mali-G52-2EE
GPU	support OpenGL ES1.1/2.0/3.0,OpenCL1.2,DirectX11.1 etc.
RAM	2G LPDDR4(4GB Optional)
ROM	16G eMMC(8~128GB Optional)
OS	Android 11
USB	1*USB2.0+1*USB3.0
HDMI	1*HDMI OUT
DC Input	12.0V-2A
MicroSD Slot	Max: 512G
Video Output	HDMI
RF	Support ATSC
LAN	RJ45 10/100/1000M Ethernet interface
WiFi	IEEE 802.11 AC 2.4G & 5.8G(optional)
BT	5.0
Video Decoder	Real-time video decoder of MPEG-1, MPEG-2, MPEG-4, H.263, H.264, H.265, VC-1, VP9, VP8, MVC Error detection and concealment support for all video formats H.265/HEVC, Main/Main10 profile @ level 5.1 High-tier; up to 4Kx2K @ 60fps H.264/AVC, Base/Main/High/High10 profile @ level 5.1; up to 4Kx2K @ 30fps MPEG-4, ISO/IEC 14496-2, SP@L0-3, ASP@L0-5, up to 1080P @ 60fps MPEG-2, ISO/IEC 13818-2, SP@ML, MP@HL, up to 1080P @ 60fps MPEG-1, ISO/IEC 11172-2, up to 1080P @ 60fps VC-1, SP@ML, MP@HL, AP@L0-3, up to 1080P @ 60fps MVC is supported based on H.264 or H.265, up to 1080P @ 60fps
JPEG Decoder	Input JPEG file: YCbCr 4:0:0, 4:2:0, 4:2:2, 4:4:0, 4:1:1 and 4:4:4 sampling formats Output raw image: YCbCr 4:0:0, 4:2:0, 4:2:2, 4:4:0, 4:1:1 and 4:4:4 semi-planar Decoder size is from 48x48 to 8176x8176(66.8Mpixels) Support JPEG ROI (region of image) decode Maximum data rate④ is up to 76million pixels per second Embedded memory management unit(MMU)
Size	136x136x35mm(Does not include external interface)

Net Weight	410g
Power Adapter	AC100 ~ 240V 50/60Hz
IR Remote	
Controller	Optional

## 9. Trademark Notice



The terms HDMI and HDMI High-Definition Multimedia Interface, and the HDMI Logo are trademarks or registered trademarks of HDMI Licensing LLC in United States and other countries.

## FCC Information and Copyright

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1)This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment .This equipment should be installed and operated with minimum distance 20cm between the radiator& your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.