

Hansker Mouse – connection instruction manual

Connecting via Bluetooth

To connect the Hansker mouse via Bluetooth, follow the next steps:

1. On Windows or Mac, open the Bluetooth settings and choose “Add a new Bluetooth device”.
2. In your Hansker Mouse, switch the connection mode to Bluetooth, by dragging the switch at the bottom of the mouse to the Bluetooth icon (which you can find to the left side of the middle icon).
3. Press and hold the left, right and middle click buttons at the same time for 2-3 seconds.
4. The top light indicator will start blinking slowly.
5. In your computer settings, a new device should have appeared, called “Hansker Perf” or “Hansker Pro”. Click on “Connect”.
6. Your Hansker Mouse should now be connected successfully to your computer. Enjoy!

Connecting with the included USB dongle

1. Connect the included USB dongle to a USB port in your computer.
2. Depending on the operative system, you might get a pop-up asking for permission to enable the USB dongle to connect to your computer. Click accept.
3. In your Hansker Mouse, switch the connection mode to USB receiver by dragging the switch at the bottom of the mouse to the wi-fi icon (which is the most-right icon).
4. Your Hansker Mouse should now be connected successfully to your computer. Enjoy!

Connecting by cable

1. In your Hansker Mouse, switch the connection mode to wired by dragging the switch at the bottom of the mouse to the cable icon (which is the middle icon).

2. Connect the USB-C to USB-C cable included in your Hansker package to the computer and mouse, at the front-bottom of the mouse.
3. Depending on the operative system, you might get a pop-up asking for permission to enable the USB dongle to connect to your computer. Click accept.
4. Your Hansker Mouse should now be connected successfully to your computer. Enjoy!*

*Bear in mind that while connected via cable, the mouse battery will be charging and might get warm at the bottom area, especially in warm climates or during hot days. This is normal and will go back to a normal temperature once you disconnect it from the power supply.

How to turn off the Hansker Mouse

The Hansker Mouse goes into sleep mode automatically after a couple of minutes not using it. You will notice that the top light indicator turns off when it's in sleep mode. It will wake up as soon as you move it or press any of the buttons.

If you want to completely turn it off, you just need to switch the connection mode to wired (middle icon at the bottom of the mouse) while there is no USB-C cable connected to it. This will turn off the mouse completely.

FCC COMPLIANCE STATEMENT:

This device complies with part 15 of the FCC Rules.

Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC Radiation Exposure Statement

The device has been evaluated to meet general RF exposure requirement.

The device can be used in portable exposure condition without restriction.