

MOG3305 Wireless Optical mouse user's manual

Mouse Button Functions

- 1 Mouse Left Button
- 2 Mouse Right Button
- 3 Scroll Wheel / Mouse Middle Button
- 4 Battery Low Indicator

System Requirements

Available USB port Microsoft® Windows® 98SE, Windows® ME, Windows® 2000, Windows® XP or Windows

Vista™ operating system CD-ROM drive (for CD or Video operation) Standard sound card (for CD or Video operation) Microsoft Office 97 or later version

Hardware Installation

- 1 The receiver is stored inside the mouse. Take out the receiver by pushing down the release button behind the scroll wheel.
- 2 Plug the receiver into the USB port on the PC. (Please refer to the mouse drawing picture B)
- 3 Open the battery cover by pushing down the release button on the backward edge of the mouse.
- 4 Insert batteries into the slots and ensure that you orient the (+) positive end towards outside.
- 5 Please make sure the power switch on the bottom of the mouse is switched to "on" before using the mouse. When not in use, you can either slide the power switch to "off" or store the receiver inside the mouse to turn the power off

Note: Ensure that you place the side with a LED indicator on top face-up when sliding the receiver back into the storage slot.

Pairing Procedure

The wireless mouse can operate out of the box immediately after you plug the receiver into your PC USB port. If it can't work, please follow the steps below to process ID setting of the wireless mouse. The LED on the top of the receiver shows the pairing or data reception status. The ID-recognition function helps protect against interference from other RF products in the same environment.

Remember to reset ID when other RF products affect your mouse.

- 1 Press the pairing button on the bottom of the mouse once.
- 2 The receiver LED will flash rapidly to indicate it has received pairing information.
- 3 When you move the mouse, the receiver LED will flash steadily. When you stop using the mouse, the receiver LED will stop flashing.

Usage Information

- 1 The mouse can work only on a clean, flat, and non-slippery surface in order to ensure smooth and accurate cursor action.
- 2 This optical mouse senses light to detect mouse's movement. When it works on the glass, translucent, reflective, or dark-colored surface, the mouse movement may be affected sometimes.

Battery Information

- 1 We recommend using alkaline batteries for a longer battery life.
- 2 Don't mix different types of batteries or new and old batteries together. Always replace old batteries with new and same type batteries.
- 3 Remove batteries after long periods of non-use. Battery leakage or corrosion may damage the device quality and cause danger.
- 4 Battery low Alarm:
 - When the mouse battery is low, the RED LED indicator behind mouse scroll wheel will blink when the mouse is moved. Please change batteries immediately when the RED LED indicator lights up to ensure the good use of this mouse. After you change the batteries, the RED LED indicator will disappear.

FCC Guidelines

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna. Increase the separation between the equipment and receiver. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or an experienced radio/TV technician for help. Use only shielded cables to connect I/O devices to this equipment.

FCC Warning: This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, (2) this device must accept any interference received, including interference that may cause undesired operation.

Information to user: The user's manual or instruction manual for an intentional or unintentional radiator shall caution the user that changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment. Shielded interface cable, if any, must be used in order to comply with emission limits.