
## **WIRELESS LEATHER MOUSE MANUAL**



#### INTRODUCTION

This leather wireless mouse is a fashionable design that combines leather with chrome. It is a newly developed wireless 2.4GHz RF mouse including both Remote (Mouse) and Dongle (Receiver). Utilizing USB charging technology this mouse can be completely recharged simply by connecting it to USB port on your computer.

#### **FEATURES**

- 1.3D optical mouse with 1000 dpi resolution
- 2.2.4GHz radio frequency wireless transmission
- 3. Battery recharge function via USB cable
- 4. Low battery power indicator
- 5. Auto switch on / off function
- 6. Smart power management

#### SPECIFICATIONS

- Interface: USB 2.0
- Sensor report rate on mouse: 3000 frame/sec
- Operation angle: 360 degree
- Operation distance: 8~12m away from receiver
- Frequency: 2.4GHz
- . ID number: 256 random ID per channel
- Sensor resolution: 1000 DPI
- Operation temperature: -5 to 40 degree
- Operation humidity: 20% 90% RH
- Operation current: 15mA
- Operation system: Windows 98 / 98SE / 2000 / ME / XP / Vista Mac OS 9 or higher
- Product size: 98 X 59 X 22mm


#### **BATTERY RECHARGE INSTRUCTION:**

- The battery needs to be recharged when the battery power indicator turns red.
- Always use rechargeable batteries only! The charge unit could not be charged with alkaline batteries and it could cause damage to the mouse and set off super heat, fire and explosion.
- 3. This device requires AAA rechargeable batteries ( 2 pcs ) for recharge.
- Dispose the batteries in accordance with local regulations.
- 5. Replace old and weak batteries promptly.
- 6. As long as the recharge cable is connected to the computer, the mouse still can be used even though the battery is not enough or without any batteries inside the battery compartment.

#### **BATTERY CONSUMPTION & ELECTRICAL PROPERTIES:**

- Operating mode: 15mA / 2.4V~3.0V
- Sleep mode: 20uA / 2.4V~3.0V / (Note: the mouse will switch to power saving mode if not working over 3 second; and powered off automatically if not working over 5 minutes)
- Low battery indicator: 2.2V
- Battery type: AAA 1.2V 800mAh NIMH rechargeable battery X 2 pcs
- Working current: 15mA
  Stand by current: 2mA
- Recharging current: 200~400mA
- · Continuous working hrs: approx: 60 hrs
- Battery life: under average usage, 3-4 hrs per day, the batteries should last approx. 2 weeks
- Normal battery charging time: Full power / 3hrs at 5V
- Receiver power requirement: 5V

#### ILLUSTRATIONS



Receiver installation

Battery install at on

Charging cable connection

# **⚠** CAUTIONS

- Always use rechargeable batteries only when recharging your mouse
- Observe polarity and the direction of battery as it may cause explosion
- Stop using the mouse immediately when battery compartment encounters an overheat problem

- 1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
  - (1) This device may not cause harmful interference, and
  - (2) This device must accept any interference received, including interference that may cause undesired operation.
- 2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

### Federal Communications Commission (FCC) Statement

This equipment has been tested. And it found to comply with the limits for a Class B digital device pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates and uses and radiates radio frequency energy and, if not installed and used in accordance with the instruction, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
- Consult the dealer or an experienced radio /TV technician for help.

Warning: A shielded-type power cord is required in order to meet FCC emission limits and also to prevent interference to the nearby radio and television reception. It is essential that only the supplied power cord be used.

NOTE: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.