Appearance

Tilt the camera lens up to find the RESET button and the microSD card slot.

RESET Button

While the camera is powered on, press and hold the RESET button to reset the camera.

• Press and hold for 5 seconds: Reset Wi-Fi settings only
• Press and hold for 10 seconds: Reset to factory settings

microSD Card Slot

Insert a microSD card (not included) and initialize it on the Tapo app for local recording.

Lens

D Micro SD   RESET

microSD

For technical support, the user guide, warranty, and more information, please visit **www.tapo.com/support/**

tp-link | tapo

Quick Start Guide

Pan/Tilt AI Home Security
Wi-Fi Camera

▶ **Setup Video**
Scan QR code or visit
https://www.tp-link.com/support/
setup-video/#cloud-cameras

CE UK CA EAC [TP]BY

7100001615 REV1.3.0   *Images may differ from actual products.

DOWNLOAD APP

Get the **Tapo** app from the App Store or Google Play, and log in.

[Download on the App Store] [GET IT ON Google Play]

Scan to download

POWER UP

Plug in your camera and wait until the LED blinks red and green.

SET UP

Tap the ⊕ button in the app and select your model. Follow app instructions to complete setup.

LED Indication

Solid red	Starting up
Blinking red and green	Ready for setup
Blinking red slowly	Connecting to Wi-Fi
Solid amber	Connected to Wi-Fi
Solid green	Connected to the cloud
Blinking red quickly	Camera resetting
Blinking green quickly	Camera updating

Mounting Kit

Camera Base   Camera   Mounting Template Sticker

Screws   Anchors (for wall mounting)

Mounting Instructions

1. Mark Position

Place the mounting template sticker where you want the camera. For wall mounting, drill two holes through two circles.

Φ=6 mm (15/64 in.)

2. Mount Base

Affix the camera base using the screws.
For wall mounting, insert two anchors into the holes and use the screws to affix the camera base over the anchors.

3. Secure Camera

Attach the camera on the base and rotate to secure the camera.