MVTAG

物品定位器
快速入门指南

入门指南 01

1. 电源开/关:
   - 按下物品定位器的功能按钮一次即可开机，会有开机提示音
   - 要关闭电源，按住同一个按钮至少三秒钟，你会听到两声哔哔声，表示你的物品定位器已关机
2. 检查更新:
   - 若要使用 Apple Find My app 来定位您的项目定位器，建议使用最新版本的 iOS、iPadOS 或 macOS。



添加您的物品定位器 02

1. 启动应用程序
   - 在您支持的 iPhone 上打开“查找我的应用程序”或者 iPad
   允许来自应用程序的通知

2. 连接您的物品定位器
   - 打开物品定位器的电源
   -在“查找我的应用”中，选择“项目”选项卡
   - 点击“添加项目”，然后点击“其他支持的项目”
   - 找到物品定位器后，点击“连接”
   - 为你的物品定位器选择一个可识别的名称和表情符号，然后点击“继续”
   - “查找我的”会要求确认将你的物品定位器添加到你的 Apple ID，点击“继续”
   - 点击“完成”，您的物品定位器将被设置好，并准备好连接到您想要定位的任何物品，例如您的钥匙

找到你的物品 03

1. 在附近时查找物品定位器
   -打开“查找app ”，选择“物品”选项卡
   - 滚动直至查找项目列表
   -点击“播放声音”，你的物品定位器发出哔哔声（播放声音需在手机蓝牙范围内）
   - 轻按“停止播放”，一旦找到您的项目，就会停止蜂鸣声

2. 查找物品定位器的最后已知位置
   打开“查找”并选择“物品”选项

- 点击你的物 品 栏 中 选 中 一 个 想 要 查 看 位 置 的 物 品
  - 你的物品定位器的最后已知位置将作为你在设置时选择的表情符号出现在地图上
  -要导航到最后一个已知位置，点击“方向”打开“地图”应用程序

超出范围时查找项目 04

1. 启用“寻找时通知”
   - 打开“查找app”并选择“物品”标签
   - 点击列表中的物品定位器
   - 启用“通知”，启用“遗落提醒”功能
   - 当你把你的物品定位器放在 某个设置的范围，并且它不在你的设备范围内时，你会收到一个通知

2. 启用“找到时通知”
   - 在“通知”下，启用“找到时通知”按钮

- 当您的物品定位器被另一个启用了“查找我的”功能的设备看到时，您将收到关更新位置的通知

-注意：“找到时通知”只能在您的物品定位器超出范围时激活

当你的物品丢失时 05

启用“丢失模式”
- 打开“查找我的应用程序”并选择“项目”选项卡
- 点击列表中的物品定位器
- 在“丢失模式”下，点击“启用”
- 将弹出一个详细描述丢失模式的屏幕，点击“继续”
- 输入您的电话号码或电子邮件地址，然后点击“下一步”
- 您可以输入将与共享的消息找到你的物品的人
- 点击“打开”以启用“丢失模式”
-注意：启用“丢失模式”时，“找到时通知”会自动启用
-注意：启用“丢失模式”后，您的物品定位器将被锁定，无法与新设备配对

重置物品定位器 06

从“查找我的应用程序”中移除物品定位器
- 打开“查找我的应用程序”并选择“项目”选项卡
- 点击列表中的物品定位器
- 请确保禁用“丢失模式”
- 滚动到屏幕底部，点击“删除项目”
- 将打开一个确认，点击“删除”进行确认

1. 重置您的物品定位器：

- 从“查找我的应用程序”中成功移除物品定位器后，快速按下物品定位器的功能按钮四次，每次按下时都会听到一声蜂鸣声，然后按住第五次，直到听到一声蜂鸣声
- 物品定位器现已重置，并准备好与新设备配对

等等. . . 还有更多 07

1. 更换电池:
   - 通常指 用指甲抠侧面的小缝隙划开
   - 将定位器外壳小心翼翼地打开
   - 用新的 CR2032 电池更换电池，使其正极朝上

（文字面朝上）

- 通过对齐两侧的照部孔，小心关闭物品定位器的盖子。

2. 跟踪提醒

当一个未知的定位器和你一起旅行它会给你发通知。将开始播放声音，以便您能够找到它。只有当物品定位器没有连接到其所有者的手机时，这些警报才会被激活，因此，如果你的伙伴与你在一起，他们的物品定位器不会触发声音。

细则 08

该设备符合FCC规则的第15部分。操作受以下两个条件的限制：

(1)本设备不会造成有害干扰，以及(2)本设备必须接受任何被收到的干扰，包括可能导致不良操作的干扰。注:制造商对未经授权对本设备进行改装或更改而导致的任何无线电或电视干扰概不负责。未经负责合规的一方明确批准的此类修改或变更可能会使用户操作本设备的权限失效。该设备已被评估为满足一般照明基础要求。该设备可以在便携式暴露条件下使用，没有限制。
斯托迪尼奥奥公司FCC辐射暴露声明均步非常底板。因此不需要计算射频幂器。

细则 09

根据FCC规则第15部分，该设备已经过测试，符合B类数字设备的限制。这些限制旨在为住宅安装中的有害干扰提供合理的保护。该设备会产生并辐射射频能量，如果不按照说明安装和使用，可能会对无线电通信造成有害干扰。但是，不能保证在特定安装中不会出现干扰。如果本设备确实对无线电或电视接收造成有害干扰，这可以通过关闭和打开设备来确定，则鼓励用户尝试通过以下一种或多种措施来消除干扰:重新定向或重新放置接收天线。增加设备和接收器之间的距离，将设备连接到与接收器不同的电路插座上。

MVTAG

Item Locator
Quick Start Guide

Getting Started 01

1. **Power On / Off:**
   - Press the function button of the item locator once to turn on, and there will be a startup prompt tone
   - To power off, hold the same button for at least 3 seconds. You will hear 2 beeps indicating your Item Locator is powered off
2. **Check For Updates:**
   - To use the Apple Find My app to locate your item Locator, the latest version of iOS, iPadOS, or macOS is recommended.



Add Your Item Locator 02

1. **Start the App**
   - Open Find My™ app on your supported iPhone or iPad
   - Allow notifications from the app
2. **Connect your Item Locator**
   - Power on your Item Locator
   - In Find My™ app, select the "Items" tab
   - Tap "Add Item" then tap "Other Supported Items"
   - Once your Item Locator is located, tap "Connect"
   - Choose a recognizable name and emoji for your Item Locator and tap "Continue"
   - Find My™ will ask for confirmation to add your Item Locator to your Apple® ID - tap "Continue"
   - Tap "Finish" and your Item Locator will be set up and ready to be connected to whatever item you wish to locate e.g. your keys

Locate Your Item 03

1. **Find Item Locator when it is Nearby**
   - Open Find My™ app and select the "Items" tab
   - Tap on your Item Locator from the list
   - Tap "Play Sound" to make your Item Locator beep.
   - Tap "Stop Sound" to stop the beeps once you find your item
2. **Find Item Locator's Last Known Location**
   - Open Find My™ app and select the "Items" tab
   - Tap on your Item Locator from the list
   - Your Item Locator's last known location will appear on the map as the emoji you chose during set up
   - To navigate to that last known location, tap "Directions" to open the Maps™ app

Find Item When Out of Range 04

1. **Enabling "Notify When Left Behind"**
   - Open Find My™ app and select the "Items" tab
   - Tap on your Item Locator from the list
   - Under "Notifications", enable the "Notify When Left Behind" toggle
   - You will receive a notification when you leave your Item Locator behind and it's no longer in range of your device
2. **Enabling "Notify When Found"**
   - Under "Notifications", enable the "Notify When Found" toggle
   - When your Item Locator is seen by another Find My™ enabled device, you will receive a notification of its updated location
   - **Note:** "Notify When Found" can only be activated when your Item Locator is out of range

When Your Item is Lost 05

1. **Enabling "Lost Mode"**
   - Open Find My™ app and select the "Items" tab
   - Tap on your Item Locator from the list
   - Under "Lost Mode", tap "Enable"
   - A screen detailing Lost Mode will pop up, tap "Continue"
   - Enter your phone number or email address and tap "Next"
   - You may enter a message that will be shared with the person that finds your item
   - Tap "Activate" to enable "Lost Mode"
   - **Note:** When "Lost Mode" is enabled, "Notify When Found" is automatically enabled
   - **Note:** When "Lost Mode" is enabled, your Item Locator is locked and cannot be paired to a new device

Resetting Your Item Locator 06

1. **Remove the Item Locator from Find My™ app**
   - Open Find My™ app and select the "Items" tab
   - Tap on your Item Locator from the list
   - Please ensure "Lost Mode" is disabled
   - Scroll to the bottom of the screen and tap "Remove Item"
   - A summary will open, tap "Remove" to confirm
2. **Factory Reset Your Item Locator:**
   - After successfully removing the Item Locator from Find My™ app, press the Item Locator's function button four times rapidly, you will hear a beep each time you press it and then hold it a fifth time until you hear a ringing chime
   - The Item Locator is now reset and ready to be paired to a new device

But Wait... There's More 07

1. **Replace the Battery:**
   - Use your fingernails at the small gap on the side of your Item Locator to carefully open the case
   - Replace the battery with a new CR2032 battery placing it positive side up (text facing up)
   - Carefully close the Item Locator by aligning the top hole on both sides

2. **Unwanted Tracking Detection:**
   - If your iPhone detects that an unknown Item Locator is traveling with you, it will send you a notification. A sound will start playing so you will be able to find it. These alerts are only activated when an Item Locator is not connected to its owner's phone, so your partner's Item Locator will not trigger a sound if they are with you.

The Fine Print

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. NOTE: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications or changes to this equipment. Such modifications or changes not expressly approved by the party responsible for compliance could void the user's authority to operate this device. The device has been evaluated to meet general RF exposure requirement, The device can be used in portable exposure condition without restriction. Federal Communication Commission (FCC) Radiation Exposure Statement Power is so low that no RF exposure calculation is needed.

The Fine Print

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: Reorient or relocate the receiving antenna. Increase the separation between the equipment and receiver. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.