KSI-WOMBAT

Willow Pro
Quick Start Guide

❖ Factory Default Setting:
- Keyboard is in macOS mode
- The power switch is located on the rear side of the keyboard and is turned off by default.
- 2.4GHz RF Receiver is paired with the keyboard

❖ Toggle between macOS mode and Windows mode
You must be in macOS Mode to use Mac hot keys.
You must be in Windows Mode to use Windows hot keys.

Enter macOS mode	LEDs status	Enter Windows mode	LEDs status
Switch the mode select switch to "MAC" located on the rear side	1st and 2nd LEDs will blink for the macOS mode	Switch the mode select switch to "Win" located on the rear side	2nd and 3rd LEDs will blink for the Windows mode

❖ Battery
- 5 hours is required to fully charge the internal battery. Charge the battery **once a month for at least 2 hours.**
- When the middle LED **blinks along with any key presses**, the **battery power is low** and charging is required.
- **When the keyboard is connected to a USB host, the keyboard is automatically switched to USB mode.**
- To conserve battery power, all LEDs are deactivated in wireless mode. Hold the Fn key to see all the current status of LEDs.

KSI-WOMBAT

❖ Wireless connection

ON ⬜ OFF

(Power Switch on the rear side of the keyboard)

Fn + 📡	Fn + ß1	Fn + ß2	Fn + ß3	Fn + ⚲
RF 2.4GHz Device	Bluetooth Device #1	Bluetooth Device #2	Bluetooth Device #3	USB

❖ RF and Bluetooth pairing

	RF 2.4GHz receiver	BT device #1	BT device #2	BT device #3
Step 1	Turn ON the power switch on the rear side of the keyboard			
Step 2	Plug the RF Receiver into the host	Ensure Bluetooth setup dialog boxes are closed before starting the Bluetooth pairing		
Step 3	Press Fn + 📡 for 3 secs	Press Fn + ß1 for 3 secs	Press Fn + ß2 for 3 secs	Press Fn + ß3 for 3 secs
Step 4	3 LEDS blink	Top LED blinks	2nd LED blinks	3rd LED blinks
Step 5	Pairing succeeded	Open the Bluetooth setup dialog box on the target host and search for new Bluetooth devices		
Step 6	N/A	Willow #1 found, click to connect	Willow #2 found, click to connect	Willow #3 found, click to connect
Step 7	N/A	Pairing succeeded		

KSI-WOMBAT

❖ Switch between different paired hosts

	RF 2.4GHz receiver	BT device #1	BT device #2	BT device #3
Step 1	Turn ON the power switch on the rear side of the keyboard			
Step 2	Press Fn + 🛜 for 3 secs	Press Fn + 🅱1 for 3 secs	Press Fn + 🅱2 for 3 secs	Press Fn + 🅱3 for 3 secs
Step 3	3 LEDS blink	Top LED blinks	2nd LED blinks	3rd LED blinks
Step 4	RF mode is ready	Willow #1 is ready	Willow #2 is ready	Willow #3 is ready

❖ Shortcut keys

Hot Key	Press Directly**	Press with Fn Key**	Hot Key	Press Directly**	Press with Fn Key**
ESC 🍎	ESC	Apple Menu Bar	F8 ▶ǀǀ	F8	Play/Pause
F1 ☀	F1	Decrease Brightness	F9 ▶▶ǀ	F9	Next track
F2 ☀	F2	Increase Brightness	F10 🔇	F10	Mute
F3 ▦	F3	Launchpad	F11 🔉	F11	Volume Decrease
F4 🔍	F4	Spotlight	F12 🔊	F12	Volume Increase
F5 🎤	F5	Dictation*			
F6 🌙	F6	Do Not Disturb*	Psc	Print Screen	Selectable Screen Capture
F7 ◀◀	F7	Previous track	Num 🌐	Windows: Numlock and Win Key lock macOS: Lang. Select	

* Requires setup in System Preferences, please visit this link for detailed information on how to do the setup. https://wombatkeyboards.com/pages/how-to-use

** Toggle between **all shortcut keys being pressed directly** and **all shortcut keys being pressed in conjunction with the Fn key** by pressing and holding Fn + Tab for 2 seconds.

❖ Macro Editing Mode

Up to 20 macros can be programmed, require our free software "WB Pouch" to do so. Download link: https://wombatkeyboards.com/pages/download

This software is designed to assist you in programming your Willow Pro, the software allows you to create useful shortcuts, add emoji keys, create custom hot keys for specific software (ex. Zoom, Final Cut Pro), and adjust keyboard backlighting effects, updates and Firmware changes and much more!

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-- Reorient or relocate the receiving antenna.
-- Increase the separation between the equipment and receiver.
-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-- Consult the dealer or an experienced radio/TV technician for help. The device has been evaluated to meet general RF exposure requirement. The device can be u sed in portable exposure condition without restriction