INTRODUCTION

Thank you for purchasing the SilverLabel® Bluetooth® Headphones. These headphones are designed to be convenient, stylish and provide high quality audio playback from most Bluetooth® enabled audio or wired devices. The headphones can also be used to receive mobile phone calls while in use. They will automatically pause the audio playback in order to receive the call and when the call ends audio playback will resume.

Please read this user guide thoroughly before use so that you can understand the set-up and functions.

CONTENTS



Bluetooth® Stereo Headphones

USB to Micro USB Data Cabl



Audio Cable



EVA case

BUTTON OPERATION



1. Power
Long press = OFF/ON; enter pairing mode
Quick press = play/pause music
2. Volume up and down
3. Call
Quick press = answer/end call
Double press = redial last number
4. Mic
5. AUX-IN jack
6. LED indicator light
7. Micro USB charging port
ON

CHARGING



1. Connect the small end of the Micro USB charging cable to the charging port on the headphones.
2. Connect the large end of the Micro USB charging cable to your computer’ s USB port or an AC adapter (not included).
3. The LED indicator light turns RED when charging.
4. When fully charged, the LED indicator light green.

CONNECTION GUIDE

1. Press and HOLD the power button until a tone is heard and the LED indicator light flashes Blue.
2. Keep your Bluetooth® headphones and Bluetooth® enabled device within 3 feet of each other during the pairing process.
3. Set your mobile phone or other Bluetooth® enabled device to search for Bluetooth® devices.

Devices

iPhone: Go to SETTINGS>BLUETOOTH® (Make sure Bluetooth® is turned ON)

Android: Go to SETTINGS>BLUETOOTH® Search for devices (Make sure Bluetooth® is turned ON)

Blackberry: Go to SETTINGS/OPTIONS>BLUETOOTH® and enable BLUETOOTH®

On other Mobile phones/Devices: Review the instruction manual that came with your phone/device.

CONNECTION GUIDE

4. When the Bluetooth® enabled device finds the headphones, select “CHBT613” from the list of found
devices.

5. If required, enter the password 0000. Select OK or yes to pair with your device.

6. After a successful registration, a tone will be heard and the LED indicator light will be a steady blue.

NOTE: If you would like to connect the headphones to another device, you must unpair the headphones from the currently paired device first. On your device’s Bluetooth® settings, select “CHBT613”, then select “unpair”. When the headphones have been unpaired, turn off the headphones,
then turn them back on to enter pairing mode again.

BASIC OPERATION

Power ON/OFF

To turn ON or OFF, press and HOLD the power button until a tone is heard.

Adjusting the volume

. To increase the volume, long press the [+] button.

. To decrease the volume, long press the [-] button.

Answer/End a call

. To answer a call, quick press the phone button.

. To end a call, quick press the phone button again.

Redial a number

Double press the phone button. The last number called will be redialed.

Play/pause

. Quick press the power button to play music.

. Quick press the power button to pause music.

Skipping songs

. Quick press the [+] button to skip to the next song.

. Quick press the [-] button to skip to the previous song

USING AS WIRED HEADPHONES

1. Connect the one end of the included 3.5mm Auxiliary Cable to the AUX-IN jack on the headphones and
the other end of the cable to the external device’ s headphone jack (smartphone, tablet, computer or
MP3 player).
2. Open a media player on your device and click PLAY to start playing your music.
3. Use the controls on your connected device to control music playback on volume.

TROUBLESHOOTING tips

Q. I can pair the bluetooth headphones with my Bluetooth® device, but I cannot hear any music.

1. Make sure your Bluetooth® device supports A2DP profile.
2. Turn up the volume on your Bluetooth® device.
3. You may have to unpair the headphones, then re-pair to your device.

Q. I cannot get the Bluetooth® headphones into Pairing mode.

1. Make sure the Bluetooth® headphones are turned OFF before beginning the pairing process.
2. Press and HOLD the power button until a tone is heard and the LED indicator light flashes WHITE.
3. Check that the headphones are charged.

Q. My Bluetooth Device is not able to pair with the Bluetooth® headphones.

1. Make sure the Bluetooth® headphones are turned OFF before beginning the pairing process.
2. Keep your headphones and Bluetooth® enabled device within 3 feet of each other during the pairing process.
3. Check that YOUR device’ s Bluetooth® feature is turned ON.
4. Try repeating the pairing process, see “Pairing the headphones with a Bluetooth® enabled device”.

LEGAL INFORMATION

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

Warranty

SilverLabel® produces high-quality products, however, should it become apparent that your product shows signs of a defect please contact the authorised reseller from whom you purchased the product.

SilverLabel® issues its manufacturer's warranty extending to 2 years through an authorised reseller. Your authorised reseller is responsible for fulfilling the warranty and is also your point of contact.

Throughout this warranty period you are exempt from any repair/replacement costs for your SilverLabel® product (not including postage). Any further claims, except for the repair costs, are excluded. Should, however, it become apparent that the product has been rendered defective as a result of improper use, adverse external influence or as

a result of an unauthorised modification (both hardware or software-related), then the repair costs shall not be covered by the manufacturer's warranty.

The warranty period will commence upon the date of sale of the product to the end user. A purchase receipt must
be submitted as proof of this and handed over to your authorised reseller. Preferably you should deliver your
defective product to your authorised reseller in its original protective packaging.