Quick Installation Guide

WiFi Extender / Repeater
Version 1.0
NF-RE513 V2

1. The Product Description

1-1. Product Interface Indicator:

NEWFAST

- Power Indicator
- WPS/Reset Button
- WiFi Status Light

2. Repeater Mode Installation

2-1. WPS Installation:

1. Plug in, wait for the power light and WiFi light to turn on.
2. Press the WPS button on the router for 1-2 seconds. (Make sure your router has WPS function and is open)
3. Press the WPS button on the extender for 1-2 seconds.
4. Wait for about 30s, then the extender will restart automatically, the indicator will turn off then on again while connect to the router successfully.

5. Connect WiFi "XXX - plus", the password is your original WiFi password.
6. Move the extender to the best position that should be in the middle of the area with a poor WiFi signal and your router. The location that you choose must be within the range of your existing WiFi router network.

one key to repeater

Press the WPS button for only 1-2s.

2-2. Setup with Webpage

1. Plug in, wait for the power light and WiFi light to turn on.
2. Connect WiFi "XXXXXXX-2G" with your smartphone or computer. (Keep your smartphone or computer being connected to the extender during the installation.)

← WLAN
WLAN
More settings
CONNECTED
NEWFAST-2G
Connected (good quality)
AVAILABLE
2.4G_COMFAST_38449D
Open (available)
360_Mesh_5G
Open (available)

3. When the extender is setup for the first time, the configuration webpage will pops up automatically. If not, launch a web browser and enter "192.168.10.1" in the address field.
4. Enter the default password "admin" and click "SET PASSWORD" or "LOGIN".

X ⓘ 192.168.10.1   ::

🔒 |

SET PASSWORD

5. It will scan the wireless network signals around. Select the WiFi you want to extend, and enter your WiFi password (Pre-Shared Key), then click the "Save setting".

SSID | RSSI | Select
comfast-2G
/**%z-")
HONOR-510A7X
COMFAST_XR11_2.4G
TP-LINK_9A7E68

Connected to   comfast-2G
Please enter   comfast-2G password
Pre-Shared Key
NEW SSID   comfast-2G-plus
Note : After setting up, the wireless password is the same as the comfast-2G password

Save setting   Re scan

Scanning, please wait < #second.

6. After the setup is complete, it will reboot automatically. Then connect WiFi "XXX - plus"(your new extender SSID), the password is your original WiFi password, and enjoy the WiFi.

← WLAN
WLAN
More settings
CONNECTED
NEWFAST-Plus
Connected (good quality)
AVAILABLE
2.4G_COMFAST_38449D
Open (available)
360_Mesh_5G
Open (available)

3. FAQ

Q1: Can not access to internet after setting?
A1: If the red light flashes after setting, it means that the setting failed. Please check whether the entered password is correct. If not, please reset and enter the correct password.

Q2: Low speed after setting?
A2: Please check the status of the WiFi indicators:
Blue—Strong signal
Red—Weak signal (The distance between router and repeater is too far, please adjust the position of the WiFi repeater.)

Q3: How to reset?
A3: Press the reset button for 6-7 seconds, then release the button , wait until the wifi indicator lights up blue, and finally the blue light goes off.
Please check whether the initial WiFi XXXXXXX-2G appears in the WIFI list , if the initial WiFi XXXXXXXX-2G appears, it means the reset is successful. (Note: If the reset fails, please unplug the repeater and plug it in again.)

If you have any questions, please contact us by E-mail wonlinkservice@163.com, we will help you as soon as possible.
Website: www.szwonlink.com
Email: wonlinkservice@163.com

⚠ **Warning**
1. Use the product safely to prevent Electric shock risk.
2. Do not use in humid environment.
3. Use supporting power supply to prevent product damage.
4. Use the product safely to prevent inflammable and explosive risks.

Maintenance Regulations

Dear Valued Clients,
Thank you for purchasing products. To protect your rights and interests in after-sales service, please read the following maintenance regulations.

The following does not belong to free maintenance, our company can provide paid service, please note:

- Damage resulting from improper installation/mounting, improper use or storage of the product, or failure to observe the operating instructions and safety notes;
- Beyond the limited warranty;
- Unauthorized alteration, tearing up the product bar code;
- Without authorization to change the settings file or recompilation;
- Unexpected factors or human actions lead to product damage, such as improper input voltage, temperature, water mechanical damage, break, rust or oxidation serious, etc;
- Other failures or damages not caused by product's design, technology, manufacturing, quality, etc.

RoHS
MADE IN CHINA

Certificate Of Qualification
Quality Inspector
Production Date
Executive Standard

QC PASS

Packaged in a separate sealed container and placed in a dry environment

CE UKCA

AT BE BG CH CY CZ DE DK
EE EL ES FI FR HR HU IE
IS IT LI LT LU LV MT NL
NO PL PT RO SE SK SI UK