英

HENGJIANG X3

Users Manual

X3 Helmet Bluetooth Headset

⚠ Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-- Reorient or relocate the receiving antenna.
-- Increase the separation between the equipment and receiver.
-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-- Consult the dealer or an experienced radio/TV technician for help.
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction

Installation steps

● Fixed and installed by means of clips

Slightly open the metal clip and insert it directly into the helmet's inner edge.

Peel back the inner padding at the ear position of the helmet where there is space, and attach the

Properly align and attach the speaker to the main surface (start with the left speaker).

Position the touch band and padding in the appropriate location on the helmet, and adjust the microphone helmet, and adjust the microphone height (ensure proper adhesion and comfort).

Insert the plug into the headphone jack.

Installation complete.

Ports and Buttons Description

1 Volume down / Next track

2 Voice assistant

3 Volume up/next track/ambient light switch automatic answering (on/off)

4 Power on/off/answer calls/hang up/reject calls switch between Chinese and English/play/pause

5 Type-C charging interface

6 Type-C headphone jack

EN

X3 Users Manual

● **Power Operations**
Power On: Press [⊕] for 3s, indicator lights flash
Power Off: When on, press [⊕] for 3s, indicator stays on for 1s

● **Wireless Functions**
· Pairing: When on, indicators flash, search "X3" on phone
  Voice prompt: "Connected" after successful pairing
· Connected: Status light flashes every few seconds
· Disconnected: Indicators flash rapidly when disconnecting

● **Call Operations**
· Answer: Click [⊕] once or wait for auto-answer after number announcement (in auto-answer mode)
· End Call: Click [⊕] during call
· Redial: Double click when connected to redial last number

● **Music Playback**
(When wirelessly connected to phone)
· Play/Pause: Click [⊕]
· Previous: Click [+] · Next: Click [-]
· Volume Up: Hold [+] · Volume Down: Hold [-]

● **Ambient Light**
Double-click [+] to cycle through: 1st-Multi-color,
2nd-White, 3rd-Multi-color, 4th-Green, 5th-Blue,6th-Off

● **Auto Answer Settings**
When Bluetooth is not connected,Press [+] and [-] at the same time
Voice prompt: 'Automatically answer to turn on' or 'Automatically answer to turn off '.

● **Language Switch**
Language Switch Operation：Double-click [⊕] to switch between English and Chinese languages
Voice prompt: "中文" or "English"

● **Voice Assistant**
Click the [⬕] when not in a call

● **Charging Status**
Charging: Indicator on, turns off/changes color when full
Low Battery: "Low Battery" alert every 5 minutes when on

The power delivered by the charger must be between min [2.5] Watts required by the radio equipment, and max [5] Watts in order to achieve the maximum charging speed.

2.5-5W