

Earbuds Charging

To Charge Earbuds

Insert the Earbuds into charging case properly and close the case, they will power off & get charged.

Flash for 10 secs after charging starts and then turns off.

Tips:

If the earbuds don't charge or even can't turn on, that may because there is oxidized layer or something else on the charging pin.

You can solve this problem by cleaning the magnet connector on the earbuds with alcohol wipes.

08

Low Battery Alarm

When the battery is less than 10% (and the voltage is lower than 3.4V), a prompt voice "Please charge" will be advised, announce once every 5 minutes and 5 times in total, earbud led indicator flashes red light one time every 5 seconds. And then the earbuds will power off as normal.

Charging Case Charging

Type-C Charging

(There is a Type-C charging cable in the small black paper box inside the packing box.)

Please use the provided Type-C cable with a 5V/1A adapter(not included) to charge the charging case.

09

When the case is being charged, the digital display will show current power, the end digital number flashes 10 seconds and then goes off. Once fully charged, when you open the charging case to view it, the number will be display as 100 and then go off.

Wireless Charging

Easy to charge your charging case without cables, just put the charging case on a wireless charging pad. Please keep LED power display facing up when charging.

If the charging case doesn't start to charge, please try to reposition it until the LED power display flashes. (Wireless Charging Pad Not Included)

10

Multi-Function Operations

For Call

Answer Call: Tap Once
End Call: Quick Double-Tap
Reject Call: Long Press 2S

Voice Assistance

Activate Siri or other voice assistances:
Quick triple-click on L or R

11

For Music

When should I reset?

- Only one earbud plays music.
- Both earbuds can not work with together.
- Occur connection issues.

(* In mono mode, R earbud only supports next song and volume +.)

Follow Steps Below to Reset Earbuds:

Step 1: Delete the pairing name "H06" on your phone and deactivate the Bluetooth setting of all devices near by the earbuds.

Step 2: Take out the two earbuds from the charging case and keep them powering on.

Step 3: Tap both earbuds 5 times, then put the earbuds back into the charging case and close the lid.

(Both earbuds will flash Blue & Red light alternately for 3s, then the Red lights keep 1s and go off.)

Step 4: Now, open the charging case to turn them on, activate the Bluetooth setting on your phone, search and select "H06" to connect, they should work properly.

If it doesn't work, please repeat the steps above to try again.

12

Factory Restore Settings

When should I reset?

To protect users from potential hearing damage, Android's limit max volume is quite low for Bluetooth audio devices. If you feel the volume is too low, search developer options and enable absolute volume, so you'll be able to max the volume at your own volition and take full capabilities of your Bluetooth earbuds.

(* In mono mode, R earbud only supports next song and volume +.)

Find Build Number Firstly

Android 4.1 and newer: The developer options screen is available by default.

Android 4.2 and higher: The developer options in Android phones are hidden, you must enable them screen through Build Number.

Android 7.1 and newer: Settings > About Phone > Build Number

Android 8.0 and Android 8.1: Settings > System > About Phone > Build Number

Android 9 and higher: Settings > About Phone > Build Number

Note: Must in non-music or standby mode. There will be a prompt sound "di" when activating the voice assistant.

13

How to Sync Volume on Android?

When should I reset?

To protect users from potential hearing damage, Android's limit max volume is quite low for Bluetooth audio devices.

If you feel the volume is too low, search developer options and enable absolute volume, so you'll be able to max the volume at your own volition and take full capabilities of your Bluetooth earbuds.

(* In mono mode, R earbud only supports next song and volume +.)

Find Build Number Firstly

Android 4.1 and newer: The developer options screen is available by default.

Android 4.2 and higher: The developer options in Android phones are hidden, you must enable them screen through Build Number.

Android 7.1 and newer: Settings > About Phone > Build Number

Android 8.0 and Android 8.1: Settings > System > About Phone > Build Number

Android 9 and higher: Settings > About Phone > Build Number

Note: Must in non-music or standby mode. There will be a prompt sound "di" when activating the voice assistant.

14

Enable Developer Options

Developer options. You may also have to tap your PIN for verification. Once developer options are activated, you will see a message that reads "Your screen is now developer mode". Go back to the Settings page, search developer options and enable absolute volume, so you'll be able to max the volume at your own volition and take full capabilities of your Bluetooth earbuds.

Enable Absolute Volume

Scroll down until you reach the Network section. On the left, enable (toggle On) the absolute volume option (figure 2).

Android 4.2 and higher: The developer options in Android phones are hidden, you must enable them screen through Build Number.

Android 7.1 and newer: Settings > About Phone > Build Number

Android 8.0 and Android 8.1: Settings > System > About Phone > Build Number

Android 9 and higher: Settings > About Phone > Build Number

Note: These options in the figure may be different from the device you're using typically, the choices depend on the type and model of the device you're working with.

15

FCC ID: 2A2BY-H06

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.