



QUICK GUIDE FOR B-UHR CONNECTED WATCH

Thank you for purchasing
B-UHR CONNECTED.

The following instructions will guide you to set up your timepiece.
Our apps are available on Apple App Store and Google Play Store.



Bluetooth Pairing and Calibration


粵 En ↻

Install and open the app. A pairing page will appear.
Press the crown for 5 SECONDS (BLUE LED flashing meaning the timepiece is in pairing mode.)

Once it is connected to your smartphone, the calibration page shows up.
Use the clockwise and anti-clockwise button to adjust the 3 hands to 12 O'CLOCK POSITION.

Click "DONE". The hands will start displaying the local time.

REMINDER: DO NOT PULL THE CROWN. IT IS A PUSHER.




Crown Functions

Calendar

When crown press is set to display calendar, the format of watch hands is as follow:
Hour(Month):Minute(Date):Second(Day of Week), eg. 12(Dec):13(13th):7/35(Sunday).





Remote Camera Shutter

The crown will function as the shutter button when you open the camera app.

Second Time Zone

Select an extra time zone which the watch hands will display when the crown is pressed.

Phone Locator

Bells will be rang on your phone when the crown is pressed.


Notifications

App Notifications

Apps will be added to the list after the first time they show on the system notification bar. A LED colour and vibration pattern can be assigned for each app.

For Android: Please switch off battery optimization for our app in system's settings. It will hibernate the app and prevent notifications after reconnecting the timepiece.

REMINDER: FREQUENT VIBRATIONS AND LED FLASHES MAY SHORTEN BATTERY LIFE. TURN ON ONLY NECESSARY NOTIFICATIONS WOULD PROLONG USAGE TIME.



Indicators

Disconnection

When the timepiece is too distant away from your smartphone, or the bluetooth connection is interrupted due to other causes, the second-hand will start moving EVERY 10 SECONDS to indicate a disconnection. The timepiece will try to reconnect by itself, or after a single press of the crown. In case it does not, press and hold the crown for 5 SECONDS. The second-hand makes ONE REVOLUTION and LED flashes in BLUE, indicating a successful connection.



Low Battery/Battery Replacement

In case of the battery running low, the second-hand will start moving EVERY 5 SECONDS, and the LED will flash in RED when the crown is pressed.

The second-hand will STOP MOVING when the battery almost run out, the LED will flash in RED when the crown is pressed, until the battery is depleted.

Battery voltage sometimes drops temporarily. Check again in a few minutes, if the second-hand does not return to normal, battery replacement is needed.




REMINDER: WHEN PUTTING BACK THE CASE-BACK AFTER REPLACING THE BATTERY, PLEASE MAKE SURE THE ORIENTATION IS CORRECT (AS SHOWN IN THE IMAGE).

Unpair and Reset the Timepiece

When a problem persists, or connections get confused after multiple pairing/unpairing, you may try to reset the timepiece and the app completely by following the below steps:

1. Remove the app from all the smartphones.
2. Forget the timepiece in the system's Bluetooth settings.
3. Press and hold the crown on the timepiece for 30 SECONDS until a short vibration and a GREEN LED flash to take place. The timepiece is now reset.
4. Install the app and pair the timepiece again.



ENVIRONMENT PROTECTION

Disposal of old electric devices

The European directive 2012/19/EU for waste electrical and electronic equipment (WEEE) states that used household devices should not be disposed of with unsorted community waste. These used devices must be collected separately from household waste in order to increase the percentage of recovered devices and to recycle their parts, with the goal of

Manufacturer has endeavored to maximize the percentage of recovered devices and to recycle them per our corporate goal of reducing the negative effects on human health and on the environment. The symbol of the crossed out garbage can will be stamped onto all devices as a reminder of the obligation to put them in a separate garbage collection. The consumer must consult local authorities or the vendor to inform themselves about the manner in which their device should be disposed of.

FCC STATEMENT

Model: B-Uhr Connected
FCC ID: 2A2F6BUC

Caution: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.
Increase the separation between the equipment and receiver.
Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
Consult the dealer or an experienced radio/TV technician for help.

This equipment can be installed and operated with a minimum distance 5 millimeters between the radiator and user's body. And this equipment has been evaluated to meet general RF exposure requirement at 5 millimeters distance.

Contact Us

We are keen to improve our timepieces and make it even better. Kindly report the problem you have found with your phone model to feedback@mokandcompany.com for our study. Your contribution is appreciated.

Please provide more information here.

Submit

[Back to Top](#) ^