





# EVE 1

## User Manual


**TWS EARBUDS**

## Package Contents

After unpacking, please confirm that it contains the following contents



▲ EVE 1 TWS gaming earbuds



▲ Charging case




▲ USB charging cable



▲ User Manual

# Key Function



Touch sensor

## Manual operation

(Outside the charging case)

Power on

Long press for 2 sec

## Automatic operation

Power off Long press for 7 sec Put in the charging case and close

Short press twice

Long press on the left

Long press on the right

Audio is playing

Play/Pause

Enter & exit game mode

Music/Movie Sound effect switch  
(ringtone: Gaming mode/Gaming mode off) (ringtone: Music mode/Movie mode )

Note: You can switch between Music/Movie sound effects only after you exit the game mode

Short press once

Short press twice

Long press for 2 sec

Incoming call


Answer the call

Hang up the call


Incoming call rejection /switching call

## Light status

The position of the earbuds light



The position of the charging case light



### Earbuds light display

Light Color	System Status
Ice blue light and pink light flashing alternately	Ready to pair
Ice blue light flashes slowly	Paired successfully
Ice blue breathing light	Play audio
Green breathing light	Enter game mode
Red light flashes slowly	Low battery

### Charging case light display

Light Color	System Status
The corresponding power LED is on, and the next power LED flashes	Charging the charging case
LED lights off	When the charging case is fully charged
Blue light flashes slowly	When the earbuds are charging
LED lights off	When the earbuds are fully charged

## How to pair Bluetooth

After booting up and automatically forming a team, enter the "pairing mode"


Open the phone "Settings" → "Bluetooth"  
Search "EVE 1" for pairing



## How to charge

Note: 1. Open the charging box, take out the earbuds, and tear off the insulating film on the earbuds

2. The charging voltage of this product: 5V



Warning: The rechargeable battery contained in this product must be properly disposed of in order to be recycled. Please do not put the battery in the fire to avoid explosion.

Recommendation: If the lithium battery product is not in use, it needs to be charged once every three months.

## Product parameter

Brand name: GAMODIO

Product name: True Wireless Stereo gaming earbuds

Product number: EVE 1

Bluetooth name: EVE 1

Bluetooth version: VER5.1

Bluetooth distance: > 10 m

Sound effect mode: Music/Movie/Gaming

Low latency:  $\leq 60$  ms

Frequency response: 20 Hz – 20 kHz

Speaker parameters: 13 mm,  $32\Omega$

The battery capacity of the earbuds: 45 mAH

The battery capacity of the charging case: 500 mAH

Charging time of the earbuds:  $\leq 2$  hr

Charging time of the charging case:  $\leq 2$  hr

Product size: 6.5\*6.2\*2.4 mm

Product weight: 58 g

# Warranty description

## Warranty content

- 1 Unable to turn on;
- 2 Unable to charge when connected to a power source;
- 3 No sound from the speaker;
- 4 The function is not operating normally;
- 5 Bluetooth cannot be connected

## Warranty scope

- 1 From the date of receipt, within 7 days after the product has the performance failures listed in the "warranty content", the product can be returned and exchanged after identification, and the seller shall bear the freight back and forth.
- 2 From the date of receipt, within 8-15 days if the product has the performance failures listed in the "warranty content", the product can be exchanged after identification, and the return freight will be borne by each.
- 3 From the date of receipt, if the product has performance failures listed in the "warranty content" within 12 months, it can be repaired free of charge after identification, and the buyer pays the return shipping fee.

The following are not covered by the warranty

- 1 The product is damaged due to its own reasons;
- 2 Unauthorized dismantling by non-designated service providers;
- 3 Damage caused by force majeure such as natural disasters
- 4 Does not meet the above "warranty content"
- 5 Exceeded the warranty period

Manufacturer: 深圳蠻睿科技有限公司 G&O Audio Co.,LTD.

Address: shenzhen baoan district xinan sea prosperous street community

N23 excellence in times square C building Haitian road 15-3, 3005

Consulting telephone: 008675586088656

## Common solutions

Problem	What to do
The earbud is manually triggered to turn on, and the left and right earbuds are not connected to turn on	<ul style="list-style-type: none"><li>Since the left and right earbuds are not in a team state after shutting down, manually triggering the power on is a non-linked power on. The single earbuds need to be turned on separately, and they will automatically form a team after being turned on.</li><li>After putting back the charging case, closing the lid, and then out of the case, the earbuds will automatically turn on to form a team.</li></ul>
Earbuds don't pair with mobile device	<ul style="list-style-type: none"><li>Turn off the earbuds manually or put it in the charging case and close the cover, then turn it on again.</li><li>Turn off the power of your mobile device and turn it on again.</li></ul>
No sound	<ul style="list-style-type: none"><li>Increase the volume of earbuds and mobile devices.</li><li>Confirm the connected mobile device and make sure that the correct device is used.</li><li>Use different music sources.</li><li>Pair with another mobile device.</li><li>If you connect two mobile devices, pause the audio of the first mobile device, and then play the audio from the other mobile device.</li><li>Move the mobile device within the Bluetooth range of the earbuds (10m).</li></ul>
Poor sound quality	<ul style="list-style-type: none"><li>Use different music sources.</li><li>Move the mobile device to a position further away from the earbuds and away from any interference or obstacles.</li><li>Remove debris and earwax on the earbuds and the sound holes of the earbuds.</li></ul>

## Common solutions

Problem	What to do
The device cannot be charged	<ul style="list-style-type: none"><li>Insert the smaller end of the USB cable firmly into the charging port at the rear of the charging case, and make sure that the connector of the cable is correctly aligned with the charging port.</li><li>Fix both ends of the USB cable.</li><li>If the earbuds has been exposed to high or low temperatures, wait for the earbuds to return to room temperature, and then charge it again.</li></ul>
After manually turning off the Bluetooth of the mobile device, and then restarting the Bluetooth, the earbuds don't connect back	<ul style="list-style-type: none"><li>After manually turning off the Bluetooth of the mobile device, the mobile phone needs to have its own connection back function, and the earbuds will not initiate a connection back automatically.</li></ul>
No response to switching sound effects	<ul style="list-style-type: none"><li>Switching sound effects is divided into low-latency mode sound effects and low-latency sound effects. When entering low-latency mode, the sound effects are gaming effects. Before exiting, long press to switch between Music &amp; Movie sound effects is invalid operation; exit low-latency mode The rear sound effect is the two sound effect switching of Music &amp; Movie.</li></ul>
There is no response to operations such as switching between the first call and the second call.	<ul style="list-style-type: none"><li>You must first confirm that the mobile device supports three-way calling.</li><li>During a three-way call, the operation of holding or switching the call is to trigger the Key and hold down for 2 seconds.</li><li>During a three-party call, hang up the current call, return the first call, and double-click the Key.</li></ul>

**FCC Caution:**

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**Note:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.