

**Produce name: remote control car radio system**

**Model: LS-T3A-TBX**

Manufacturer: Shantou Haiboxing Technology&Education Model Co., Ltd.

Address: Guangyi Road, Chenghai District, Shantou, Guangdong, China

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

## 2.4GHz Transmitter Introduction:



Insert 2 AA batteries into the transmitter.

Do not mix old and new batteries, and ensure the polarities are not inverted.

Always remove the batteries when the transmitter is not in use.

### Low Battery Indication:

The LED on the transmitter will flash twice continuously when the batteries are low. Please replace them with new batteries.



- 1) **Button A:**  
No function for this vehicle
- 2) **Button B:**  
Press and hold for over 3 seconds to switch the vehicle light on or off.
- 3) **Trigger**
- 4) **Steering Wheel**
- 5) **Steering Trim**
- 6) **Steering Reverse**
- 7) **Steering D/R**
- 8) **Power Indicator**
- 9) **Speed Selection**
- 10) **Power On/Off**

## To Drive Your Vehicle


### 1) Turn on the transmitter Power

Press the On/Off Button on the transmitter to power it on.



### 2) Turn on the vehicle


Press and hold the On/Off button on the vehicle for more than 3 seconds to turn it on.




### 3) Testing Steering Performance



Turn to the left



Turn to the right



- Turn the steering wheel left, the vehicle should turn left.
- Turn the steering wheel right, the vehicle should turn right.



#### Steering Trim Knob:

Adjust this knob to align the front wheels straight if they veer left or right.



#### Steering Reverse Switch:

Use this if the vehicle turns in the opposite direction of the steering wheel. (Flip the switch accordingly).

### 4) Throttle Control



Slow ↔ High



Notice: Always begin by driving the vehicle at the low speed setting. You may use the high speed setting only once you gain experience.

Forward



Reverse




- Accelerate by pulling the trigger.
- Slow down by releasing the trigger.
- Brake by pushing the trigger forward.
- For reverse, bring the trigger to the center, then push forward again.

## To Drive Your Vehicle

### 4) Steering D/R Settings




The dual rate settings adjust the maximum steering angle.  
Move the D/R lever down to increase the steering angle or up to decrease it.



## Powering Down and Storage:

### 1) Turn off the vehicle

Press and hold the On/Off button on the vehicle for more than 3 seconds to turn it off.



### 2) Turn off the transmitter Power

Press the On/Off Button on the transmitter to power it off.



**Battery Care:** Always disconnect and remove the battery pack when not in use. Fully charge the battery before storing.

**Inspect the Vehicle:** Check for any damaged or worn parts on the vehicle before storing.