
M42843TS

Android 8.1 is the Operating System for your Touch Screen MT6739.

INTRODUCTION

Thanks for choosing *M42843TS*, Dual SIM Android, 4G smart phone based on 1.5GHz Quad Core Processor. This smartphone is running on Android 8.1OS. If you'd like your phone to live a long and fruitful life, please read this guide carefully and keep it for future reference. You never know when you might need it.

And don't worry if the pictures we use to demonstrate your phone's functions look a little different from what you see on its screen. It's the functions that matter.

Table of Contents

1	Safety	5
1.1	Safety Precautions	5
1.2	Using your phone safely	5
2	Understanding your Phone	8
2.1	Your Phone	8
2.2	Description Icons	9
2.3	Charging the battery	11
2.4	Power ON/OFF	11
2.5	Enter Main Menu	12
2.6	Enter Sub Menu	12
2.7	Use Notification Panel	12
2.8	Memory cleaner	12
2.9	Adjust the volume	12
2.10	Flashlight	12
2.11	Input	13
2.12	Do Not Disturb preferences	
		13
2.13	Voicemail	13
2.14	Signal frequency band	13
3	Using your Phone	14
3.1	Main Menu & Its Functions	
		14
4	Taking Care of your Device	14

1.1 Safety Precautions



Please read through the following briefings carefully and act in accordance with these rules, so as to prevent causing any danger or violating any law.

SAR Value

- **W/kg@1g(Head) W/kg@1g(Body)**
- Use cell phone when the signal strength is good. Keep your calls short or instead use headset or send a text message. This advice applies especially to children, adolescents and pregnant women.
- If you are using a Bluetooth headset device, please make sure it has a low power emitter.

ROHS Declaration

Declaration of Conformity with the requirements of the e-waste Management Rules, 2011 (adopted by Notification S.O. 1035 (E) of Ministry of Environment and Forests)

- The Product is in conformity with the requirements of Rule 13 of the e-waste Rules. The content of hazardous substance with the exemption of the applications listed in SCHEDULE II of the e-waste Rules:
 - a. Lead (Pb) – not over 0.1% by weight;
 - b. Cadmium (Cd) – not over 0.01% by weight;
 - c. Mercury (Hg) – not over 0.1% by weight;
 - d. Hexavalent chromium (Cr6+) – not over 0.1% by weight;
 - e. Polybrominated biphenyls (PBBs) – not over 0.1% by weight;
 - f. Polybrominated diphenyl ethers (PBDEs) – not over 0.1% by weight.

1.2 Using your phone safely



On The Road

Using a phone while driving is illegal in many countries. Please follow local laws and drive safely at all times.



Near Sensitive Electronics

Don't use your phone near sensitive electronic equipment – particularly medical devices such as pacemakers – as it could cause them to malfunction. It can also interfere with the operation of fire detectors and other automatic-control equipment.

For more information about how your phone affects pacemakers or other electronic equipment, please contact the manufacturer or your local distributor.

Your phone may cause interference when used near TVs, radios or automated office equipment.



While Flying

Your phone can cause interference with aircraft equipment. So it's essential you follow airline regulations. And if airline personnel ask you to switch off your phone, or disable its wireless functions, please do as they say.



In Hospital

Your phone may interfere with the normal operation of medical equipment. Follow all hospital regulations and turn it off when you're asked to by posted warnings or medical staff.



At a Petrol Station

Don't use your phone at petrol stations. In fact, it's always best to switch off whenever you're near fuels, chemicals or explosives.



Around Water

Keep your phone away from water (or any other liquid). It's not a waterproof model.



Making Repairs

Never take your phone apart. Please leave that to the professionals. Unauthorised repairs could break the terms of your warranty.



Broken Antenna

Don't use your phone if the antenna is damaged, as it could cause injury.



Around Children

Keep your mobile out of children's reach. It should never be used as a toy and it might not

be good for their health.



Original Accessories

Only use the original accessories supplied with your phone or those approved by the manufacturer. Using unapproved accessories may affect performance, make the warranty void, break national regulations on the use of mobile phones, or even cause injury.



Near Explosives

Turn off your phone in or near areas where explosive materials are used. Always obey local laws and turn off your phone when requested.



Emergency Calls

To make an emergency call your phone must be turned on and in an area where there's network coverage. Dial the national emergency number and press 'send'. Explain exactly where you are and don't hang up until help has arrived.



Working Temperature

The working temperature for the phone is between 0 Degree and 40 Degree Celcius. Please don't use the phone outside the range. Using the phone under too high or too low temperature might cause problems.



At very high volume, prolonged listening to a mobile phone can damage your hearing.

2.1

Your Phone



2.2 Description Icons

Keys	Functions
Hang up	<ul style="list-style-type: none">●Press this button to return home from any application or interface.●When the screen is off, short press it to turn on the screen, short press it to turn off the screen when on the homepage.●You can press it to reject the call or hang up during an incoming call or call.●Long press it to open the phone's menu, then you could choose to restart phone or turn off the phone.
Menu	<ul style="list-style-type: none">●In some application interfaces, you can click on it to bring up the application menu.
Back	<ul style="list-style-type: none">●Press it to return to the previous interface, or to close dialog box ,options,menu notification panel or the keypad.●Long press it to open recently opened Memory cleaner.
Dial	<ul style="list-style-type: none">●Press this button to call History from any application or interface.●After entering the number on the dial pad, click on it to call this number.

Up	<ul style="list-style-type: none">● You can move the cursor position by short-pressing it or long-pressing it.
Down	<ul style="list-style-type: none">● You can move the cursor position by short-pressing it or long-pressing it.● When on the homepage, you can bring up the notification bar by long pressing it.
Left	<ul style="list-style-type: none">● You can move the cursor position by short-pressing it or long-pressing it.
Right	<ul style="list-style-type: none">● You can move the cursor position by short-pressing it or long-pressing it.
OK	<ul style="list-style-type: none">● The cursor selects the menu or the mouse selects the menu, you can click ok to confirm. When the confirmation menu is not displayed, you can also click ok to confirm.
Numeric keyboard (0~9, *, #)	<ul style="list-style-type: none">● You can enter characters through the numeric keyboard in the editing interface or the dial interface.● You can quickly enter the dial pad through the numeric keyboard on the homepage.

- Some characters (for example: 0, *, #) have special usage in some scenes, please continue to check this description for detailed usage.

2.3 Charging the battery

The rechargeable Li-ion battery that comes with your phone is ready to be used, but is not charged full. It is easy to do & can be done in 3 simple steps below:

1. Connect the charger to your phone, and plug it into a socket.
2. The battery icon in the corner of the screen will display a battery icon with a lightning bolt, indicating that it is charging.
3. When fully charged, the battery icon will appear as a battery icon without lightning, indicating that charging has stopped.
4. Disconnect the charger from your mobile, and unplug.

2.4 Power ON/OFF

Long press the hang up key to power-ON/OFF the phone.

When you turn your phone on, it'll automatically check the SIM and show the following information on screen:

- **Input SIM PIN:** If you've set a PIN for your SIM.

Note:

The PIN is supplied with your SIM. Please replace it with your own PIN code as soon as possible. Enter the wrong PIN three times, and your SIM will be locked. Then you'll need to contact your network service provider to ask for a PUK code to unlock it.

2.5 Enter Main Menu

After unlocking the screen after power on, the main menu is displayed by default or you need to click the ok key to enter the main menu, all your applications will be displayed here.

2.6 Enter Sub Menu

Once at the main menu, click the icon to select the submenu, press Back Key to return to the previous menu, and press the Hang up key to return to the home screen.

2.7 Use Notification Panel

As a new notification appears in the notification area,to return to the homepage, long press the down button to view the notifications.

2.8 Memory cleaner

On any interface, long press [back]to access to Memory cleaner, view all the recent tasks &click menu to clear all applications.

2.9 Adjust the volume

1. We can adjust the volume of each type through Settings -> Sound.
2. In the interface of playing video or playing music, we can use the "*" key to decrease the media volume, and the "#" key to increase the media volume.
3. In the call interface, we can use the "*" key to lower the call volume, and the "#" key to increase the call volume.

2.10 Flashlight

When your screen is displayed on the home page, you can long press the down key to open the shortcut switch interface and choose to turn on or off the flashlight; or when the screen is displayed on the home page, long press the number key "0" to turn on the flashlight or close

2.11 Input

In the editing interface, you can enter characters by pressing the numeric keyboard.

1. Short press the # key, you can call the special character panel.
2. Long press # key, you can switch the input method language.
3. Long press the * key ,you can switch the input mode.

2.12 Do Not Disturb preferences

1. When you are on the home page, press the down key to enter the shortcut switch interface. This interface can be set to enable or disable the do not disturb mode.
2. When you are on the home page, you can also press and hold the number "#" key to switch the Do Not Disturb mode quickly.
3. Go to Settings - Sound - Do Not Disturb Mode interface, you can make more detailed settings for Do Not Disturb mode

2.13 Voicemail

Go to Phone-Settings-voicemail, set the voicemail number.

Pass, long press the number "1" key to make a voicemail call.

2.14 Signal frequency band

2G: GSM 850/900/1800/1900
3G: Band2(1900)/Band4(1700)/Band5(850)
FDD: B2/B4/B5/B7/B12/B13/B17/B66

3.1 Main Menu & Its Functions

Select to enter the main menu.

Allows you to view a list of features available in your phone.

1.Phone

Allow you to make quick outgoing calls.

2.CallLog

View your call history

3.Clock

After entering the clock, use the navigation keys to set the alarm.

4.Contacts

To see your list of Contacts. Access phonebook through this function.

5.Messaging

Allow you to view messages sent & received as a thread.

6.Settings

Modify settings under the following:

- Screen lock
- Bluetooth
- SIM cards
- Display
- Notifications
- Sound
- Apps
- Battery
- Security
- Language & input

- Date & time
- About phone

7.FM Radio

FM Radio can be used to listen to radio broadcasts.

8.Bluetooth

Can be paired with your bluetooth device, only supports the transmission of voice information.

4 **Taking Care of your Device**

Your device is a product of superior design and craftsmanship and should be handled with care: The following suggestions will help you protect your phone:

- Always keep the small parts of the phone away from children.
- Keep the device dry. Precipitation, humidity, and all types of liquids or moisture can contain minerals that rust electronic circuits. If your device does get wet, remove the battery, and allow the device to dry completely before replacing it.
- Do not use or store the device in dusty, dirty areas. Its moving parts and electronic components can be damaged.
- Do not store the device in high or cold temperature. High temperatures can shorten the life of electronic devices and damage batteries.
- Do not attempt to open the device other than as instructed in this guide.
- Do not drop, knock, or shake the device. Rough handling can break internal circuit boards and fine mechanics.
- Do not use harsh chemicals, cleaning solvents, or strong detergents to clean the device. Only use a soft, clean, dry cloth to clean the surface of the device.
- Do not paint the device. Paint can clog the moving parts and prevent proper operation.
- Use indoor chargers.

Use a dry soft cloth to wipe general dirt.

Do not use a hard cloth, benzene or thinner to wipe the phone, otherwise, the surface of the phone will be scratched or could even result in the fading of colour.

FCC Statement

1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
 - (1) This device may not cause harmful interference.
 - (2) This device must accept any interference received, including interference that may cause undesired operation.
2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

SAR Information Statement

Your wireless phone is a radio transmitter and receiver. It is designed and manufactured not to exceed the emission limits for exposure to radiofrequency (RF) energy set by the Federal Communications Commission of the U.S. Government. These limits are part of comprehensive guidelines and establish permitted levels of RF energy for the general population. The guidelines are based on standards that were developed by independent scientific organizations through periodic and thorough evaluation of scientific studies. The standards include a substantial safety margin designed to assure the safety of all persons, regardless of age and health. The exposure standard for wireless mobile phones employs a unit of measurement known as the Specific Absorption Rate, or SAR. The SAR limit set by the FCC is 1.6 W/kg. * Tests for SAR are conducted with the phone transmitting at its highest certified power level in all tested frequency bands. Although the SAR is determined at the highest certified power level, the actual SAR level of the phone while operating can be well below the maximum value. This is because the phone is designed to operate at multiple power levels so as to use only the power required to reach the network. In general, the closer you are to a wireless base station antenna, the lower the power output. Before a phone model is available for sale to the public, it must be

tested and certified to the FCC that it does not exceed the limit established by the government adopted requirement for safe exposure. The tests are performed in positions and locations (e.g., at the ear and worn on the body) as required by the FCC for each model. The highest SAR value for this model phone when tested for use at the ear is 0.785W/Kg and when worn on the body, as described in this user guide, is 1.399W/Kg (Body-worn measurements differ among phone models, depending upon available accessories and FCC requirements). While there may be differences between the SAR levels of various phones and at various positions, they all meet the government requirement for safe exposure. The FCC has granted an Equipment Authorization for this model phone with all reported SAR levels evaluated as in compliance with the FCC RF exposure guidelines. SAR information on this model phone is on file with the FCC and can be found under the Display Grant section of <http://www.fcc.gov/oet/fccid> after searching on

FCC ID:2A3BAITREEG799 Additional information on Specific Absorption Rates (SAR) can be found on the Cellular Telecommunications Industry Association (CTIA) web-site at <http://www.wow-com.com>. * In the United States and Canada, the SAR limit for mobile phones used by the public is 1.6 watts/kg (W/kg) averaged over one gram of tissue. The standard incorporates a substantial margin of safety to give additional protection for the public and to account for any variations in measurements.

Body-worn Operation

This device was tested for typical body-worn operations. To comply with RF exposure requirements, a minimum separation distance of 10mm must be maintained between the user's body and the handset, including the antenna. Third-party belt-clips, holsters, and similar accessories used by this device should not contain any metallic components. Body-worn accessories that do not meet these requirements may not comply with RF exposure requirements and should be avoided. Use only the supplied or an approved antenna.