

H62S Series Smart Switch

Manual

1

This user manual applies to:

• Wifi switch

Installation

Warning:

Make sure power supply totally been cut off for the switch you are replacing.

1.Remove your old switch from junction box

2.As shown in these diagrams below,insert wires into the corresponding terminal holes and fasten them.

3.Take off panel and fix switch with screws to junction box in the wall.

• For Dimmer switch

Dimmer switch

CERTIFICATE: CE, ROHS

INPUT: 100-240V~50/60HZ

OUTPUT: 300W/gang

Wireless protocol:IEEE: 2.4GHz

SIZE: 70*120*41mm

2

• Neutral switch

CERTIFICATE: CE, ROHS

INPUT: 100-240V~50/60HZ

OUTPUT: 500W/gang

Wireless protocol:IEEE: 2.4GHz

SIZE: 70*120*41mm

3

This user manual applies to:

• Wifi switch

Installation

Warning:

Make sure power supply totally been cut off for the switch you are replacing.

1.Remove your old switch from junction box

2.As shown in these diagrams below,insert wires into the corresponding terminal holes and fasten them.

3.Take off panel and fix switch with screws to junction box in the wall.

• For Dimmer switch

Dimmer switch

Model: TY-TJ-WUSH62S-T1D

CERTIFICATE: CE, ROHS

INPUT: 100-240V~50/60HZ

OUTPUT: 300W

Wireless protocol:IEEE: 802.11 b/g/n, 2.4GHz

SIZE: 70*120*41mm

4

• For 1 gang switch

1 gang switch

Model: TY-TJ-WUSH62S-L1D

CERTIFICATE: CE, ROHS

INPUT: 100-240V~50/60HZ

OUTPUT: 1000W/gang

Wireless protocol:IEEE: 802.11 b/g/n, 2.4GHz

SIZE: 70*120*41mm

5

Add switch to APP

1.Download Smart Life APP from APPstore and register

2.Preparations before get started

• For WiFi switch

A wifi router is required,the wifi switch only supports 2.4GHz WIFI network.

3.Power up the switch,press and hold the button(for about 5 seconds) until the indicator blinking to enter pairing mode,then do the following steps for adding.

6

• For WiFi switch

1.Open Smart Life APP,tap the icon + on the top right in the homepage.

2.Tap Electrical--Switch(WI-FI), enter into Add Device

7

3.Choose your local wifi and input wifi password

4.Comfirm the indicator is blinking rapidly.---(Long press any switch button for about 5 seconds then indicator will blinking)

8

5.Wait for configuring successfully,then tap Cpmplete and edit name

9

FCC Statement

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Radiation Exposure Statement

To comply with FCC RF exposure compliance requirements, this grant is applicable to only mobile configurations. The antennas used for this transmitter must be installed to provide a separation distance of at least 20cm from all persons and must not be co-located or operating in conjunction with any other antenna or transmitter.