

## **DANCESOUL Charging Wireless Mouse**



## **Usage method**

- **2.4G Wireless connection**

1. Insert the receiver into the USB interface of the computer(device).

2. Turn on the mouse power switch within a distance of less than 30 cm from the mouse receiver(move the switch to the on).

## **Other functions**

### **DPI/ sensitivity adjustment:**

Touch lightly (DPI) button to adjust DPI/sensitivity. The value is 1000/1200/1600 DPI.


### **Turn off the mouse:**

If you don't use the mouse temporarily, you can toggle the toggle switch to the OFF. The position (OFF) can turn off the mouse power, which can save power and prevent misuse.



**3 Levels DPI switchable**

**1000 1200 1600**



## **Product parameters:**

Transmission distance: 10M

Connection method : 2.4G

Battery type: comes with charging

Interface type: USB

Tracking system: Optics

Resolution: 1000/1200/1600DPI

Wireless carrier frequency: 2405-2478MHz

Wireless working channel: 16 automatic frequency hopping

Rated operating current:  $\leq 7\text{mA}$

Maximum acceleration: 14 in/S

USB interface: 1.1/2.0

Working voltage: 3.7V

Working current: 5V=500mAh

Producing country: China

Please use the computer USB interface to charge the mouse.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction