


Operating Instructions for Space Capsule Base

- ★ The base of the astronaut space capsule is a Bluetooth speaker, which can be connected to Bluetooth to play music.
- ★ When playing music, you need to connect Bluetooth first, turn on the bluetooth of the space capsule and the mobile phone, and select Space for pairing. After the pairing is successful, you can use your mobile phone to play music.




Precautions

- ★ When using the starlight, turn on the power switch on the base first, and then turn on the power switch on the backpack.
- ★ When not in use, please press the power switch/Bluetooth switch to turn it off to avoid battery power consumption.
- ★ The base of the space capsule cannot be charged. It can only be charged using the power socket on the astronaut backpack. The charging time takes 3 to 6 hours to fully charge. Do not use the starlight when charging.

Precautions


- ★ The light source of stars and nebulae is so strong that the eyes should not look directly at the light source.
- ★ The brightness of the stars (ie the laser brightness) is affected by the ambient temperature and time of use. When the ambient temperature is hot or the power-on time is longer, the brightness of the laser will decrease due to the heat of the light source. At this time, just turn off the laser and let the laser transmitter dissipate heat. (The heat dissipation time usually takes more than 15 minutes) The brightness can be restored after turning on the machine.
- ★ The head and body of the astronaut are connected together by magnets, and the direction of the head can be adjusted. Do not stretch your head and body forcefully, otherwise the wires may break due to stretching.



Please install the base before use and make sure that the astronaut's feet are in full contact with the base of the capsule.

Host key operation instructions

Remote control instructions



- ★ **Remote control window:** Receive infrared remote control signal.

Host key operation instructions

Timing indicator light

★ **Timing switch:** The timing function is divided into two levels, namely 45-minute timing/90-minute timing. Press the first time, the timing indicator light blue, and enter the 45-minute timer; press the second time, the timer indicator light red, and enters the 90-minute timer; in the timing state, the timer indicator light stays on; long press to cancel the timer, after canceling the timing indicator light goes out.

★ **Nebula brightness:** There are 5 levels of Nebula brightness. The default brightness is the middle level. Each time you press it, the brightness will increase by one level.

★ **Nebula color switching:** Each time you press the button, the nebula will switch to a color. After a cycle, it will return to the default color. Long press the button to turn off the nebula. After closing the nebula, short press the button to open the nebula.

★ **Nebula change speed:** Nebula change speed is divided into 0-1-2-3-4 gears, gear 0 is static, gear 1 is the fastest change speed, the default gear is 2 gear, and the nebula changes speed every time you press. Decrease one gear until it reaches 0 gear.

★ **Star breathing rate:** Each time you press it up to the 4th level.

★ **Nebula brightness:** There are 5 levels of Nebula Brightness, the default is the middle level, and the brightness is reduced by one level each time you press.

★ **Star switch:** Short press the button, each time you press it to switch a star breathing rate, long press to turn off the star function, and then short press again to turn on the star function.

★ **Star breathing frequency:** Star breathing frequency is divided into 0-1-2-3 gears, at the stars are always on, gear 3 is the highest frequency, the default gear is 2 gears, every time you press the star, the breathing rate is reduced by one gear until it reaches the 0 gear.

★ **Remote control window:** Receive infrared remote control signal.

Host key operation instructions

Star brightness

★ **Star brightness:** The star brightness adjustment is limited to the constant light mode. In the breathing state, this button is invalid. There are 3 levels of brightness adjustment. The default brightness is the highest when it turns on. Each time you press it, the brightness is reduced to the darkest position.

★ **Star brightness:** The default brightness is the highest. Whether the brightness is dimmed, each time this button is pressed, the brightness will increase by one level until it reaches the highest level.

Material: ABS/PC

Product color: white

Battery capacity: 2400mAh

Laser wavelength: 532nm

LED power: 5W

Control method: remote control

Remote control distance: <5m (at range)

Power input: 10-24V 50/60Hz 0.4A

Working input: 5V 1A

Product size: 120*130*22mm

Usage environment: indoor/dark environment better

Working temperature: -10~40°C



This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.