


Flood Sensor

AFZ01



User Manual

Key Features:

AFZ01

- Z-wave 800 series design, support Z-wave LR and compatible with Z-wave Mesh.
- Thin profile—can fit under appliances.
- Beeps and sends Z-Wave notification when water is detected.
- 1 mile under LR mode, up to 200 feet under Z-wave mesh mode.
- Wear-resistant surface, suitable for most of the environments.
- Low Battery Indication.

Good to place near washing machines, dishwashers, sinks, toilets, or your indoor garden to alert you of any leaky accidents!

- The Flood Sensor should be within 10' of your Z-Wave controller for the inclusion process. After successful pairing, the device can be brought to the desired location.

Physical Characteristics

MAIN BODY

REMOTE SENSOR PROBE

ACTION BUTTON

MAIN BODY CRADLE

Figure 1

Waking Up the Flood Sensor

To power on your Flood Sensor with the included CR2 battery, follow these steps:

- Press the Action Button quickly 3 times in a row. The LED will be colorful gradient for 5 seconds and then if indicating exclusion successful.
- Press and hold Action Button for 3 seconds for device inclusion.
- The Flood Sensor detects moisture then contact the METAL EET on the REMOTE SENSOR PROBE or the MAIN BODY BASE to monitor a specific appliance for leaks, place the Flood Sensor near by on a flat surface where water is likely to accumulate during a leak.
- If your Z-Wave gateway support SmartStart scan the QR code on Flood Sensor using the gateway's app. Your sensor will join your Z-Wave network automatically.

Resetting the Flood Sensor

Following these steps. Only do this when your Z-Wave controller is disconnected or otherwise unreachable. Beware that resetting your device will disconnect it from the system:

- Remove the Main Body bottom cover and confirm that your Flood Sensor is powered on.
- When using the REMOTE SENSOR PROBE, the SENSOR ASSEMBLY will be in the MAIN BODY CRADLE.

Adding (Inclusion)

Follow the instructions for your Z-Wave Certified Controller adding inclusion mode. When prompted by the controller:

- The device should already be included in your Z-Wave system before continuing further. Study the Pre-Installation Checklist below for a broad overview of installation options and other notes to be in mind.
- Remove the Main Body bottom cover from the Main Body.

Physical Installation

The device should already be included in your Z-Wave system before continuing further. Study the Pre-Installation Checklist below for a broad overview of installation options and other notes to be in mind.

Removing (Exclusion)

Follow the instructions for your Z-Wave Certified Controller for the exclusion mode. When prompted by the controller:

- Press an hold Action Button for 12 seconds then release. A flashing light with two colors alternately indicate a successful factory reset.
- The Flood Sensor's memory will be erased to factory settings.

Pre-Installation Checklist

1. The Flood Sensor should be within 10' of your Z-Wave controller for the inclusion process. After successful pairing, the device can be brought to the desired location.

2. Press the Action Button quickly 3 times in a row. The LED will be colorful gradient for 5 seconds and then if indicating exclusion successful.

3. Press and hold Action Button for 3 seconds for device inclusion.
- The Flood Sensor detects moisture then contact the METAL EET on the REMOTE SENSOR PROBE or the MAIN BODY BASE to monitor a specific appliance for leaks, place the Flood Sensor near by on a flat surface where water is likely to accumulate during a leak.

Power Flood Sensor

To power on your Flood Sensor with the included CR2 battery, follow these steps:

4. If your Z-Wave gateway support SmartStart scan the QR code on Flood Sensor using the gateway's app. Your sensor will join your Z-Wave network automatically.

Indicator

The MAIN BODY CRADLE and REMOTE SENSOR PROBE

LED will be colorful gradient for 5 seconds and then if indicating exclusion successful.

5. Press and hold Action Button for 3 seconds for device inclusion.

The Flood Sensor detects moisture then contact the METAL EET on the REMOTE SENSOR PROBE or the MAIN BODY BASE to monitor a specific appliance for leaks, place the Flood Sensor near by on a flat surface where water is likely to accumulate during a leak.

6. If your Z-Wave gateway support SmartStart scan the QR code on Flood Sensor using the gateway's app. Your sensor will join your Z-Wave network automatically.




Figure 2 - Flood Sensor Installation Without the REMOTE SENSOR PROBE




Figure 3 - Flood Sensor Installation With the REMOTE SENSOR PROBE

Installation—Without the REMOTE SENSOR PROBE

1. Make sure the Flood Sensor is already included in your Z-Wave System and bring it to your desired installation location.
2. Confirm that your device can communicate with your Z-Wave Controller from the final installed location before proceeding.
3. Place Flood Sensor on a flat surface near the device to be monitored.
4. Double-check that your Z-Wave Controller can still communicate with the Flood Sensor, pour a small amount of water on the floor to emulate a leak and confirm that the device beeps and reports the event to your Controller.

Installation—With the REMOTE SENSOR PROBE

1. Mount the MAIN BODY CRADLE on a wall near the location you wish to monitor, making sure the REMOTE SENSOR PROBE's cable will reach it comfortably. You may optionally rest the MAIN BODY CRADLE, unmounted, on a table, shelf, or another surface.
2. Snap the SENSOR ASSEMBLY into the MAIN BODY CRADLE, making sure the METAL FEET on the SENSOR ASSEMBLY line up with their mates on the MAIN BODY CRADLE.
3. Plug the REMOTE SENSOR PROBE into the MAIN BODY CRADLE and place the other end of the PROBE in the area to monitor, making sure the METAL FEET is flat on the surface.

Warranty.

The manufacturer is not responsible for any damage or circuit different from that which the receiver is connected.

(4) Consult the dealer or an experienced radio/TV technician for help.

(5) Ensure this equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to

provide reasonable protection against harmful

interference in a residential installation.

This equipment generates and

radiates radio frequency energy

and, if not installed and used in accordance with the

instructions, may cause harmful interference to radio

communications. However, there is no guarantee that

interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio

or television reception, which can be determined by

turning the equipment off and on, the user is encouraged

to try to correct the interference by one or more of the

following measures:

(1) Reorient or relocate the receiving

antenna.

(2) Increase the separation between the

equipment and receiver.

(3) Connect the equipment into a circuit different from that to which the receiver is connected.

(4) Consult the dealer or an experienced radio/TV technician for help.

(5) Ensure this equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to

provide reasonable protection against harmful

interference in a residential installation.

This equipment generates and

radiates radio frequency energy

and, if not installed and used in accordance with the

instructions, may cause harmful interference to radio

communications. However, there is no guarantee that

interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio

or television reception, which can be determined by

turning the equipment off and on, the user is encouraged

to try to correct the interference by one or more of the

following measures:

(1) Reorient or relocate the receiving

antenna.

(2) Increase the separation between the

equipment and receiver.

(3) Connect the equipment into a circuit different from that to which the receiver is connected.

(4) Consult the dealer or an experienced radio/TV technician for help.

(5) Ensure this equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to

provide reasonable protection against harmful

interference in a residential installation.

This equipment generates and

radiates radio frequency energy

and, if not installed and used in accordance with the

instructions, may cause harmful interference to radio

communications. However, there is no guarantee that

interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio

or television reception, which can be determined by

turning the equipment off and on, the user is encouraged

to try to correct the interference by one or more of the

following measures:

(1) Reorient or relocate the receiving

antenna.

(2) Increase the separation between the

equipment and receiver.

(3) Connect the equipment into a circuit different from that to which the receiver is connected.

(4) Consult the dealer or an experienced radio/TV technician for help.

(5) Ensure this equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to

provide reasonable protection against harmful

interference in a residential installation.

This equipment generates and

radiates radio frequency energy

and, if not installed and used in accordance with the

instructions, may cause harmful interference to radio

communications. However, there is no guarantee that

interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio

or television reception, which can be determined by

turning the equipment off and on, the user is encouraged

to try to correct the interference by one or more of the

following measures:

(1) Reorient or relocate the receiving

antenna.

(2) Increase the separation between the

equipment and receiver.

(3) Connect the equipment into a circuit different from that to which the receiver is connected.

(4) Consult the dealer or an experienced radio/TV technician for help.

(5) Ensure this equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to

provide reasonable protection against harmful

interference in a residential installation.

This equipment generates and

radiates radio frequency energy

and, if not installed and used in accordance with the

instructions, may cause harmful interference to radio

communications. However, there is no guarantee that

interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio

or television reception, which can be determined by

turning the equipment off and on, the user is encouraged

to try to correct the interference by one or more of the

following measures:

(1) Reorient or relocate the receiving

antenna.

(2) Increase the separation between the

equipment and receiver.

(3) Connect the equipment into a circuit different from that to which the receiver is connected.

(4) Consult the dealer or an experienced radio/TV technician for help.

(5) Ensure this equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to

provide reasonable protection against harmful

interference in a residential installation.

This equipment generates and

radiates radio frequency energy

and, if not installed and used in accordance with the

instructions, may cause harmful interference to radio

communications. However, there is no guarantee that

interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio

or television reception, which can be determined by

turning the equipment off and on, the user is encouraged

to try to correct the interference by one or more of the

following measures:

(1) Reorient or relocate the receiving

antenna.

(2) Increase the separation between the

equipment and receiver.

(3) Connect the equipment into a circuit different from that to which the receiver is connected.

(4) Consult the dealer or an experienced radio/TV technician for help.

(5) Ensure this equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to

provide reasonable protection against harmful

interference in a residential installation.

This equipment generates and

radiates radio frequency energy

and, if not installed and used in accordance with the

instructions, may cause harmful interference to radio

communications. However, there is no guarantee that

interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio

or television reception, which can be determined by

turning the equipment off and on, the user is encouraged

to try to correct the interference by one or more of the

following measures:

(1) Reorient or relocate the receiving

antenna.

(2) Increase the separation between the

equipment and receiver.

(3) Connect the equipment into a circuit different from that to which the receiver is connected.

(4) Consult the dealer or an experienced radio/TV technician for help.

(5) Ensure this equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to

provide reasonable protection against harmful

interference in a residential installation.

This equipment generates and

radiates radio frequency energy

and, if not installed and used in accordance with the

instructions, may cause harmful interference to radio

communications. However, there is no guarantee that

interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio

or television reception, which can be determined by

turning the equipment off and on, the user is encouraged

to try to correct the interference by one or more of the

following measures:

(1) Reorient or relocate the receiving

antenna.

(2) Increase the separation between the

equipment and receiver.

(3) Connect the equipment into a circuit different from that to which the receiver is connected.

(4) Consult the dealer or an experienced radio/TV technician for help.