

User guide for
Wireless charger



The Wireless charger is a two-in-one wireless charger and catchall tray, designed to hold the daily essentials and discreetly power your device. It is functional and easy-to-use, supporting all electronic devices with Qi compatibility. The Wireless charger is inspired by industrial design and has a streamlined aesthetic and leather finish. Station it in your home office or on a bedside table.

Instructions for use

How to connect

1. Connect the Type-C cable to the port on your Wireless charger.
2. Plug the other end of the Type-C cable into a power adapter or computer outlet with the correct output: 5V/2A(MAX), 9V/1.67A(MAX), 12V/2A(MAX). Slow white LED flashes indicate that standby mode is activated.
3. Place your Qi-compatible device onto the centre of the wireless charging area. A solid white light indicates that the device is charging. If the device does not begin to charge immediately, carefully move it around until the desired alignment is achieved.
4. When the device is fully charged, the LED light will turn off.


Alignment

Wireless Qi technology is activated when the transmitter coil in The Wireless charger and the receiver coil in your device are aligned.

The Wireless charger's transmitter coil is located in the centre of the raised section. To begin charging, place your device here.

You can check if your device is positioned correctly by monitoring the LED light. Charging mode is indicated by a solid white light.

If charging mode is not activated, carefully reposition your device until the two coils are aligned.



Safety information

- Plug the product into a reliable and correct electrical outlet.
- Do not place credit cards or metallic items, such as keys, on the raised side of The Wireless charger.
- Do not place mechanical watches on the raised side of The Charging Catchall. The magnetic field created by the coils can damage them.
- The Wireless charger should be kept in a dry and ventilated environment. Do not use it in severely hot or humid conditions. It is for indoor use only.
- Do not attempt to disassemble the product.
- If the USB-C cable or transmitter plate begins to overheat, disconnect from power. Only attempt to use it again when it has cooled down.
- Do not exceed the maximum input voltage of 12V/2A. Supplying a voltage over the maximum rating can damage The Wireless charger and cause safety hazards.

Device not charging

- Make sure the device is Qi-enabled.
- Make sure The Wireless charger is connected to a working power outlet.
- Make sure the device is aligned correctly.
- Ensure there are no other items resting on the charging section.
- Remove the device's case. It may be preventing charging.

LED indicator status

Slow white flashes	Standby mode
Solid white	Charging mode (when it's fully charged it will turn off)
Fast white flashes	Foreign object detected

Technical specifications

Input	5V/2A, 9V/2A, 12V/1.5A
Output	5W/7.5W/10W/15W
Dimension	27 x 20 x 0.5 (cm)
Weight	0.5kg

FCC Statement

This device complies with part 15 of the FCC Rules. Operation is Subject To the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Changes or modifications not explicitly approved by the party responsible for compliance could void the user's authority to operate this equipment.

Note: this equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and candidate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. During the operation of device a distance of 15 cm surrounding the device and 20 cm above the top surface of the device must be respected.