


Frequently Asked Questions

- 1 Can I share with family and friends?**
Yes, you can share your camera with family and friends who will have the same app. After you have installed the app, you can use the app to add devices. In the app, press the Profile button and click on the Home button. Then, you can share your camera with family and friends. In order to share, the other user should already have downloaded the app and registered a new account.
- 2 What's the Wireless Range?**
The range of your home Wi-Fi is heavily dependent on your home router and the environment. The range of the Wi-Fi is about 100m. If you want to use the camera in a different room, you can use a Wi-Fi extender to extend the range.
- 3 The device appears offline or unreachable?**
Make sure your Wi-Fi router is online and in range. Check the Wi-Fi signal strength. If the signal is weak, move your Wi-Fi router and try again.
- 4 Cannot connect to your Wi-Fi network.**
Make sure you entered the correct Wi-Fi password during the Wi-Fi setup. Check whether there are any internet connection problems. If the Wi-Fi signal is too weak, move your Wi-Fi router and try again.
- 5 How many cameras can I control?**
TypeSmart app can control an unlimited amount of devices in an unlimited amount of locations. Your router may have a limit of how many devices can be connected to your router.

6 Is the process same when I add the device through wifi or network cable?
Yes, they have same process, you can use the app to add devices.

Description of assembly steps

1. Remove expansion bolt into wall body as per the hole position of the device.
2. Put the doorbell to the back plate.
3. Put the doorbell to buckle it on the back plate to complete installation.



Technical Specifications

Doorbell

- Operating temperature: -20°C ~ 50°C, Operating humidity: 10%~95%, No condensation
- Power supply: 100-240V~50/60Hz, 10W
- Power consumption: 10W
- Power supply: 100-240V~50/60Hz, 10W
- Power consumption: 10W

Chime

- Operating temperature: -10°C to 50°C, Operating humidity: <90% at 25°C
- Communication: RF 433MHz
- Power: 100-240V~50/60Hz, 10W
- Indoor use, bathroom excluded. Symbol:  means for indoor use
- Symbol:  means Class II product/Double Insulated. No earth required

Declaration of Conformity

CE


Declaration of Conformity European Notice

This product is in compliance with essential requirements and other relevant provisions of Directive 2014/53/EU, 2014/52/EU.

This product must not be disposed of as normal household waste. In accordance with EU directives for waste electrical and electronic equipment (WEEE), this product must be disposed of separately from other waste. Please refer to the local authorities for disposal of this product. The device could be used with a separation distance of 20cm to the human body.


- Never use the appliance and its battery in extreme conditions (high or low extreme temperature, high altitude...) during use, storage or transportation.
- Warning: Batteries shall not be exposed to excessive heat such as fire, direct sunlight, or near a heat source.
- Never use the appliance and its battery in the presence of flammable or explosive materials.
- Never short circuit the battery.
- For plug-type equipment, the socket-outlet shall be installed near the equipment and shall be easily accessible.

Smart Battery Doorbell



Please read the manual carefully before use

Product description



Packing list

- Set 1: Video Doorbell + Ring Dongle
- Video doorbell
 - Speaker
 - Charging cable
 - Power cord
 - Mounting hole labels

Disassembling the doorbell charging instructions

1. Insert the disassembly wedge into the hole and press down firmly.
2. Pull out the doorbell forward as shown.
3. Plug in the USB cable to charge.

Doorbell Status

Green Light

- Solid — Charging
- Off — Charging Completed
- Charging status — Charging abnormal

Red Light

- Solid — Network connection failure
- Off — Network connection successful
- Red light and blue light quickly blink — OTA Upgrading

Blue Light


- Solid — Network connection successful
- Off — Normal status
- Flashes 3 times — Doorbell wake up
- Slowly Blink — Waiting configuration

Basic Operations

Power on: Toggle the switch button to on

Power off: Toggle the switch button to off

Reset: Long Press "Reset" for 5 seconds




Get Ready

- Know your Wi-Fi network and password
- Make sure your mobile device is running iOS 11 or higher or Android™ 5.0 or higher
- Make sure you're connecting to a 2.4GHz Wi-Fi network (It can't connect to 5GHz networks)

1

Download the Smart Life app from App Store or Google Play.



2

Register an account on your TypeSmart app

STEP 1

Enter your mobile phone number or email address

STEP 2

Enter the verification code and create a password

3

Add device


- Open TypeSmart APP, click "+" on the top right corner of the page "HOME", then click "Add Device".
- Make sure the indicator light on the device is flashing. Then press "Next".

4

Enter your Wi-Fi network and password

5

Reset the instruction about Scan with the camera's QR code



*Please refer to the specific APP interface if there are any difference.