


# YORTOT

## Clock AC198-Black User Manual



### 12 Months Warranty

If you have any questions, please feel free to contact us by email at: [customer@kerweilai.com](mailto:customer@kerweilai.com)

## **Friendly Tips**

1. If the display is " blank " or turn on night light " don't work " after plugging in, please slide the " Display Dimmer " or " Nightlight Dimmer " switch on the back of the clock to brighten the screen/night light.
2. Only supports Airpods and Iwatch (not included iwatch charger)
3. Please keep plugged in ! The batteries drains fast if battery operated ONLY.

## Features

- Wireless Charging (Phone / iWatch / Airpods)
- 7 Color Night Lights
- 10-100% Nightlight Dimmer
- Alarm Clock
- 9 Minutes Snooze
- 0-100% Display Dimmer
- 3 Levels Volume Adjustment
- 12/24H Mode
- Battery Backup (Phone and Headphone Charging Not Supported)
- YORTOT Indicator Light


## Package Include

- 1 \* 5 in 1 Wireless Charging Station with Alarm Clock
- 1 \* Power Cord With Adapter
- 1 \* User Manual


## Power Specifications

AC, 100-240V, 50-60Hz, 0.55A Max  
DC, 9V-2A

# Front View




## Back View



## Bottom View

Heat Dissipation Hole



Battery Compartment (Batteries not included)

## Supported only on battery power

Night Light	√	Phone charging	✗
Alarm Clock	√	Airpods charging	✗
Iwatch charging	√		

## Getting Started

Plug the adaptor into a standard household outlet and install 3\*AAA batteries, you will see 12:00 on the display and the clock is ready to be set.


### Notice:

If the display is " blank " after plugging in, slide the "  " (Display Dimmer) button to brighten the screen.


# Time Setting & 12/24H Switch

Press "🕒" → HOUR → MINUTE → 12/24H → Press "🕒"


1. First, press the "🕒" button to enter HOUR setting. The HOUR digits will flash on the display. Press " + " or " - " button to advance to the correct hour.



2. Second, press again the "🕒" button to confirm and enter MINUTE setting. When the MINUTE digits flash, press " + " or " - " button to advance to the correct minute.



3. Again, press the "  " button, press " + " or " - " button to switch and enter 12H or 24H hour choice of display.



4. Finally, press the "  " button to confirm and exit the time setting mode.


## Notice:

In 12 hour mode, " AM " will appear in the morning and " PM " will appear in the afternoon.


## Alarm & Volume Setting

Press "  " → **ALARM HOUR** → **ALARM MINUTE** → Press "  "


1. First, press the "  " button to enter ALARM HOUR setting. The HOUR digits will flash on the display. Press " + " or " - " button to advance to the desired hour.



2. Second, press the "  " button to enter ALARM MINUTE setting. The MINUTE digits will flash on the display. Press " + " or " - " button to advance to the desired minute.



3. Again, press the "  " button once again to enter the ALARM VOLUME setting. A number will be shown on the display and there will be a beeping alarm sound. Press the " + " or " - " button to select the volume level (The higher the number, the louder the volume) .



## Alarm On/Off

Press and hold 3S the "  " button to turn on or off alarm. If the "  " icon displays, it means the alarm is on. If the "  " icon doesn't display, it means the alarm is off.

## Alarm Pause & Snooze

When the alarm goes off, you have 2 options:

1. Press any button except " SNOOZE " button to stop the alarm when it's ringing and it will still go off on the nextday.
2. Press the " SNOOZE " button to activate the snooze. the "  " will flash on the display and the alarm will ring again after 9 minutes.
3. During the snooze process, Press any button except the " SNOOZE " to cancel the snooze time.

# Wireless Charging Function

## Phone Wireless charging

Please place your phone horizontally on the phone wireless charging pad, Once the charging connection is successful, the front side " YORTOT " indicator light turns on 5S blue light and then turns off.

### Notice:

1. The " YORTOT " indicator light on the front will alert you by flashing if there is a metal foreign object on the wireless charging pad.
2. Please remove any protective cases containing magnets, metal, or materials thicker than 0.32'(8mm).

## Airpods plug-in charging

Simply connect the charging port to your airpods and it's ready to charge.

## Iwatch wireless charging

When using this product to charge your iwatch for the first time, please install the wireless charging cable that is compatible with your iwatch in advance.


## The installation steps are as follows:




1. Remove the cover of the cable storage box on the back.




2. Fix your iwatch charging disk on the iwatch charging stand.



3. Plug the other end of the iwatch charger into the USB/USB-C port.



4. Bury the iwatch charging cable in the iwatch cable groove according to the path.



5. Fold and Bind the excess iwatch charging cable into the cable storage box.



6. Close the cover of the cable storage box and connect the machine to home power supply.

**Notice:**

1. IWatch wireless charging cable not included
2. Iwatch charging only works with apple watch.

## Wireless Charging Function

1. Compatible phones : iPhone 14 / 13 / 13 Pro / 13Pro Max / 13 mini / 12 / 12Pro / 12Pro Max / 12 mini / 11 / 11 Pro / 11 Pro Max / X / XR / XS / XS Max / 8 / 8 Plus; SAMSUNG S22 Ultra / S22+ / S22 / S21 Ultra 5G / S21+ / S21 / S21 FE/ S20 / S10 / S9 / S9+ / S8 / S8+ / S7 / S7 Edge/ S6 Edge Plus / Note 10 / 10+ / Note 9 / Note 8 / Note 7/ Note 5 / Note FE / W2017(SM-W2017) / Kelly(SM-W2018) / Galaxy S Lite (SM-G8750) and other phone with wireless charging function.
2. Compatible iwatches: Apple Watch 8 / Ultra / SE / 7/ 6 / 5 / 4 / 3 / 2.
3. Compatible airpods: AirPods1 / 2 / 3 / pro.

## Night light & Nightlight Dimmer

Turn On



Switch Colour (7 kinds)



Turn Off

1. ON/SWITCH/OFF : Press the " Light/SNOOZE " button to turn on/switch colours the night light, long press " Light / Snooze " to turn off the night light.

2. Nightlight Brightness Adjustment : Rolling "  " (Nightlight Dimmer) to adjust the brightness of night light.

**Notice:**

If the night light doesn't work after turning it on, try scrolling " Nightlight Dimmer " to turn up the brightness of the night light.

YORTOT provides you with 12-MONTH WARRANTY and 24-HOUR ONLINE SERVICE, if you have any questions about the product, please contact us: [customer@kerweilai.com](mailto:customer@kerweilai.com)

## **FCC Compliance Statement**

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference.
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.