



Input voltage and current: 5V 2A

Output power: 5W

Sensing distance: 4mm

Inefficiency:>80%

Instructions:

1. Connect the external 5V 2A power supply to the Type-C input port of the product through the USB-C charging cable, and the LED indicator blinks alternately red and green for 2 seconds and then goes off.
2. When the mobile phone and other charged devices are involved, the green indicator light starts to breathe and blink, indicating that the product is working on external output.
3. After the charged device is fully charged, the indicator turns off and you can remove the charged device.
4. Card reading function: when the TF card is inserted into the card slot, connect the computer with the product through the transmission line. The computer system will automatically identify the external TF card and display it in the computer system in the form of U disk. USB transmission type is USB2.0, and the actual transmission speed is about 30MB/s

FCC WARNING

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum distance between 20cm the radiator your body: Use only the supplied antenna.